

PRODUCT-DETAILS

2006/1 UC-92-507

2006/1 UC-92-507 Cover Plates Rocker/button  
Off switch 1-pole white - Basic55



### General Information

Extended Product Type	2006/1 UC-92-507
Product ID	2CKA001012A2146
EAN	4011395091081
Catalog Description	2006/1 UC-92-507 Cover Plates Rocker/button Off switch 1-pole white - Basic55
Long Description	2006/1 UC-92-507 1G 1W Switch

### Technical

Rated Voltage ( $U_r$ )	250 V
Auxiliary Voltage AC/DC	250 V AC/DC
Rated Current ( $I_n$ )	10 A
Maximum Switching Current	Fluorescent Lamps 10 A
Number of Rocker Switches	1
Design Range	Basic55
Wiring Configuration	Off switch 1-pole
Actuator Type	Rocker/button
Connection Type	Plug Clamp
Mounting Type	Flush Mounted
Surface Finishing	Untreated Matt
Material	Thermoplastic
Label Space Provided	No
Illumination	Non-illuminated

Color white

## Environmental

RoHS Status Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019  
 RoHS Information 2CKA200000E0137  
 REACH Declaration 2CKA309999E9999

## Dimensions

Product Net Width 71 mm  
 Product Net Height 32 mm  
 Product Net Depth / Length 71 mm  
 Product Net Weight 70 g  
 Built-In Depth (t<sub>2</sub>) 32 mm

## Ordering

Minimum Order Quantity 1 piece  
 Package Level 1 Units carton 10 piece  
 Package Level 1 Gross Weight 0.87 kg  
 Customs Tariff Number 85365080  
 Country of Origin Germany (DE)

## Certificates and Declarations

Declaration of Conformity 2CKA100000E0046  
 - CE

## Popular Downloads

Data Sheet, Technical Information No document needed  
 Instructions and Manuals No document needed

## Classifications

ETIM 8 EC001590 - Installation switch  
 ETIM 9 EC001590 - Installation switch  
 WEEE Category 5. Small Equipment (No External Dimension More Than 50 cm)  
 WEEE B2C / B2B Business To Consumer  
 CN8 8536 50 80  
 eClass V11.0 : 27144053

## Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001725A1531	2511-91-507 Cover Frame 1gang(s) entrée-grey - Basic55	2511-91-507	1	piece
2CKA001725A1484	2511-92-507 Cover Frame 1gang(s) white - Basic55	2511-92-507	1	piece
2CKA001725A1501	2511-93-507 Cover Frame 1gang(s) champagne - Basic55	2511-93-507	1	piece
2CKA001725A1479	2511-94-507 Cover Frame 1gang(s) alpine white - Basic55	2511-94-507	1	piece

2CKA001725A1506	2511-95-507 Cover Frame 1gang(s) château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	2511-96-507 Cover Frame 1gang(s) chalet-white - Basic55	2511-96-507	1	piece
2CKA001725A1516	2511-97-507 Cover Frame 1gang(s) foyer-red - Basic55	2511-97-507	1	piece
2CKA001725A1521	2511-98-507 Cover Frame 1gang(s) bistro-blue - Basic55	2511-98-507	1	piece
2CKA001725A1526	2511-99-507 Cover Frame 1gang(s) maison-beige - Basic55	2511-99-507	1	piece
2CKA001725A1532	2512-91-507 Cover Frame 2gang(s) entrée-grey - Basic55	2512-91-507	1	piece
2CKA001725A1485	2512-92-507 Cover Frame 2gang(s) white - Basic55	2512-92-507	1	piece
2CKA001725A1502	2512-93-507 Cover Frame 2gang(s) champagne - Basic55	2512-93-507	1	piece
2CKA001725A1480	2512-94-507 Cover Frame 2gang(s) alpine white - Basic55	2512-94-507	1	piece
2CKA001725A1507	2512-95-507 Cover Frame 2gang(s) château-black - Basic55	2512-95-507	1	piece
2CKA001725A1512	2512-96-507 Cover Frame 2gang(s) chalet-white - Basic55	2512-96-507	1	piece
2CKA001725A1517	2512-97-507 Cover Frame 2gang(s) foyer-red - Basic55	2512-97-507	1	piece
2CKA001725A1522	2512-98-507 Cover Frame 2gang(s) bistro-blue - Basic55	2512-98-507	1	piece
2CKA001725A1527	2512-99-507 Cover Frame 2gang(s) maison-beige - Basic55	2512-99-507	1	piece
2CKA001725A1533	2513-91-507 Cover Frame 3gang(s) entrée-grey - Basic55	2513-91-507	1	piece
2CKA001725A1486	2513-92-507 Cover Frame 3gang(s) white - Basic55	2513-92-507	1	piece
2CKA001725A1503	2513-93-507 Cover Frame 3gang(s) champagne - Basic55	2513-93-507	1	piece
2CKA001725A1481	2513-94-507 Cover Frame 3gang(s) alpine white - Basic55	2513-94-507	1	piece
2CKA001725A1508	2513-95-507 Cover Frame 3gang(s) château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	2513-96-507 Cover Frame 3gang(s) chalet-white - Basic55	2513-96-507	1	piece
2CKA001725A1518	2513-97-507 Cover Frame 3gang(s) foyer-red - Basic55	2513-97-507	1	piece
2CKA001725A1523	2513-98-507 Cover Frame 3gang(s) bistro-blue - Basic55	2513-98-507	1	piece
2CKA001725A1528	2513-99-507 Cover Frame 3gang(s) maison-beige - Basic55	2513-99-507	1	piece
2CKA001725A1534	2514-91-507 Cover Frame 4gang(s) entrée-grey - Basic55	2514-91-507	1	piece
2CKA001725A1487	2514-92-507 Cover Frame 4gang(s) white - Basic55	2514-92-507	1	piece
2CKA001725A1504	2514-93-507 Cover Frame 4gang(s) champagne - Basic55	2514-93-507	1	piece
2CKA001725A1482	2514-94-507 Cover Frame 4gang(s) alpine white - Basic55	2514-94-507	1	piece
2CKA001725A1509	2514-95-507 Cover Frame 4gang(s) château-black - Basic55	2514-95-507	1	piece
2CKA001725A1514	2514-96-507 Cover Frame 4gang(s) chalet-white - Basic55	2514-96-507	1	piece
2CKA001725A1519	2514-97-507 Cover Frame 4gang(s) foyer-red - Basic55	2514-97-507	1	piece
2CKA001725A1524	2514-98-507 Cover Frame 4gang(s) bistro-blue - Basic55	2514-98-507	1	piece
2CKA001725A1529	2514-99-507 Cover Frame 4gang(s) maison-beige - Basic55	2514-99-507	1	piece
2CKA001725A1535	2515-91-507 Cover Frame 5gang(s) entrée-grey - Basic55	2515-91-507	1	piece
2CKA001725A1488	2515-92-507 Cover Frame 5gang(s) white - Basic55	2515-92-507	1	piece
2CKA001725A1505	2515-93-507 Cover Frame 5gang(s) champagne - Basic55	2515-93-507	1	piece

2CKA001725A1483	2515-94-507 Cover Frame 5gang(s) alpine white - Basic55	2515-94-507	1	piece
2CKA001725A1510	2515-95-507 Cover Frame 5gang(s) château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	2515-96-507 Cover Frame 5gang(s) chalet-white - Basic55	2515-96-507	1	piece
2CKA001725A1520	2515-97-507 Cover Frame 5gang(s) foyer-red - Basic55	2515-97-507	1	piece
2CKA001725A1525	2515-98-507 Cover Frame 5gang(s) bistro-blue - Basic55	2515-98-507	1	piece
2CKA001725A1530	2515-99-507 Cover Frame 5gang(s) maison-beige - Basic55	2515-99-507	1	piece
2CKA001726A0222	2516-901-507 Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	2516-902-507 Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	2516-903-507 Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	2516-904-507 Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	2516-905-507 Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece
2CKA001726A0227	2516-906-507 Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	2516-907-507 Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	2516-92-507 Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	2516-93-507 Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece
2CKA001726A0218	2516-94-507 Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	2516-95-507 Decorative Styling Frame château-black - Basic55	2516-95-507	1	piece
2CKA001726A0234	2516-96-507 Decorative Styling Frame chalet-white - Basic55	2516-96-507	1	piece

---

## Categories

---

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates → Switch & Push Buttons

