



PRODUCT-DETAILS

1724-45M-500

Cover frame 4-gang black matt - Busch-art linear



General Information

| | |
|-------------------------------|--|
| Extended Product Type: | 1724-45M-500 |
| Product ID: | 2CKA001754A4868 |
| EAN: | 4011395321270 |
| Catalog Description: | Cover frame 4-gang black matt - Busch-art linear |
| Long Description: | For vertical or horizontal installation. |
| Display Name: | 1724-45M-500 |

Installation

| | |
|-------------------------------------|------------------------|
| Instructions and Manuals: | No document needed |
| Mounting Type: | Flush Mounted |
| Type of Fastening: | Clamp |
| Mounting Orientation: | Horizontal Vertical |
| Modular Components Included: | Cover Frame |

Environmental

| | |
|------------------------------|------|
| Degree of Protection: | IP20 |
|------------------------------|------|

Technical

| | |
|---|--------------------|
| Data Sheet, Technical Information: | No document needed |
|---|--------------------|

| | |
|---------------------------|---------|
| Options Available: | "basic" |
|---------------------------|---------|

Design

| | |
|----------------------|------------------|
| Design Range: | Busch-art linear |
|----------------------|------------------|

| | |
|------------------------------|------------------|
| Design Range Variant: | Busch-art linear |
|------------------------------|------------------|

| | |
|---------------------------|-------------------|
| Surface Finishing: | Lacquered Matt |
|---------------------------|-------------------|

| | |
|------------------|--------------------------|
| Material: | Plastic Thermoplastic |
|------------------|--------------------------|

| | |
|------------------------------|---------------------|
| Label Space Provided: | Without Label Space |
|------------------------------|---------------------|

| | |
|--------------------|---------------------|
| RAL Number: | Similar to RAL 9005 |
|--------------------|---------------------|

| | |
|---------------|------------|
| Color: | black matt |
|---------------|------------|

| | |
|-------------------------|--------|
| Number of Gangs: | 4-gang |
|-------------------------|--------|

| | |
|---------------------------|----------------------------|
| Number of Modules: | Horizontal 4 Vertical 4 |
|---------------------------|----------------------------|

Dimensions

| | |
|---------------------------|-------|
| Product Net Width: | 85 mm |
|---------------------------|-------|

| | |
|----------------------------|----------|
| Product Net Height: | 298.3 mm |
|----------------------------|----------|

| | |
|------------------------------------|--------|
| Product Net Depth / Length: | 8.6 mm |
|------------------------------------|--------|

| | |
|----------------------------|------|
| Product Net Weight: | 42 g |
|----------------------------|------|

| | |
|---------------------------|-----------------|
| Dimension Diagram: | 2CKA000097E4046 |
|---------------------------|-----------------|

Material Compliance

| | |
|--------------------------|-----------------|
| RoHS Declaration: | 2CKA200000E8182 |
|--------------------------|-----------------|

| | |
|--------------------------|--|
| RoHS Information: | Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019 |
|--------------------------|--|

| | |
|---------------------------|-----------------|
| REACH Declaration: | 2CKA309999E9999 |
|---------------------------|-----------------|

| | |
|---------------------------|---|
| REACH Information: | False - does not contain substances > 0.1 mass percentage |
|---------------------------|---|

| | |
|--------------------|----------|
| REACH Date: | 20260216 |
|--------------------|----------|

| | |
|---|-----------------|
| Conflict Minerals Reporting Template (CMRT): | 9AKK108468A3363 |
|---|-----------------|

| | |
|-----------------------|---------------------------|
| WEEE Category: | Product Not in WEEE Scope |
|-----------------------|---------------------------|

Certificates and Declarations

Declaration of Conformity - CE: No declaration needed

EU Data Act Applicability and Compliance: Not Applicable

External Classifications and Standards

ETIM 9: EC000007 - Cover frame for domestic switching devices

ETIM 10: EC000007 - Cover frame for domestic switching devices

eClass: V11.0 : 27144001

Accessories

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|-----------------|-----|-----------------|
| 2CKA001751A3333 | Rocker for Switch/push button, Single rocker studio white - Busch-art linear | 1786-44G | 1 | piece |
| 2CKA001751A3334 | Rocker for Switch/push button, Single rocker studio white matt - Busch-art linear | 1786-44M | 1 | piece |
| 2CKA001751A3336 | Rocker for Switch/push button, Single rocker black matt - Busch-art linear | 1786-45M | 1 | piece |
| 2CKA001751A3337 | Rocker for Switch/push button, Single rocker studio white - Busch-art linear | 1786-44G-500 | 1 | piece |
| 2CKA001751A3338 | Rocker for Switch/push button, Single rocker studio white matt - Busch-art linear | 1786-44M-500 | 1 | piece |
| 2CKA001751A3340 | Rocker for Switch/push button, Single rocker black matt - Busch-art linear | 1786-45M-500 | 1 | piece |
| 2CKA002013A5489 | SCHUKO® socket insert Safety Shutter studio white - Busch-art linear | 20 EUCB-44G | 1 | piece |
| 2CKA002013A5490 | SCHUKO® socket insert Safety Shutter studio white matt - Busch-art linear | 20 EUCB-44M | 1 | piece |
| 2CKA002013A5492 | SCHUKO® socket insert Safety Shutter black matt - Busch-art linear | 20 EUCB-45M | 1 | piece |
| 2CKA002013A5493 | Socket insert Safety Shutter studio white - Busch-art linear | 20 EUCB-44G-500 | 1 | piece |
| 2CKA002013A5494 | Socket insert Safety Shutter studio white matt - Busch-art linear | 20 EUCB-44M-500 | 1 | piece |
| 2CKA002013A5496 | Socket insert Safety Shutter black matt - Busch-art linear | 20 EUCB-45M-500 | 1 | piece |
| 2CKA001751A3409 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 NWD-44G | 1 | piece |
| 2CKA001751A3410 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 NWD-44M | 1 | piece |
| 2CKA001751A3412 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 NWD-45M | 1 | piece |
| 2CKA001751A3341 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white - Busch-art linear | 2520 KI-44G | 1 | piece |
| 2CKA001751A3342 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - Busch-art linear | 2520 KI-44M | 1 | piece |
| 2CKA001751A3344 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - Busch-art linear | 2520 KI-45M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|---|----------------|-----|-----------------|
| 2CKA001751A3345 | Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white - Busch-art linear | 2520 LI-44G | 1 | piece |
| 2CKA001751A3346 | Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - Busch-art linear | 2520 LI-44M | 1 | piece |
| 2CKA001751A3348 | Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - Busch-art linear | 2520 LI-45M | 1 | piece |
| 2CKA001751A3349 | Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - Busch-art linear | 2520 TR-44G | 1 | piece |
| 2CKA001751A3350 | Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - Busch-art linear | 2520 TR-44M | 1 | piece |
| 2CKA001751A3352 | Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - Busch-art linear | 2520 TR-45M | 1 | piece |
| 2CKA001731A4021 | Rocker with labelling field for Switch/push button, Single rocker studio white - Busch-art linear | 1764 N-44G | 1 | piece |
| 2CKA001731A4022 | Rocker with labelling field for Switch/push button, Single rocker studio white matt - Busch-art linear | 1764 N-44M | 1 | piece |
| 2CKA001731A4024 | Rocker with labelling field for Switch/push button, Single rocker black matt - Busch-art linear | 1764 N-45M | 1 | piece |
| 2CKA001731A4025 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker studio white - Busch-art linear | 1764 N/KI-44G | 1 | piece |
| 2CKA001731A4026 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker studio white matt - Busch-art linear | 1764 N/KI-44M | 1 | piece |
| 2CKA001731A4028 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker black matt - Busch-art linear | 1764 N/KI-45M | 1 | piece |
| 2CKA001751A3353 | Rocker with legend Characters 0 and 1 with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1788-44G | 1 | piece |
| 2CKA001751A3354 | Rocker with legend Characters 0 and 1 with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1788-44M | 1 | piece |
| 2CKA001751A3356 | Rocker with legend Characters 0 and 1 with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1788-45M | 1 | piece |
| 2CKA001751A3357 | Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 H-44G | 1 | piece |
| 2CKA001751A3358 | Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 H-44M | 1 | piece |
| 2CKA001751A3360 | Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 H-45M | 1 | piece |
| 2CKA001751A3361 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 N-44G | 1 | piece |
| 2CKA001751A3362 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 N-44M | 1 | piece |
| 2CKA001751A3364 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 N-45M | 1 | piece |
| 2CKA001751A3365 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 N-44G-500 | 1 | piece |
| 2CKA001751A3366 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 N-44M-500 | 1 | piece |
| 2CKA001751A3368 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 N-45M-500 | 1 | piece |
| 2CKA001751A3369 | Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 KI-44G | 1 | piece |
| 2CKA001751A3370 | Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 KI-44M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|-----------------|-----|-----------------|
| 2CKA001751A3372 | Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 KI-45M | 1 | piece |
| 2CKA001751A3373 | Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 LI-44G | 1 | piece |
| 2CKA001751A3374 | Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 LI-44M | 1 | piece |
| 2CKA001751A3376 | Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 LI-45M | 1 | piece |
| 2CKA001751A3377 | Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 TR-44G | 1 | piece |
| 2CKA001751A3378 | Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 TR-44M | 1 | piece |
| 2CKA001751A3380 | Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 TR-45M | 1 | piece |
| 2CKA001751A3381 | Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear | 1789 ST-44G | 1 | piece |
| 2CKA001751A3382 | Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 ST-44M | 1 | piece |
| 2CKA001751A3384 | Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear | 1789 ST-45M | 1 | piece |
| 2CKA001751A3305 | Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker studio white - Busch-art linear | 1785 K-44G | 1 | piece |
| 2CKA001751A3306 | Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker studio white matt - Busch-art linear | 1785 K-44M | 1 | piece |
| 2CKA001751A3308 | Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker black matt - Busch-art linear | 1785 K-45M | 1 | piece |
| 2CKA001751A3385 | Rocker for Switch/push button, Two-part rocker studio white - Busch-art linear | 1785-44G | 1 | piece |
| 2CKA001751A3386 | Rocker for Switch/push button, Two-part rocker studio white matt - Busch-art linear | 1785-44M | 1 | piece |
| 2CKA001751A3388 | Rocker for Switch/push button, Two-part rocker black matt - Busch-art linear | 1785-45M | 1 | piece |
| 2CKA001751A3389 | Rocker for Switch/push button, Two-part rocker studio white - Busch-art linear | 1785-44G-500 | 1 | piece |
| 2CKA001751A3390 | Rocker for Switch/push button, Two-part rocker studio white matt - Busch-art linear | 1785-44M-500 | 1 | piece |
| 2CKA001751A3392 | Rocker for Switch/push button, Two-part rocker black matt - Busch-art linear | 1785-45M-500 | 1 | piece |
| 2CKA001751A3393 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - Busch-art linear | 1785 JA-44G | 1 | piece |
| 2CKA001751A3394 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - Busch-art linear | 1785 JA-44M | 1 | piece |
| 2CKA001751A3396 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - Busch-art linear | 1785 JA-45M | 1 | piece |
| 2CKA001751A3397 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - Busch-art linear | 1785 JA-44G-500 | 1 | piece |
| 2CKA001751A3398 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - Busch-art linear | 1785 JA-44M-500 | 1 | piece |
| 2CKA001751A3400 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - Busch-art linear | 1785 JA-45M-500 | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|--------------------|-----|-----------------|
| 2CKA002011A6316 | SCHUKO® USB socket insert Safety Shutter with USB A/C studio white - Busch-art linear | 20 EUCB2USBAC-44G | 1 | piece |
| 2CKA002011A6318 | SCHUKO® USB socket insert Safety Shutter with USB A/C studio white matt - Busch-art linear | 20 EUCB2USBAC-44M | 1 | piece |
| 2CKA002011A6322 | SCHUKO® USB socket insert Safety Shutter with USB A/C black matt - Busch-art linear | 20 EUCB2USBAC-45M | 1 | piece |
| 2CKA002013A5521 | SCHUKO® socket insert flat Safety Shutter studio white - Busch-art linear | 20-1 EUCBF-44G | 1 | piece |
| 2CKA002013A5522 | SCHUKO® socket insert flat Safety Shutter studio white matt - Busch-art linear | 20-1 EUCBF-44M | 1 | piece |
| 2CKA002013A5524 | SCHUKO® socket insert flat Safety Shutter black matt - Busch-art linear | 20-1 EUCBF-45M | 1 | piece |
| 2CKA002013A5525 | Socket insert Safety Shutter studio white - Busch-art linear | 20-1 EUCBF-44G-500 | 1 | piece |
| 2CKA002013A5526 | Socket insert Safety Shutter studio white matt - Busch-art linear | 20-1 EUCBF-44M-500 | 1 | piece |
| 2CKA002013A5528 | Socket insert Safety Shutter black matt - Busch-art linear | 20-1 EUCBF-45M-500 | 1 | piece |
| 2CKA002017A1905 | Socket insert flat with earthing pin Safety Shutter studio white - Busch-art linear | 20-1 MUCB-44G | 1 | piece |
| 2CKA002017A1906 | Socket insert flat with earthing pin Safety Shutter studio white matt - Busch-art linear | 20-1 MUCB-44M | 1 | piece |
| 2CKA002017A1908 | Socket insert flat with earthing pin Safety Shutter black matt - Busch-art linear | 20-1 MUCB-45M | 1 | piece |
| 2CKA002013A5497 | SCHUKO® socket insert Safety Shutter without claw studio white - Busch-art linear | 20 EUCRB-44G | 1 | piece |
| 2CKA002013A5498 | SCHUKO® socket insert Safety Shutter without claw studio white matt - Busch-art linear | 20 EUCRB-44M | 1 | piece |
| 2CKA002013A5500 | SCHUKO® socket insert Safety Shutter without claw black matt - Busch-art linear | 20 EUCRB-45M | 1 | piece |
| 2CKA002013A5501 | Socket insert Safety Shutter without claw studio white - Busch-art linear | 20 EUCRB-44G-500 | 1 | piece |
| 2CKA002013A5502 | Socket insert Safety Shutter without claw studio white matt - Busch-art linear | 20 EUCRB-44M-500 | 1 | piece |
| 2CKA002013A5504 | Socket insert Safety Shutter without claw black matt - Busch-art linear | 20 EUCRB-45M-500 | 1 | piece |
| 2CKA002013A5505 | SCHUKO® socket insert Safety Shutter with screw terminals studio white - Busch-art linear | 23 EUCB-44G | 1 | piece |
| 2CKA002013A5506 | SCHUKO® socket insert Safety Shutter with screw terminals studio white matt - Busch-art linear | 23 EUCB-44M | 1 | piece |
| 2CKA002013A5508 | SCHUKO® socket insert Safety Shutter with screw terminals black matt - Busch-art linear | 23 EUCB-45M | 1 | piece |
| 2CKA002013A5509 | SCHUKO® socket insert Safety Shutter with label space studio white - Busch-art linear | 20 EUCNB-44G | 1 | piece |
| 2CKA002013A5510 | SCHUKO® socket insert Safety Shutter with label space studio white matt - Busch-art linear | 20 EUCNB-44M | 1 | piece |
| 2CKA002013A5512 | SCHUKO® socket insert Safety Shutter with label space black matt - Busch-art linear | 20 EUCNB-45M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|------------------|-----|-----------------|
| 2CKA002013A5513 | SCHUKO® socket insert Safety Shutter with LED Control light /Green studio white - Busch-art linear | 20 EUCBL-44G | 1 | piece |
| 2CKA002013A5514 | SCHUKO® socket insert Safety Shutter with LED Control light /Green studio white matt - Busch-art linear | 20 EUCBL-44M | 1 | piece |
| 2CKA002013A5516 | SCHUKO® socket insert Safety Shutter with LED Control light /Green black matt - Busch-art linear | 20 EUCBL-45M | 1 | piece |
| 2CKA002018A1579 | SCHUKO® socket insert Safety Shutter with Hinged Lid without claw studio white - Busch-art linear | 20 EUKBR-44G | 1 | piece |
| 2CKA002018A1580 | SCHUKO® socket insert Safety Shutter with Hinged Lid without claw studio white matt - Busch-art linear | 20 EUKBR-44M | 1 | piece |
| 2CKA002018A1582 | SCHUKO® socket insert Safety Shutter with Hinged Lid without claw black matt - Busch-art linear | 20 EUKBR-45M | 1 | piece |
| 2CKA002013A5517 | Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White studio white - Busch-art linear | 20 EUCBLI-44G | 1 | piece |
| 2CKA002013A5518 | Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White studio white matt - Busch-art linear | 20 EUCBLI-44M | 1 | piece |
| 2CKA002013A5520 | Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White black matt - Busch-art linear | 20 EUCBLI-45M | 1 | piece |
| 2CKA002018A1575 | SCHUKO® socket insert Safety Shutter with Hinged Lid studio white - Busch-art linear | 20 EUKB-44G | 1 | piece |
| 2CKA002018A1576 | SCHUKO® socket insert Safety Shutter with Hinged Lid studio white matt - Busch-art linear | 20 EUKB-44M | 1 | piece |
| 2CKA002018A1578 | SCHUKO® socket insert Safety Shutter with Hinged Lid black matt - Busch-art linear | 20 EUKB-45M | 1 | piece |
| 2CKA002017A1909 | Socket insert with earthing pin Safety Shutter with Hinged Lid studio white - Busch-art linear | 20-1 MUCBK-44G | 1 | piece |
| 2CKA002017A1910 | Socket insert with earthing pin Safety Shutter with Hinged Lid studio white matt - Busch-art linear | 20-1 MUCBK-44M | 1 | piece |
| 2CKA002017A1912 | Socket insert with earthing pin Safety Shutter with Hinged Lid black matt - Busch-art linear | 20-1 MUCBK-45M | 1 | piece |
| 2CKA001763A0032 | Sealing Set with Sealing Ring transparent - Busch-art linear | 20 WD-4X | 1 | piece |
| 2CKA001710A4141 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white - Busch-art linear | 1740-44G | 1 | piece |
| 2CKA001710A4142 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white matt - Busch-art linear | 1740-44M | 1 | piece |
| 2CKA001710A4144 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button black matt - Busch-art linear | 1740-45M | 1 | piece |
| 2CKA006599A3052 | Cover plate for Dimmer Turn button with Neon lamp studio white - Busch-art linear | 6540-44G-102 | 1 | piece |
| 2CKA006599A3053 | Cover plate for Dimmer Turn button with Neon lamp studio white matt - Busch-art linear | 6540-44M-102 | 1 | piece |
| 2CKA006599A3055 | Cover plate for Dimmer Turn button with Neon lamp black matt - Busch-art linear | 6540-45M-102 | 1 | piece |
| 2CKA006599A3056 | Cover plate for Dimmer Turn button with Neon lamp studio white - Busch-art linear | 6540-44G-102-500 | 1 | piece |
| 2CKA006599A3057 | Cover plate for Dimmer Turn button with Neon lamp studio white matt - Busch-art linear | 6540-44M-102-500 | 1 | piece |
| 2CKA006599A3059 | Cover plate for Dimmer Turn button with Neon lamp black matt - Busch-art linear | 6540-45M-102-500 | 1 | piece |
| 2CKA006155A0122 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44G | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|---|-----------------|-----|-----------------|
| 2CKA006155A0123 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44M | 1 | piece |
| 2CKA006155A0125 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller black - Busch-art linear | 6109/03-45M | 1 | piece |
| 2CKA006155A0126 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44G-500 | 1 | piece |
| 2CKA006155A0127 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44M-500 | 1 | piece |
| 2CKA006155A0129 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller black - Busch-art linear | 6109/03-45M-500 | 1 | piece |
| 2CKA006220A0920 | Cover plate Symbols "up, down, ECO, Power" 2gang studio white - Busch-art linear | 6235-44G | 1 | piece |
| 2CKA006220A0921 | Cover plate Symbols "up, down, ECO, Power" 2gang studio white matt - Busch-art linear | 6235-44M | 1 | piece |
| 2CKA006220A0923 | Cover plate Symbols "up, down, ECO, Power" 2gang black matt - Busch-art linear | 6235-45M | 1 | piece |
| 2CKA001710A4206 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Busch-art linear | 1794 R-44M | 1 | piece |
| 2CKA001710A4207 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Busch-art linear | 1794 R-44G | 1 | piece |
| 2CKA001710A4208 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Busch-art linear | 1794 R-45M | 1 | piece |
| 2CKA006430A0426 | Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate studio white - Busch-art linear | 1794 MDRT-44G | 1 | piece |
| 2CKA006430A0425 | Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate studio white matt - Busch-art linear | 1794 MDRT-44M | 1 | piece |
| 2CKA006430A0427 | Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate black matt - Busch-art linear | 1794 MDRT-45M | 1 | piece |
| 2CKA006800A3136 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear | 64764-44G | 1 | piece |
| 2CKA006800A3137 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear | 64764-44M | 1 | piece |
| 2CKA006800A3139 | Busch-Watchdog 180 flex Cover plate Movement sensor black - Busch-art linear | 64764-45M | 1 | piece |
| 2CKA006800A3140 | Cover plate Movement sensor white - Busch-art linear | 64764-44G-500 | 1 | piece |
| 2CKA006800A3141 | Cover plate Movement sensor white - Busch-art linear | 64764-44M-500 | 1 | piece |
| 2CKA006800A3143 | Cover plate Movement sensor black - Busch-art linear | 64764-45M-500 | 1 | piece |
| 2CKA006800A3120 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear | 64761-44G | 1 | piece |
| 2CKA006800A3121 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear | 64761-44M | 1 | piece |
| 2CKA006800A3123 | Busch-Watchdog 180 flex Cover plate Movement sensor black - Busch-art linear | 64761-45M | 1 | piece |
| 2CKA006800A3124 | Busch-Watchdog Cover plate Movement sensor white - Busch-art linear | 64761-44G-500 | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|---|----------------|-----|-----------------|
| 2CKA006800A3125 | Busch-Watchdog Cover plate Movement sensor white - Busch-art linear | 64761-44M-500 | 1 | piece |
| 2CKA006800A3127 | Busch-Watchdog Cover plate Movement sensor black - Busch-art linear | 64761-45M-500 | 1 | piece |
| 2CKA001751A3309 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button, Two-part rocker studio white - Busch-art linear | 1785/11 K-44G | 1 | piece |
| 2CKA001751A3310 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button, Two-part rocker studio white matt - Busch-art linear | 1785/11 K-44M | 1 | piece |
| 2CKA001751A3312 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button, Two-part rocker black matt - Busch-art linear | 1785/11 K-45M | 1 | piece |
| 2CKA001751A3401 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED studio white - Busch-art linear | 2029/12 UC-44G | 1 | piece |
| 2CKA001751A3402 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED studio white matt - Busch-art linear | 2029/12 UC-44M | 1 | piece |
| 2CKA001751A3404 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED black matt - Busch-art linear | 2029/12 UC-45M | 1 | piece |
| 2CKA001751A3405 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO studio white - Busch-art linear | 2029 UC-44G | 1 | piece |
| 2CKA001751A3406 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO studio white matt - Busch-art linear | 2029 UC-44M | 1 | piece |
| 2CKA001751A3408 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO black matt - Busch-art linear | 2029 UC-45M | 1 | piece |
| 2CKA001710A4240 | Cover plate with legend Card, Symbol "arrows" with Transparent Calotte 2-1792 U-44G pole push button 2P with LED Orientation light 1NO studio white - Busch-art linear | 1792 U-44G | 1 | piece |
| 2CKA001710A4241 | Cover plate with legend Card, Symbol "arrows" with Transparent Calotte 2-1792 U-44M pole push button 2P with LED Orientation light 1NO studio white matt - Busch-art linear | 1792 U-44M | 1 | piece |
| 2CKA001710A4243 | Cover plate with legend Card, Symbol "arrows" with Transparent Calotte 2-1792 U-45M pole push button 2P with LED Orientation light 1NO black matt - Busch-art linear | 1792 U-45M | 1 | piece |
| 2CKA001710A4244 | Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card studio white - Busch-art linear | 1792 RFID-44G | 1 | piece |
| 2CKA001710A4245 | Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card studio white matt - Busch-art linear | 1792 RFID-44M | 1 | piece |
| 2CKA001710A4247 | Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card black matt - Busch-art linear | 1792 RFID-45M | 1 | piece |
| 2CKA001751A3313 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button Two-part rocker studio white - Busch-art linear | 2058-24-44G | 1 | piece |
| 2CKA001751A3314 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button Two-part rocker studio white matt - Busch-art linear | 2058-24-44M | 1 | piece |
| 2CKA001751A3316 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button Two-part rocker black matt - Busch-art linear | 2058-24-45M | 1 | piece |
| 2CKA001751A3317 | Rocker with Small Transparent Calotte for Electronic push button Two-part rocker studio white - Busch-art linear | 2570-20-44G | 1 | piece |
| 2CKA001751A3318 | Rocker with Small Transparent Calotte for Electronic push button Two-part rocker studio white matt - Busch-art linear | 2570-20-44M | 1 | piece |
| 2CKA001751A3320 | Rocker with Small Transparent Calotte for Electronic push button Two-part rocker black matt - Busch-art linear | 2570-20-45M | 1 | piece |
| 2CKA001751A3321 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker studio white - Busch-art linear | 2059 UC-44G | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|------------------|-----|-----------------|
| 2CKA001751A3322 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker studio white matt - Busch-art linear | 2059 UC-44M | 1 | piece |
| 2CKA001751A3324 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker black matt - Busch-art linear | 2059 UC-45M | 1 | piece |
| 2CKA001751A3325 | Rocker with Small Transparent Calotte for Electronic push button Single rocker studio white - Busch-art linear | 2570-10-44G | 1 | piece |
| 2CKA001751A3326 | Rocker with Small Transparent Calotte for Electronic push button Single rocker studio white matt - Busch-art linear | 2570-10-44M | 1 | piece |
| 2CKA001751A3328 | Rocker with Small Transparent Calotte for Electronic push button Single rocker black matt - Busch-art linear | 2570-10-45M | 1 | piece |
| 2CKA001751A3329 | Rocker with Small Transparent Calotte for Electronic push button Three-part rocker studio white - Busch-art linear | 2570-30-44G | 1 | piece |
| 2CKA001751A3330 | Rocker with Small Transparent Calotte for Electronic push button Three-part rocker studio white matt - Busch-art linear | 2570-30-44M | 1 | piece |
| 2CKA001751A3332 | Rocker with Small Transparent Calotte for Electronic push button Three-part rocker black matt - Busch-art linear | 2570-30-45M | 1 | piece |
| 2CKA001751A3413 | Rocker for Smart switch Single rocker studio white - Busch-art linear | 6735 BT-44G | 1 | piece |
| 2CKA001751A3414 | Rocker for Smart switch Single rocker studio white matt - Busch-art linear | 6735 BT-44M | 1 | piece |
| 2CKA001751A3416 | Rocker for Smart switch Single rocker black matt - Busch-art linear | 6735 BT-45M | 1 | piece |
| 2CKA006730A0166 | Rocker for Smart switch Two-part rocker studio white - Busch-art linear | 6736 FoH-44G | 1 | piece |
| 2CKA006730A0167 | Rocker for Smart switch Two-part rocker studio white matt - Busch-art linear | 6736 FoH-44M | 1 | piece |
| 2CKA006730A0169 | Rocker for Smart switch Two-part rocker black matt - Busch-art linear | 6736 FoH-45M | 1 | piece |
| 2CKA001710A4137 | Cover plate with legend Loudspeaker Turn button studio white - Busch-art linear | 1740 DR/03-44G | 1 | piece |
| 2CKA001710A4138 | Cover plate with legend Loudspeaker Turn button studio white matt - Busch-art linear | 1740 DR/03-44M | 1 | piece |
| 2CKA001710A4140 | Cover plate with legend Loudspeaker Turn button black matt - Busch-art linear | 1740 DR/03-45M | 1 | piece |
| 2CKA001710A4145 | Cover plate Symbol "2-1-3" for Level switch, Turn button studio white - Busch-art linear | 1740 DRL-44G-503 | 1 | piece |
| 2CKA001710A4146 | Cover plate Symbol "2-1-3" for Level switch, Turn button studio white matt - Busch-art linear | 1740 DRL-44M-503 | 1 | piece |
| 2CKA001710A4148 | Cover plate Symbol "2-1-3" for Level switch, Turn button black matt - Busch-art linear | 1740 DRL-45M-503 | 1 | piece |
| 2CKA001753A9978 | Cover plate with legend 0 ... 120 Min for Time switch, Turning handle studio white - Busch-art linear | 1771-44G-103 | 1 | piece |
| 2CKA001753A9979 | Cover plate with legend 0 ... 120 Min for Time switch, Turning handle studio white matt - Busch-art linear | 1771-44M-103 | 1 | piece |
| 2CKA001753A9981 | Cover plate with legend 0 ... 120 Min for Time switch, Turning handle black matt - Busch-art linear | 1771-45M-103 | 1 | piece |
| 2CKA001753A9982 | Cover plate with legend 0 ... 15 Min for Time switch, Turning handle studio white - Busch-art linear | 1770-44G-103 | 1 | piece |
| 2CKA001753A9983 | Cover plate with legend 0 ... 15 Min for Time switch, Turning handle studio white matt - Busch-art linear | 1770-44M-103 | 1 | piece |
| 2CKA001753A9985 | Cover plate with legend 0 ... 15 Min for Time switch, Turning handle black matt - Busch-art linear | 1770-45M-103 | 1 | piece |
| 2CKA001710A4149 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - Busch-art linear | 2542 DR/01-44G | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|----------------|-----|-----------------|
| 2CKA001710A4150 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white matt - Busch-art linear | 2542 DR/01-44M | 1 | piece |
| 2CKA001710A4152 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button black matt - Busch-art linear | 2542 DR/01-45M | 1 | piece |
| 2CKA001710A4157 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white - Busch-art linear | 1755 SL/PZ-44G | 1 | piece |
| 2CKA001710A4158 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white matt - Busch-art linear | 1755 SL/PZ-44M | 1 | piece |
| 2CKA001710A4160 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key black matt - Busch-art linear | 1755 SL/PZ-45M | 1 | piece |
| 2CKA001710A4153 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - Busch-art linear | 2542 DR/02-44G | 1 | piece |
| 2CKA001710A4154 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white matt - Busch-art linear | 2542 DR/02-44M | 1 | piece |
| 2CKA001710A4156 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button black matt - Busch-art linear | 2542 DR/02-45M | 1 | piece |
| 2CKA008200A0285 | Cover plate with legend Busch-Radio Radio white - Busch-art linear | 8252-44G-101 | 1 | piece |
| 2CKA008200A0286 | Cover plate with legend Busch-Radio Radio white - Busch-art linear | 8252-44M-101 | 1 | piece |
| 2CKA008200A0288 | Cover plate with legend Busch-Radio Radio black - Busch-art linear | 8252-45M-101 | 1 | piece |
| 2CKA008200A0289 | Cover plate Loudspeaker white - Busch-art linear | 8253-44G | 1 | piece |
| 2CKA008200A0291 | Cover plate Loudspeaker black - Busch-art linear | 8253-45G | 1 | piece |
| 2CKA006430A0450 | Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate studio white - Busch-art linear | 6435-44G | 1 | piece |
| 2CKA006430A0451 | Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate studio white matt - Busch-art linear | 6435-44M | 1 | piece |
| 2CKA006430A0453 | Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate black matt - Busch-art linear | 6435-45M | 1 | piece |
| 2CKA006220A0924 | Rocker with Small Transparent Calotte 1gang studio white - Busch-art linear | 6230-10-44G | 1 | piece |
| 2CKA006220A0925 | Rocker with Small Transparent Calotte 1gang studio white matt - Busch-art linear | 6230-10-44M | 1 | piece |
| 2CKA006220A0927 | Rocker with Small Transparent Calotte 1gang black matt - Busch-art linear | 6230-10-45M | 1 | piece |
| 2CKA006220A0928 | Rocker Symbol "light" with Small Transparent Calotte 1gang studio white - Busch-art linear | 6231-10-44G | 1 | piece |
| 2CKA006220A0929 | Rocker Symbol "light" with Small Transparent Calotte 1gang studio white matt - Busch-art linear | 6231-10-44M | 1 | piece |
| 2CKA006220A0931 | Rocker Symbol "light" with Small Transparent Calotte 1gang black matt - Busch-art linear | 6231-10-45M | 1 | piece |
| 2CKA006220A0932 | Rocker Symbol "dimming" with Small Transparent Calotte 1gang studio white - Busch-art linear | 6234-10-44G | 1 | piece |
| 2CKA006220A0933 | Rocker Symbol "dimming" with Small Transparent Calotte 1gang studio white matt - Busch-art linear | 6234-10-44M | 1 | piece |
| 2CKA006220A0935 | Rocker Symbol "dimming" with Small Transparent Calotte 1gang black matt - Busch-art linear | 6234-10-45M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|-------------|-----|-----------------|
| 2CKA006220A0936 | Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang studio white - Busch-art linear | 6232-10-44G | 1 | piece |
| 2CKA006220A0937 | Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang studio white matt - Busch-art linear | 6232-10-44M | 1 | piece |
| 2CKA006220A0939 | Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang black matt - Busch-art linear | 6232-10-45M | 1 | piece |
| 2CKA006220A0940 | Rocker Symbol "scene" with Small Transparent Calotte 1gang studio white - Busch-art linear | 6233-10-44G | 1 | piece |
| 2CKA006220A0941 | Rocker Symbol "scene" with Small Transparent Calotte 1gang studio white matt - Busch-art linear | 6233-10-44M | 1 | piece |
| 2CKA006220A0943 | Rocker Symbol "scene" with Small Transparent Calotte 1gang black matt - Busch-art linear | 6233-10-45M | 1 | piece |
| 2CKA006220A0944 | Rocker with Small Transparent Calotte 2gang studio white - Busch-art linear | 6230-20-44G | 1 | piece |
| 2CKA006220A0945 | Rocker with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6230-20-44M | 1 | piece |
| 2CKA006220A0947 | Rocker with Small Transparent Calotte 2gang black matt - Busch-art linear | 6230-20-45M | 1 | piece |
| 2CKA006220A0948 | Rocker Symbol "light" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6231-21-44G | 1 | piece |
| 2CKA006220A0949 | Rocker Symbol "light" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6231-21-44M | 1 | piece |
| 2CKA006220A0951 | Rocker Symbol "light" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6231-21-45M | 1 | piece |
| 2CKA006220A0952 | Rocker Symbol "light" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6231-22-44G | 1 | piece |
| 2CKA006220A0953 | Rocker Symbol "light" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6231-22-44M | 1 | piece |
| 2CKA006220A0955 | Rocker Symbol "light" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6231-22-45M | 1 | piece |
| 2CKA006220A0956 | Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6234-21-44G | 1 | piece |
| 2CKA006220A0957 | Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6234-21-44M | 1 | piece |
| 2CKA006220A0959 | Rocker Symbol "dimming" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6234-21-45M | 1 | piece |
| 2CKA006220A0960 | Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6234-22-44G | 1 | piece |
| 2CKA006220A0961 | Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6234-22-44M | 1 | piece |
| 2CKA006220A0963 | Rocker Symbol "dimming" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6234-22-45M | 1 | piece |
| 2CKA006220A0964 | Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6232-20-44G | 1 | piece |
| 2CKA006220A0965 | Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6232-20-44M | 1 | piece |
| 2CKA006220A0967 | Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6232-20-45M | 1 | piece |
| 2CKA006220A0968 | Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6233-21-44G | 1 | piece |
| 2CKA006220A0969 | Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6233-21-44M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|------------------|-----|-----------------|
| 2CKA006220A0971 | Rocker Symbol "scene" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6233-21-45M | 1 | piece |
| 2CKA006220A0972 | Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6233-22-44G | 1 | piece |
| 2CKA006220A0973 | Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6233-22-44M | 1 | piece |
| 2CKA006220A0975 | Rocker Symbol "scene" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6233-22-45M | 1 | piece |
| 2CKA006220A0976 | Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6237-21-44G | 1 | piece |
| 2CKA006220A0977 | Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6237-21-44M | 1 | piece |
| 2CKA006220A0979 | Rocker Symbols "music control" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6237-21-45M | 1 | piece |
| 2CKA006220A0980 | Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white - Busch-art linear | 6237-22-44G | 1 | piece |
| 2CKA006220A0981 | Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white matt - Busch-art linear | 6237-22-44M | 1 | piece |
| 2CKA006220A0983 | Rocker Symbols "music control" with Small Transparent Calotte 2gang black matt - Busch-art linear | 6237-22-45M | 1 | piece |
| 2CKA006200A0298 | Cover plate Movement sensor Wireless white - Busch-art linear | 62762-44G-WL | 1 | piece |
| 2CKA006200A0299 | Cover plate Movement sensor Wireless white - Busch-art linear | 62762-44M-WL | 1 | piece |
| 2CKA006200A0301 | Cover plate Movement sensor Wireless black - Busch-art linear | 62762-45M-WL | 1 | piece |
| 2CKA006200A0302 | Cover plate Movement sensor Wireless white - Busch-art linear | 62762-44G-WL-500 | 1 | piece |
| 2CKA006200A0303 | Cover plate Movement sensor Wireless white - Busch-art linear | 62762-44M-WL-500 | 1 | piece |
| 2CKA006200A0305 | Cover plate Movement sensor Wireless black - Busch-art linear | 62762-45M-WL-500 | 1 | piece |
| 2CKA006800A3128 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear | 64762-44G | 1 | piece |
| 2CKA006800A3129 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear | 64762-44M | 1 | piece |
| 2CKA006800A3131 | Busch-Watchdog 180 flex Cover plate Movement sensor black - Busch-art linear | 64762-45M | 1 | piece |
| 2CKA006800A3132 | Busch-Watchdog Cover plate Movement sensor white - Busch-art linear | 64762-44G-500 | 1 | piece |
| 2CKA006800A3133 | Busch-Watchdog Cover plate Movement sensor white - Busch-art linear | 64762-44M-500 | 1 | piece |
| 2CKA006800A3135 | Busch-Watchdog Cover plate Movement sensor black - Busch-art linear | 64762-45M-500 | 1 | piece |
| 2CKA006200A0307 | Cover plate Enrolment device Wireless white - Busch-art linear | 62764-44G-WL | 1 | piece |
| 2CKA006200A0308 | Cover plate Enrolment device Wireless white - Busch-art linear | 62764-44M-WL | 1 | piece |
| 2CKA006200A0310 | Cover plate Enrolment device Wireless black - Busch-art linear | 62764-45M-WL | 1 | piece |
| 2CKA006200A0311 | Cover plate Enrolment device Wireless white - Busch-art linear | 62764-44G-WL-500 | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|------------------|-----|-----------------|
| 2CKA006200A0312 | Cover plate Enrolment device Wireless white - Busch-art linear | 62764-44M-WL-500 | 1 | piece |
| 2CKA006200A0314 | Cover plate Enrolment device Wireless black - Busch-art linear | 62764-45M-WL-500 | 1 | piece |
| 2CKA006800A3144 | Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light white - Busch-art linear | 64765-44G | 1 | piece |
| 2CKA006800A3145 | Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light white - Busch-art linear | 64765-44M | 1 | piece |
| 2CKA006800A3147 | Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light black - Busch-art linear | 64765-45M | 1 | piece |
| 2CKA001710A4170 | Intermediate Ring for cover plates Busch-Balance® SI 1-gang white - Busch-art linear | 1747 BSI-44G | 1 | piece |
| 2CKA001710A4171 | Intermediate Ring for cover plates Busch-Balance® SI 1-gang white - Busch-art linear | 1747 BSI-44M | 1 | piece |
| 2CKA001710A4173 | Intermediate Ring for cover plates Busch-Balance® SI 1-gang black - Busch-art linear | 1747 BSI-45M | 1 | piece |
| 2CKA001719A0179 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring white - Busch-art linear | 2518-WD-44G | 1 | piece |
| 2CKA001719A0180 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring white - Busch-art linear | 2518-WD-44M | 1 | piece |
| 2CKA001719A0182 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring black - Busch-art linear | 2518-WD-45M | 1 | piece |
| 2CKA001710A4174 | Cover plate 50x50 mm for data connection housing white - Busch-art linear | 1746/10-44G | 1 | piece |
| 2CKA001710A4175 | Cover plate 50x50 mm for data connection housing white - Busch-art linear | 1746/10-44M | 1 | piece |
| 2CKA001710A4177 | Cover plate 50x50 mm for data connection housing black - Busch-art linear | 1746/10-45M | 1 | piece |
| 2CKA001710A4178 | Cover plate 50x50 mm for data connection housing white - Busch-art linear | 1746/10-44G-500 | 1 | piece |
| 2CKA001710A4179 | Cover plate 50x50 mm for data connection housing white - Busch-art linear | 1746/10-44M-500 | 1 | piece |
| 2CKA001710A4181 | Cover plate 50x50 mm for data connection housing black - Busch-art linear | 1746/10-45M-500 | 1 | piece |
| 2CKA001753A9917 | Cover plate 50x50 mm with Hinged Lid for data connection housing white - Busch-art linear | 1746-44G | 1 | piece |
| 2CKA001753A9918 | Cover plate 50x50 mm with Hinged Lid for data connection housing white - Busch-art linear | 1746-44M | 1 | piece |
| 2CKA001753A9920 | Cover plate 50x50 mm with Hinged Lid for data connection housing black - Busch-art linear | 1746-45M | 1 | piece |
| 2CKA001710A4211 | Cover plate for Blind cap 1-gang with Mounting plate white - Busch-art linear | 1742-44G | 1 | piece |
| 2CKA001710A4212 | Cover plate for Blind cap 1-gang with Mounting plate white - Busch-art linear | 1742-44M | 1 | piece |
| 2CKA001710A4214 | Cover plate for Blind cap 1-gang with Mounting plate black - Busch-art linear | 1742-45M | 1 | piece |
| 2CKA001710A4215 | Cover plate for Blind cap 1-gang with Mounting plate white - Busch-art linear | 1742-44G-500 | 1 | piece |
| 2CKA001710A4216 | Cover plate for Blind cap 1-gang with Mounting plate white - Busch-art linear | 1742-44M-500 | 1 | piece |
| 2CKA001710A4218 | Cover plate for Blind cap 1-gang with Mounting plate black - Busch-art linear | 1742-45M-500 | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|---|-----------------|-----|-----------------|
| 2CKA001710A4248 | Cover plate for Cable outlet 1-gang with Mounting plate; 3-pole screw terminal block white - Busch-art linear | 1749-44G | 1 | piece |
| 2CKA001710A4249 | Cover plate for Cable outlet 1-gang with Mounting plate; 3-pole screw terminal block white - Busch-art linear | 1749-44M | 1 | piece |
| 2CKA001710A4251 | Cover plate for Cable outlet 1-gang with Mounting plate; 3-pole screw terminal block black - Busch-art linear | 1749-45M | 1 | piece |
| 2CKA001710A4162 | Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang white - Busch-art linear | 1766-44G | 1 | piece |
| 2CKA001710A4163 | Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang white - Busch-art linear | 1766-44M | 1 | piece |
| 2CKA001710A4165 | Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang black - Busch-art linear | 1766-45M | 1 | piece |
| 2CKA001710A4166 | Cover plate DSub15Pole 1 gang white - Busch-art linear | 1766-44G-500 | 1 | piece |
| 2CKA001710A4167 | Cover plate DSub15Pole 1 gang white - Busch-art linear | 1766-44M-500 | 1 | piece |
| 2CKA001710A4169 | Cover plate DSub15Pole 1 gang black - Busch-art linear | 1766-45M-500 | 1 | piece |
| 2CKA001724A4432 | Cover plate SAT 3 gang white - Busch-art linear | 1743-44G | 1 | piece |
| 2CKA001724A4433 | Cover plate SAT 3 gang white - Busch-art linear | 1743-44M | 1 | piece |
| 2CKA001724A4435 | Cover plate SAT 3 gang black - Busch-art linear | 1743-45M | 1 | piece |
| 2CKA001724A4436 | Cover plate TV / Radio / SAT 3 gang studio white - Busch-art linear | 1743-44G-500 | 1 | piece |
| 2CKA001724A4437 | Cover plate TV / Radio / SAT 3 gang studio white matt - Busch-art linear | 1743-44M-500 | 1 | piece |
| 2CKA001724A4439 | Cover plate TV / Radio / SAT 3 gang black matt - Busch-art linear | 1743-45M-500 | 1 | piece |
| 2CKA001724A4440 | Cover plate SAT 4 gang white - Busch-art linear | 1743/10-04-44G | 1 | piece |
| 2CKA001724A4441 | Cover plate SAT 4 gang white - Busch-art linear | 1743/10-04-44M | 1 | piece |
| 2CKA001724A4443 | Cover plate SAT 4 gang black - Busch-art linear | 1743/10-04-45M | 1 | piece |
| 2CKA001710A4219 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44G | 1 | piece |
| 2CKA001710A4220 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44M | 1 | piece |
| 2CKA001710A4222 | Cover plate with labelling field for data connection housing 1 gang black - Busch-art linear | 1803-45M | 1 | piece |
| 2CKA001710A4223 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44G-500 | 1 | piece |
| 2CKA001710A4224 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44M-500 | 1 | piece |
| 2CKA001710A4226 | Cover plate with labelling field for data connection housing 1 gang black - Busch-art linear | 1803-45M-500 | 1 | piece |
| 2CKA001710A4227 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44G | 1 | piece |
| 2CKA001710A4228 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44M | 1 | piece |
| 2CKA001710A4230 | Cover plate with labelling field for data connection housing 2 gang black - Busch-art linear | 1803-02-45M | 1 | piece |
| 2CKA001710A4231 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44G-500 | 1 | piece |
| 2CKA001710A4232 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44M-500 | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|-------------------|-----|-----------------|
| 2CKA001710A4234 | Cover plate with labelling field for data connection housing 2 gang black - Busch-art linear | 1803-02-45M-500 | 1 | piece |
| 2CKA001724A4444 | Cover plate Pilot devices 1 gang white - Busch-art linear | 2533-44G | 1 | piece |
| 2CKA001724A4445 | Cover plate Pilot devices 1 gang white - Busch-art linear | 2533-44M | 1 | piece |
| 2CKA001724A4447 | Cover plate Pilot devices 1 gang black - Busch-art linear | 2533-45M | 1 | piece |
| 2CKA001724A4455 | Cover plate with labelling field for data connection housing white - Busch-art linear | 1758-44G | 1 | piece |
| 2CKA001724A4456 | Cover plate with labelling field for data connection housing white - Busch-art linear | 1758-44M | 1 | piece |
| 2CKA001724A4458 | Cover plate with labelling field for data connection housing black - Busch-art linear | 1758-45M | 1 | piece |
| 2CKA001753A9922 | Cover plate Keystone 1 gang white - Busch-art linear | 2561-44G | 1 | piece |
| 2CKA001753A9923 | Cover plate Keystone 1 gang white - Busch-art linear | 2561-44M | 1 | piece |
| 2CKA001753A9925 | Cover plate Keystone 1 gang black - Busch-art linear | 2561-45M | 1 | piece |
| 2CKA001710A4235 | Cover plate with labelling field Keystone 2 gang white - Busch-art linear | 1800-44G | 1 | piece |
| 2CKA001710A4236 | Cover plate with labelling field Keystone 2 gang white - Busch-art linear | 1800-44M | 1 | piece |
| 2CKA001710A4238 | Cover plate with labelling field Keystone 2 gang black - Busch-art linear | 1800-45M | 1 | piece |
| 2CKA001753A9926 | Cover plate Keystone 2 gang white - Busch-art linear | 2561-02-44G | 1 | piece |
| 2CKA001753A9927 | Cover plate Keystone 2 gang white - Busch-art linear | 2561-02-44M | 1 | piece |
| 2CKA001753A9929 | Cover plate Keystone 2 gang black - Busch-art linear | 2561-02-45M | 1 | piece |
| 2CKA001724A4448 | Cover plate XLR 1 gang white - Busch-art linear | 2553-44G | 1 | piece |
| 2CKA001724A4449 | Cover plate XLR 1 gang white - Busch-art linear | 2553-44M | 1 | piece |
| 2CKA001724A4451 | Cover plate XLR 1 gang black - Busch-art linear | 2553-45M | 1 | piece |
| 2CKA001582A0441 | Handicapped toilet signal set Busch-Infoline® studio white - Busch-art linear | 1510 UC-44G-101 | 1 | piece |
| 2CKA001582A0453 | Handicapped toilet signal set Busch-Infoline® with storage battery buffering studio white - Busch-art linear | 1510 UJ-44G | 1 | piece |
| 2CKA001582A0443 | Cover plate Busch-Infoline® Alarm studio white - Busch-art linear | 1573 CN-44G | 1 | piece |
| 2CKA001582A0445 | Cover plate with labelling field Busch-Infoline® Push button 1 gang studio white - Busch-art linear | 1571 CN-44G | 1 | piece |
| 2CKA001582A0447 | Cover plate with labelling field Busch-Infoline® Push button / Clear 1 gang studio white - Busch-art linear | 1572 CN-44G | 1 | piece |
| 2CKA001582A0449 | Cover plate with labelling field Busch-Infoline® studio white - Busch-art linear | 1575 CN-44G | 1 | piece |
| 2CKA001582A0451 | Cover plate Busch-Infoline® studio white - Busch-art linear | 1576 CN-44G | 1 | piece |
| 2CKA001582A0454 | Cover plate Busch-Infoline® telephone connector boxes (VDo) white - Busch-art linear | 1745-44G | 1 | piece |
| 2CKA001753A0244 | Insert Busch-Infolicht® LED / White studio white - Busch-art linear | 1756 U-44G | 1 | piece |
| 2CKA001753A0245 | Insert Busch-Infolicht® LED / White studio white matt - Busch-art linear | 1756 U-44M | 1 | piece |
| 2CKA001753A0247 | Insert Busch-Infolicht® LED / White black matt - Busch-art linear | 1756 U-45M | 1 | piece |
| 2CKA006115A0509 | Control element 70 | KK/U4.70.11 | 1 | piece |
| 2CKA006115A0510 | Keypad white - Trevion | KK/U4.70.1 | 1 | piece |
| 2TMA310010B000 | SD/U12.70.11-4015,RoomTouch 2.4,12 gang glass black - Busch-art linear | SD/U12.70.11-4015 | 1 | piece |
| 2TMA310011B0004 | RoomTouch 2.4 2.4 in "glass black - Trevion | SD/U12.70.1-4015 | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|---|--------------------|-----|-----------------|
| 2CKA006199A0518 | Cover plate None white - Busch-art linear | LFW/A.0.70.11-CKL | 1 | piece |
| 2CKA006199A0519 | Cover plate None studio white - Trevion | LFW/A.0.70.1-CKL | 1 | piece |
| 2CKA006199A0024 | Cover plate None studio white - Busch-art linear | LFW/A.0.70.11-CK | 1 | piece |
| 2CKA006199A0025 | Cover plate None studio white - Trevion | LFW/A.0.70.1-CK | 1 | piece |
| 2CKA006199A0026 | Cover plate studio white - Busch-art linear | LFW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0027 | Cover plate studio white - Busch-art linear | LFW/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0028 | Cover plate studio white - Busch-art linear | LFW/A.3.70.11-44G | 1 | piece |
| 2CKA006199A0029 | Cover plate studio white - Busch-art linear | LFW/A.4.70.11-44G | 1 | piece |
| 2CKA006199A0030 | Cover plate Symbol "light" studio white - Busch-art linear | LFB/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0031 | Cover plate Symbol "venetian blind" studio white - Busch-art linear | LFJ/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0032 | Cover plate Symbol "scene" studio white - Busch-art linear | LFS/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0378 | Cover plate Symbol "dimming" studio white - Busch-art linear | LFDW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0379 | Cover plate Symbol "venetian blind" studio white - Busch-art linear | LFJW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0380 | Cover plate Symbol "arrows" studio white - Busch-art linear | LFAW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0381 | Cover plate Symbol "light" studio white - Busch-art linear | LFBT/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0382 | Cover plate Symbol "venetian blind" studio white - Busch-art linear | LFJT/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0383 | Cover plate Symbol "scene" studio white - Busch-art linear | LFST/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0384 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white - Busch-art linear | LFDW/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0385 | Cover plate Symbol "arrows" studio white - Busch-art linear | LFAW/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0386 | Cover plate Symbols "music control" studio white - Busch-art linear | LFMW/A.4.70.11-44G | 1 | piece |
| 2CKA006199A0387 | Cover plate studio white matt - Busch-art linear | LFW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0388 | Cover plate studio white matt - Busch-art linear | LFW/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0389 | Cover plate studio white matt - Busch-art linear | LFW/A.3.70.11-44M | 1 | piece |
| 2CKA006199A0390 | Cover plate studio white matt - Busch-art linear | LFW/A.4.70.11-44M | 1 | piece |
| 2CKA006199A0391 | Cover plate Symbol "light" studio white matt - Busch-art linear | LFB/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0392 | Cover plate Symbol "venetian blind" studio white matt - Busch-art linear | LFJ/A.1.70.11-44M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|--------------------|-----|-----------------|
| 2CKA006199A0393 | Cover plate Symbol "scene" studio white matt - Busch-art linear | LFS/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0394 | Cover plate Symbol "dimming" studio white matt - Busch-art linear | LFDW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0395 | Cover plate Symbol "venetian blind" studio white matt - Busch-art linear | LFJW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0396 | Cover plate Symbol "arrows" studio white matt - Busch-art linear | LFAW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0397 | Cover plate Symbol "light" studio white matt - Busch-art linear | LFBT/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0398 | Cover plate Symbol "venetian blind" studio white matt - Busch-art linear | LFJT/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0399 | Cover plate Symbol "scene" studio white matt - Busch-art linear | LFST/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0400 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white matt - Busch-art linear | LFDW/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0401 | Cover plate Symbol "arrows" studio white matt - Busch-art linear | LFAW/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0402 | Cover plate Symbols "music control" studio white matt - Busch-art linear | LFMW/A.4.70.11-44M | 1 | piece |
| 2CKA006199A0419 | Cover plate black matt - Busch-art linear | LFW/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0420 | Cover plate black matt - Busch-art linear | LFW/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0421 | Cover plate black matt - Busch-art linear | LFW/A.3.70.11-45M | 1 | piece |
| 2CKA006199A0422 | Cover plate black matt - Busch-art linear | LFW/A.4.70.11-45M | 1 | piece |
| 2CKA006199A0423 | Cover plate Symbol "light" black matt - Busch-art linear | LFB/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0424 | Cover plate Symbol "venetian blind" black matt - Busch-art linear | LFJ/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0425 | Cover plate Symbol "scene" black matt - Busch-art linear | LFS/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0426 | Cover plate Symbol "dimming" black matt - Busch-art linear | LFDW/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0427 | Cover plate Symbol "venetian blind" black matt - Busch-art linear | LFJW/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0428 | Cover plate Symbol "arrows" black matt - Busch-art linear | LFAW/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0429 | Cover plate Symbol "light" black matt - Busch-art linear | LFBT/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0430 | Cover plate Symbol "venetian blind" black matt - Busch-art linear | LFJT/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0431 | Cover plate Symbol "scene" black matt - Busch-art linear | LFST/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0432 | Cover plate Symbol "arrows/venetian blind" and "dimmer" black matt - Busch-art linear | LFDW/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0433 | Cover plate Symbol "arrows" black matt - Busch-art linear | LFAW/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0434 | Cover plate Symbols "music control" black matt - Busch-art linear | LFMW/A.4.70.11-45M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|--|-------------------|-----|-----------------|
| 2CKA006199A0435 | Cover plate studio white - Trevion | LFW/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0436 | Cover plate studio white - Trevion | LFW/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0437 | Cover plate studio white - Trevion | LFW/A.3.70.1-44G | 1 | piece |
| 2CKA006199A0438 | Cover plate studio white - Trevion | LFW/A.4.70.1-44G | 1 | piece |
| 2CKA006199A0439 | Cover plate Symbol "light" studio white - Trevion | LFB/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0440 | Cover plate Symbol "venetian blind" studio white - Trevion | LFJ/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0441 | Cover plate Symbol "scene" studio white - Trevion | LFS/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0442 | Cover plate Symbol "dimming" studio white - Trevion | LFDW/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0443 | Cover plate Symbol "venetian blind" studio white - Trevion | LFJW/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0444 | Cover plate Symbol "arrows" studio white - Trevion | LFAW/A.1.70.1-44G | 1 | piece |
| 2CKA006199A0445 | Cover plate Symbol "light" studio white - Trevion | LFBT/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0446 | Cover plate Symbol "venetian blind" studio white - Trevion | LFJT/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0447 | Cover plate Symbol "scene" studio white - Trevion | LFST/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0448 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white - Trevion | LFDW/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0449 | Cover plate Symbol "arrows" studio white - Trevion | LFAW/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0450 | Cover plate Symbols "music control" studio white - Trevion | LFMW/A.4.70.1-44G | 1 | piece |
| 2CKA006199A0451 | Cover plate studio white matt - Trevion | LFW/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0452 | Cover plate studio white matt - Trevion | LFW/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0453 | Cover plate studio white matt - Trevion | LFW/A.3.70.1-44M | 1 | piece |
| 2CKA006199A0454 | Cover plate studio white matt - Trevion | LFW/A.4.70.1-44M | 1 | piece |
| 2CKA006199A0455 | Cover plate Symbol "light" studio white matt - Trevion | LFB/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0456 | Cover plate Symbol "venetian blind" studio white matt - Trevion | LFJ/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0457 | Cover plate Symbol "scene" studio white matt - Trevion | LFS/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0458 | Cover plate Symbol "dimming" studio white matt - Trevion | LFDW/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0459 | Cover plate Symbol "venetian blind" studio white matt - Trevion | LFJW/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0460 | Cover plate Symbol "arrows" studio white matt - Trevion | LFAW/A.1.70.1-44M | 1 | piece |

| Identifier | Description | Type | Qty | Unit Of Measure |
|-----------------|---|-------------------|-----|-----------------|
| 2CKA006199A0461 | Cover plate Symbol "light" studio white matt - Trevion | LFBT/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0462 | Cover plate Symbol "venetian blind" studio white matt - Trevion | LFJT/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0463 | Cover plate Symbol "scene" studio white matt - Trevion | LFST/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0464 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white matt - Trevion | LFDW/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0465 | Cover plate Symbol "arrows" studio white matt - Trevion | LFAW/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0466 | Cover plate Symbols "music control" studio white matt - Trevion | LFMW/A.4.70.1-44M | 1 | piece |
| 2CKA006199A0483 | Cover plate black matt - Trevion | LFW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0484 | Cover plate black matt - Trevion | LFW/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0485 | Cover plate black matt - Trevion | LFW/A.3.70.1-45M | 1 | piece |
| 2CKA006199A0486 | Cover plate black matt - Trevion | LFW/A.4.70.1-45M | 1 | piece |
| 2CKA006199A0487 | Cover plate Symbol "light" black matt - Trevion | LFB/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0488 | Cover plate Symbol "venetian blind" black matt - Trevion | LFJ/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0489 | Cover plate Symbol "scene" black matt - Trevion | LFS/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0490 | Cover plate Symbol "dimming" black matt - Trevion | LFDW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0491 | Cover plate Symbol "venetian blind" black matt - Trevion | LFJW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0492 | Cover plate Symbol "arrows" black matt - Trevion | LFAW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0493 | Cover plate Symbol "light" black matt - Trevion | LFBT/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0494 | Cover plate Symbol "venetian blind" black matt - Trevion | LFJT/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0495 | Cover plate Symbol "scene" black matt - Trevion | LFST/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0496 | Cover plate Symbol "arrows/venetian blind" and "dimmer" black matt - Trevion | LFDW/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0497 | Cover plate Symbol "arrows" black matt - Trevion | LFAW/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0498 | Cover plate Symbols "music control" black matt - Trevion | LFMW/A.4.70.1-45M | 1 | piece |

Categories

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > free@home > User Operation > Frames

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > KNX > User Operation > Frames

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Frames

