



PRODUCT-DETAILS

2513-212K-102-500

Cover frame 3-gang white - Busch-Duro 2000
SI Linear



General Information	
Extended Product Type:	2513-212K-102-500
Product ID:	2CKA001725A1551
EAN:	4011395174029
Catalog Description:	Cover frame 3-gang white - Busch-Duro 2000 SI Linear
Long Description:	With small corner radii for trunking systems.
Display Name:	2513-212K-102-500

Installation	
Instructions and Manuals:	No document needed
Mounting Type:	Flush Mounted
Type of Fastening:	Clamp
Mounting Orientation:	Horizontal Vertical
Modular Components Included:	Cover Frame

Environmental

Degree of Protection:	IP20
-----------------------	------

Technical

Data Sheet, Technical Information:	No document needed
------------------------------------	--------------------

Options Available:	"basic"
--------------------	---------

Design

Design Range:	Busch-Duro 2000 SI
---------------	--------------------

Design Range Variant:	Busch-Duro 2000 SI Linear
-----------------------	---------------------------

Surface Finishing:	Untreated Glossy
--------------------	---------------------

Material:	Thermoplastic
-----------	---------------

Label Space Provided:	Without Label Space
-----------------------	---------------------

RAL Number:	Similar to RAL 1013
-------------	---------------------

Color:	white
--------	-------

Number of Gangs:	3-gang
------------------	--------

Number of Modules:	Horizontal 3 Vertical 3
--------------------	----------------------------

Dimensions

Product Net Width:	81 mm
--------------------	-------

Product Net Height:	223 mm
---------------------	--------

Product Net Depth / Length:	11 mm
-----------------------------	-------

Product Net Weight:	56 g
---------------------	------

Dimension Diagram:	2CKA000097E0576
--------------------	-----------------

Material Compliance

RoHS Declaration:	2CKA200000E1513
-------------------	-----------------

RoHS Information:	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
-------------------	--

REACH Declaration:	2CKA309999E9999
--------------------	-----------------

REACH Information:	False - does not contain substances > 0.1 mass percentage
--------------------	---

REACH Date:	20260216
-------------	----------

Conflict Minerals Reporting Template (CMRT):	9AKK108468A3363
--	-----------------

WEEE Category:	Product Not in WEEE Scope
----------------	---------------------------

Certificates and Declarations

Declaration of Conformity - CE: No declaration needed

EU Data Act Applicability and Compliance: Not Applicable

External Classifications and Standards

ETIM 9: EC000007 - Cover frame for domestic switching devices

ETIM 10: EC000007 - Cover frame for domestic switching devices

eClass: V11.0 : 27144001

Accessories

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001582A0360	Cover plate Busch-Infoline® white - Busch-Duro 2000 SI	1576 C-212	1	piece
2CKA001710A3682	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button white - Busch-Duro 2000 SI	1794 TA-212	1	piece
2CKA001710A3996	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button white - Busch-Duro 2000 SI	1795 HK-212	1	piece
2CKA001710A4028	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button white - Busch-Duro 2000 SI	1795 HKEA-212	1	piece
2CKA001710A3709	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button white - Busch-Duro 2000 SI	1795 TA-212	1	piece
2CKA002013A5313	SCHUKO® Socket insert with legend EDV Safety Shutter white - Busch-Duro 2000 SI	20 EUC/DVKS-212	1	piece
2CKA002011A3788	Socket Outlets white - Busch-Duro 2000 SI	20 EUC-212-507	1	piece
2CKA002013A5466	SCHUKO® socket insert Safety Shutter with LED Control light /Green green - Reflex SI	20 EUCBL-13-212-101	1	piece
2CKA002013A5283	SCHUKO® socket insert Safety Shutter with LED Control light /Green orange - Reflex SI	20 EUCBL-14-212	1	piece
2CKA002013A5280	SCHUKO® socket insert Safety Shutter with LED Control light /Green white - Busch-Duro 2000 SI	20 EUCBL-212	1	piece
2CKA002013A5290	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White white - Busch-Duro 2000 SI	20 EUCBLI-212	1	piece
2CKA002013A5468	SCHUKO® socket insert Safety Shutter green - Reflex SI	20 EUCKS-13-212-101	1	piece
2CKA002013A5310	SCHUKO® socket insert Safety Shutter orange - Reflex SI	20 EUCKS-14-212	1	piece
2CKA002013A5317	SCHUKO® Socket insert with legend ZSV Safety Shutter orange - Reflex SI	20 EUCKS-14-212-10	1	piece
2CKA002013A5471	SCHUKO® socket insert Safety Shutter with Hinged Lid green - Reflex SI	20 EUKB-13-212-101	1	piece
2CKA002013A5308	SCHUKO® socket insert Safety Shutter with Hinged Lid orange - Reflex SI	20 EUKB-14-212	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002013A5306	SCHUKO® socket insert Safety Shutter with Hinged Lid white - Busch-Duro 2000 SI	20 EUKB-212	1	piece
2CKA002013A5311	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space white - Busch-Duro 2000 SI	20 EUKNB-212	1	piece
2CKA002013A5312	SCHUKO® socket insert Safety Shutter without claw white - Busch-Duro 2000 SI	20 EURKS-212	1	piece
2CKA002013A5469	SCHUKO® Socket insert with legend SV Safety Shutter green - Reflex SI	20EUCKS-13-212-102	1	piece
2CKA002013A5315	Busch-Protector® SCHUKO® socket insert Safety Shutter with Neon lamp /Red with screw terminals white - Busch-Duro 2000 SI	2310 EUGL/VAB-212	1	piece
2CKA002011A3816	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals white - Busch-Duro 2000 SI	2310EUGL/V A-212-11	1	piece
2CKA002099A0207	Socket Outlets Safety Shutter white - Busch-Duro 2000 SI	2399 UCKS-212	1	piece
2CKA001731A3992	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker white - Busch-Duro 2000 SI	2505 K-212	1	piece
2CKA001731A1890	Mechanical Controls for Switch/push button, Two-part rocker white - Busch-Duro 2000 SI	2505-212-507	1	piece
2CKA001731A1889	Mechanical Controls for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2506-212-507	1	piece
2CKA001724A0194	Cover plate SAT 2 gang white - Busch-Duro 2000 SI	2531-212	1	piece
2CKA001724A4328	Data / Telecommunication / Antenna SAT 2 gang white - Busch-Duro 2000 SI	2531-212-500	1	piece
2CKA001724A2865	Data / Telecommunication / Antenna SAT 2 gang white - Busch-Duro 2000 SI	2531-212-507	1	piece
2CKA001731A1919	Cover Busch-Infolicht® white - Busch-Duro 2000 SI	2562-212	1	piece
2CKA003116A0659	FI-SCHUKOMAT SCHUKO® socket insert 2P+PE 16 A 30 mA white - Busch-Duro 2000 SI	3120 EUCB-212	1	piece
2CKA003117A0003	Buschmat RCD - Insert RCD 16 A 30 mA white - Busch-Duro 2000 SI	3151 UC-212	1	piece
2CKA006115A0455	Cover plate Symbols "up, down, menu left, menu right, " 1-gang for Control element 6gang white - Busch-Duro 2000 SI	6108/61-212	1	piece
2CKA006115A0474	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang white - Busch-Duro 2000 SI	6108/61-212-500	1	piece
2CKA006155A0032	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-Duro 2000 SI	6109/03-212	1	piece
2CKA006155A0051	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-Duro 2000 SI	6109/03-212-500	1	piece
2CKA006132A0357	Busch-Watchdog Motion detector Twisted Pair Wiring white	6122/10-212	1	piece
2CKA006132A0373	Busch-Watchdog Motion detector Twisted Pair Wiring white	6122/10-212-500	1	piece
2CKA006220A0115	Motion detector 1gang Movement sensor 1 channel Twisted Pair Wiring white - Busch-Duro 2000 SI	6215/1.1-212	1	piece
2CKA006200A0057	WL-Mov. detector/act. 1g	6215/1.1-212-WL	1	piece
2CKA006220A0113	Motion detector Movement sensor 1 channel Twisted Pair Wiring white - Busch-Duro 2000 SI	6225/1.0-212	1	piece
2CKA006220A0077	Rocker with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	6230-10-212	1	piece
2CKA006220A0087	Rocker with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6230-20-212	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0079	Rocker Symbol "light" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	6231-10-212	1	piece
2CKA006220A0089	Rocker Symbol "light" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6231-21-212	1	piece
2CKA006220A0097	Rocker Symbol "light" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6231-22-212	1	piece
2CKA006220A0081	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	6232-10-212	1	piece
2CKA006220A0091	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6232-20-212	1	piece
2CKA006220A0083	Rocker Symbol "scene" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	6233-10-212	1	piece
2CKA006220A0093	Rocker Symbol "scene" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6233-21-212	1	piece
2CKA006220A0101	Rocker Symbol "scene" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6233-22-212	1	piece
2CKA006220A0085	Rocker Symbol "dimming" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	6234-10-212	1	piece
2CKA006220A0095	Rocker Symbol "dimming" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6234-21-212	1	piece
2CKA006220A0256	Rocker Symbol "dimming" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6234-22-212	1	piece
2CKA006220A0105	Cover plate Symbols "up, down, ECO, Power" 2gang white - Busch-Duro 2000 SI	6235-212	1	piece
2CKA006220A0251	Cover plate Symbols "up, down, ECO, menu" 2gang white - Busch-Duro 2000 SI	6236-212	1	piece
2CKA006220A0741	Rocker Symbols "music control" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6237-21-212	1	piece
2CKA006220A0742	Rocker Symbols "music control" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	6237-22-212	1	piece
2CKA006430A0313	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single push button white - Busch-Duro 2000 SI	6430-212-102	1	piece
2CKA006430A0285	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate white - Busch-Duro 2000 SI	6435-212	1	piece
2CKA006470A0001	Cover plate for Proximity switch white - Busch-Duro 2000 SI	6476-212	1	piece
2CKA006400A0048	Cover plate PowerDock 1 gang white - Busch-Duro 2000 SI	6477-212	1	piece
2CKA006599A2888	Control Element for Dimmer Two-part button with Neon lamp white - Busch-Duro 2000 SI	6545-212	1	piece
2CKA006730A0044	WaveLine Wall sensor 1-gang 1 channel Wireless white - Busch-Duro 2000 SI	6731-212	1	piece
2CKA006730A0028	WaveLine Wall sensor 1 channel Wireless white - Busch-Duro 2000 SI	6731-212-500	1	piece
2CKA006730A0045	WaveLine Wall sensor 2-gang Wireless white - Busch-Duro 2000 SI	6732-212	1	piece
2CKA006730A0029	WaveLine Wall sensor 2 channel Wireless white - Busch-Duro 2000 SI	6732-212-500	1	piece
2CKA008200A0076	Cover plate Loudspeaker white - Busch-Duro 2000 SI	8253-212	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA008300A0228	Welcome, white	83260-212-515	1	piece
2CKA006220A0245	Cover plate Symbols "up, down, ECO, menu" 1gang white - Busch-Duro 2000 SI	CP-FCC-212	1	piece
2CKA006220A0210	Cover plate Symbols "up, down, ECO, Power" 1gang white - Busch-Duro 2000 SI	CP-RTC-212	1	piece
2CKA006220A0218	Motion Detectors Movement sensor Twisted Pair Wiring white - Busch-Duro 2000 SI	MD-F-1.0.1-212	1	piece
2CKA006220A0220	Motion Detectors 1gang Movement sensor 1 channel Twisted Pair Wiring white - Busch-Duro 2000 SI	MSA-F-1.1.1-212	1	piece
2CKA006200A0092	WL-Mov. detector/act. 1g	MSA-F-1.1.1-212-WL	1	piece
2CKA006220A0182	Rocker with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	SR-1-212	1	piece
2CKA006220A0192	Rocker with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SR-2-212	1	piece
2CKA006220A0186	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	SRB-1-212	1	piece
2CKA006220A0196	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRB-2-212	1	piece
2CKA006220A0190	Rocker Symbol "dimming" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	SRD-1-212	1	piece
2CKA006220A0200	Rocker Symbol "dimming" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRD-2-L-212	1	piece
2CKA006220A0261	Rocker Symbol "dimming" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRD-2-R-212	1	piece
2CKA006220A0184	Rocker Symbol "light" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	SRL-1-212	1	piece
2CKA006220A0194	Rocker Symbol "light" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRL-2-L-212	1	piece
2CKA006220A0202	Rocker Symbol "light" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRL-2-R-212	1	piece
2CKA006220A0188	Rocker Symbol "scene" with Small Transparent Calotte 1gang white - Busch-Duro 2000 SI	SRS-1-212	1	piece
2CKA006220A0198	Rocker Symbol "scene" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRS-2-L-212	1	piece
2CKA006220A0206	Rocker Symbol "scene" with Small Transparent Calotte 2gang white - Busch-Duro 2000 SI	SRS-2-R-212	1	piece

Categories

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > free@home > User Operation > Frames

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > KNX > User Operation > Frames

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Frames

