



PRODUCT-DETAILS

1721-184-500

Cover frame 1-gang studio white - future



General Information	
Extended Product Type:	1721-184-500
Product ID:	2CKA001754A4504
EAN:	4011395174586
Catalog Description:	Cover frame 1-gang studio white - future
Long Description:	ABB cover frame, White - Future series. Provides an elegant finish for ABB flush-mounted wall installations, compatible with the full ABB switch and socket range.
Display Name:	1721-184-500

Installation	
Instructions and Manuals:	No document needed
Mounting Type:	Flush Mounted
Type of Fastening:	Clamp
Mounting Orientation:	Horizontal Vertical
Modular Components Included:	Cover Frame

Environmental

Degree of Protection: IP20

Technical

Data Sheet, Technical Information: No document needed

Options Available: "basic"

Design

Design Range: future linear
Platform 63

Design Range Variant: future

Surface Finishing: Glossy
Untreated

Material: Plastic
Thermoplastic

Label Space Provided: Without Label Space

RAL Number: Similar to RAL 9016

Color: studio white

Number of Gangs: 1-gang

Number of Modules: Horizontal 1
Vertical 1

Dimensions

Product Net Width: 80 mm

Product Net Height: 80 mm

Product Net Depth / Length: 11 mm

Product Net Weight: 17.5 g

Dimension Diagram: 2CKA000097E4147

Material Compliance

RoHS Declaration: 2CKA200000E2831

RoHS Information: Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019

REACH Declaration: 2CKA309999E9999

REACH Information: False - does not contain substances > 0.1 mass percentage

REACH Date: 20260216

Conflict Minerals Reporting Template (CMRT): 9AKK108468A3363

WEEE Category: Product Not in WEEE Scope

Certificates and Declarations

Declaration of Conformity - CE: No declaration needed

EU Data Act Applicability and Compliance: Not Applicable

External Classifications and Standards

ETIM 9: EC000007 - Cover frame for domestic switching devices

ETIM 10: EC000007 - Cover frame for domestic switching devices

eClass: V11.0 : 27144001

Accessories

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A2749	Rocker switch for Switch/push button, Single rocker studio white - Platform 63	1786-84	1	piece
2CKA001751A3074	Control Elements for Switch/push button, Single rocker studio white - Platform 63	1786-84-500	1	piece
2CKA001751A3145	Rocker for Switch/push button, Single rocker red - Platform 63	1786-12-82	1	piece
2CKA001751A2926	Rocker for Switch/push button, Single rocker anthracite - Platform 63	1786-81	1	piece
2CKA001751A3079	Mechanical Controls for Switch/push button, Single rocker anthracite - Platform 63	1786-81-500	1	piece
2CKA001751A2943	Rocker for Switch/push button, Single rocker aluminium silver - Platform 63	1786-83	1	piece
2CKA001751A3075	Control Elements for Switch/push button, Single rocker aluminium silver - Platform 63	1786-83-500	1	piece
2CKA001751A3027	Rocker for Switch/push button, Single rocker studio white matt - Platform 63	1786-884	1	piece
2CKA001751A3089	Control Elements for Switch/push button, Single rocker studio white matt - Platform 63	1786-884-500	1	piece
2CKA001751A3041	Rocker switch for Switch/push button, Single rocker black matt - Platform 63	1786-885	1	piece
2CKA001751A3094	Control Elements for Switch/push button, Single rocker black matt - Platform 63	1786-885-500	1	piece
2CKA001751A2752	Rocker for Switch/push button, Two-part rocker studio white - Platform 63	1785-84	1	piece
2CKA001751A3076	Control Elements for Switch/push button, Two-part rocker studio white - Platform 63	1785-84-500	1	piece
2CKA001751A2930	Rocker for Switch/push button, Two-part rocker anthracite - Platform 63	1785-81	1	piece
2CKA001751A2942	Rocker for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785-83	1	piece
2CKA001751A3092	Control Elements for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785-83-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3024	Rocker for Switch/push button, Two-part rocker studio white matt - Platform 63	1785-884	1	piece
2CKA001751A3038	Rocker for Switch/push button, Two-part rocker black matt - Platform 63	1785-885	1	piece
2CKA002011A3725	SCHUKO® socket insert studio white - Platform 63	20 EUC-84	1	piece
2CKA002099A0307	SCHUKO® socket insert studio white - Platform 63	20 EUC-84 BULK	1	piece
2CKA002011A6207	Socket Outlets studio white - Platform 63	20 EUC-84-500	1	piece
2CKA002011A6260	SCHUKO® Socket insert with legend SV green - Platform 63	20 EUC-13-82-101	1	piece
2CKA002011A3723	SCHUKO® Socket insert with legend ZSV orange - Platform 63	20 EUC-14-82	1	piece
2CKA002011A3801	SCHUKO® socket insert anthracite - Platform 63	20 EUC-81	1	piece
2CKA002011A6215	Socket Outlets anthracite - Platform 63	20 EUC-81-500	1	piece
2CKA002011A3721	SCHUKO® socket insert ivory white - Platform 63	20 EUC-82	1	piece
2CKA002011A6214	Socket Outlets ivory white - Platform 63	20 EUC-82-500	1	piece
2CKA002011A3798	SCHUKO® socket insert aluminium silver - Platform 63	20 EUC-83	1	piece
2CKA002011A6213	Socket Outlets aluminium silver - Platform 63	20 EUC-83-500	1	piece
2CKA002011A3879	SCHUKO® socket insert studio white matt - Platform 63	20 EUC-884	1	piece
2CKA002011A6208	Socket Outlets studio white matt - Platform 63	20 EUC-884-500	1	piece
2CKA002011A3883	SCHUKO® socket insert black matt - Platform 63	20 EUC-885	1	piece
2CKA002011A6211	Socket Outlets black matt - Platform 63	20 EUC-885-500	1	piece
2CKA002011A3875	SCHUKO® socket insert grey metallic - Platform 63	20 EUC-803	1	piece
2CKA002011A6216	Socket Outlets grey metallic - Platform 63	20 EUC-803-500	1	piece
2CKA002013A5245	SCHUKO® socket insert Safety Shutter studio white - Platform 63	20 EUCKS-84	1	piece
2CKA002013A5372	Socket insert Safety Shutter studio white - Platform 63	20 EUCKS-84-500	1	piece
2CKA002013A5472	SCHUKO® Socket insert with legend SV Safety Shutter green - Platform 63	20 EUCB-13-82-102	1	piece
2CKA002013A5413	SCHUKO® Socket insert with legend ZSV Safety Shutter orange - Platform 63	20 EUCB-14-82-10	1	piece
2CKA002013A5464	SCHUKO® socket insert Safety Shutter red - Platform 63	20 EUCKS-12-82-101	1	piece
2CKA002013A5470	SCHUKO® socket insert Safety Shutter green - Platform 63	20 EUCKS-13-82-101	1	piece
2CKA002013A5324	SCHUKO® socket insert Safety Shutter orange - Platform 63	20 EUCKS-14-82	1	piece
2CKA002013A5265	SCHUKO® socket insert Safety Shutter anthracite - Platform 63	20 EUCKS-81	1	piece
2CKA002013A5244	SCHUKO® socket insert Safety Shutter ivory white - Platform 63	20 EUCKS-82	1	piece
2CKA002013A5376	Socket Outlets Safety Shutter ivory white - Platform 63	20 EUCKS-82-500	1	piece
2CKA002013A5272	SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	20 EUCKS-83	1	piece
2CKA002013A5375	Socket Outlets Safety Shutter aluminium silver - Platform 63	20 EUCKS-83-500	1	piece
2CKA002013A5328	SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	20 EUCKS-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002013A5373	Socket insert Safety Shutter studio white matt - Platform 63	20 EUCKS-884-500	1	piece
2CKA002013A5333	SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUCKS-885	1	piece
2CKA002013A5297	SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	20 EUCKS-803	1	piece
2CKA001032A0523	Room Temperature Controller set studio white - future linear	1098 UJ-84	1	piece
2CKA001582A0424	Handicapped toilet signal set Busch-Infoline® LED / Red studio white - Platform 63	1510 UC-84-101	1	piece
2CKA001582A0425	Handicapped toilet signal set Busch-Infoline® LED / Red studio white - Platform 63	1510 UC-84-503-101	1	piece
2TKA00004631	Handicapped toilet signal set Busch-Infoline® with storage battery buffering LED / Red studio white - Platform 63	1510 UJ-84	1	piece
2CKA001582A0346	Cover plate with labelling field Busch-Infoline® Push button 1 gang studio white - Platform 63	1571 CN-84	1	piece
2CKA001582A0348	Cover plate with labelling field Busch-Infoline® Push button / Clear 1 gang studio white - Platform 63	1572 CN-84	1	piece
2CKA001582A0350	Cover plate with labelling field Busch-Infoline® Alarm studio white - Platform 63	1573 CN-84	1	piece
2CKA001582A0353	Cover plate with labelling field Busch-Infoline® studio white - Platform 63	1575 CN-84	1	piece
2CKA001582A0355	Cover plate with labelling field Busch-Infoline® studio white - Platform 63	1576 CN-84	1	piece
2CKA001731A1923	Cover Busch-Infolicht® studio white - Platform 63	1716-84	1	piece
2CKA001731A1916	Rocker open for red pull button calotte, Pull cord studio white - Platform 63	1720-84	1	piece
2CKA001710A3808	Cover plate with legend Loudspeaker Turn button studio white - Platform 63	1740 DR/03-84	1	piece
2CKA001710A3512	Cover plate Symbol "2-1-3" for Level switch, Turn button studio white - Platform 63	1740 DRL-84-503	1	piece
2CKA001710A3172	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white - Platform 63	1740-84	1	piece
2CKA001710A3161	Cover plate for Blind cap 1-gang with Mounting plate studio white - Platform 63	1742-84	1	piece
2CKA001710A3991	Cable Outlet / Blank Plate / Adapter Ring for Blind cap 1-gang with Mounting plate studio white - Platform 63	1742-84-500	1	piece
2CKA001724A4368	Cover plate SAT 4 gang studio white - Platform 63	1743/10-04-84	1	piece
2CKA001724A4377	Cover plate SAT 4 gang studio white - Platform 63	1743-04-84	1	piece
2CKA001724A2774	Cover plate SAT 3 gang studio white - Platform 63	1743-84	1	piece
2CKA001724A4332	Data / Telecommunication / Antenna SAT 3 gang studio white - Platform 63	1743-84-500	1	piece
2CKA001710A3173	Cover plate Busch-Infoline® telephone connector boxes (VDo) Central cover plate studio white - Platform 63	1745-84	1	piece
2CKA001710A3522	Cover plate 50x50 mm for data connection housing studio white - Platform 63	1746/10-84	1	piece
2CKA001710A3993	Cover plate 50x50 mm for data connection housing 0 gang studio white - Platform 63	1746/10-84-500	1	piece
2CKA001710A3167	Cover plate 50x50 mm with Hinged Lid for data connection housing studio white - Platform 63	1746-84	1	piece
2CKA001710A4096	Intermediate Ring for cover plates Busch-Balance® SI 1-gang studio white - Platform 63	1747 BSI-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3863	Intermediate Ring for Cover plates Busch-Duro 2000® SI and Reflex SI studio white - Platform 63	1747 SI-84	1	piece
2CKA001710A3861	Intermediate Ring studio white - Platform 63	1747-84	1	piece
2CKA001710A3656	Cover plate Data connection 2 gang studio white - Platform 63	1748-84	1	piece
2CKA001710A3163	Cover plate Cable outlet studio white - Platform 63	1749-84	1	piece
2CKA001710A3994	Cable Outlet / Blank Plate / Adapter Ring for Cable outlet 1-gang studio white - Platform 63	1749-84-500	1	piece
2CKA001710A3166	Cover plate BNC/TNC 2 gang studio white - Platform 63	1750-84	1	piece
2CKA001723A0240	Cover plate Loudspeaker 2 gang studio white - Platform 63	1751-84	1	piece
2CKA001710A3175	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white - Platform 63	1755 SL/PZ-84-101	1	piece
2CKA001753A0092	Cover plate studio white - Platform 63	1756-84	1	piece
2CKA001724A2761	Cover plate with labelling field for data connection housing studio white - Platform 63	1758-84	1	piece
2CKA001710A4106	Data / Telecommunication / Antenna TDO 1 gang studio white - Platform 63	1762-84-506	1	piece
2CKA001731A4001	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker studio white - Platform 63	1764 NLI/KI-84	1	piece
2CKA001731A4002	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker studio white - Platform 63	1764 NLI/KI-84-500	1	piece
2CKA001731A1877	Rocker with labelling field for Switch/push button, Single rocker studio white - Platform 63	1764 NLI-84	1	piece
2CKA001710A3162	Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang studio white - Platform 63	1766-84	1	piece
2CKA001710A3992	Multimedia Devices DSub15Pole 1 gang studio white - Platform 63	1766-84-500	1	piece
2CKA001753A0258	Cover plate with legend 0 ... 15 Min for Time switch, Turning handle studio white - Platform 63	1770-84-103	1	piece
2CKA001753A0301	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle studio white - Platform 63	1771-84-103	1	piece
2CKA001751A2980	Multimedia Devices studio white	1785 ENO-84	1	piece
2CKA001751A3099	Rocker with legend Symbol "arrows" 4gang for KNX push-button coupling unit Two-part rocker studio white - Platform 63	1785 JA/02-84	1	piece
2CKA001751A2756	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - Platform 63	1785 JA-84	1	piece
2CKA001751A3088	Control Elements Symbol "arrows" for Venetian blind, Two-part rocker studio white - Platform 63	1785 JA-84-500	1	piece
2CKA001751A3127	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker studio white - Platform 63	1785 K-84	1	piece
2CKA001751A3128	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker studio white - Platform 63	1785 K-84-500	1	piece
2CKA001751A3209	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker studio white - Platform 63	1785/11 K-84	1	piece
2CKA001751A2992	Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white - Platform 63	1785/11-84	1	piece
2CKA001751A2968	Multimedia Devices studio white	1786 ENO-84	1	piece
2CKA001751A3098	Rocker with legend Symbol "arrows" for KNX push-button coupling unit Single rocker studio white - Platform 63	1786 JA/02-84	1	piece
2CKA001751A2998	Rocker with legend DND for Switch/push button, Single rocker studio white - Platform 63	1786/11-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A2750	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1788-84	1	piece
2CKA001751A2751	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 H-84	1	piece
2CKA001751A2754	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 KI-84	1	piece
2CKA001751A2753	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 LI-84	1	piece
2CKA001751A3084	Mechanical Controls Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 LI-84-500	1	piece
2CKA001751A3150	Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 N-84	1	piece
2CKA001751A3151	Mechanical Controls with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 N-84-500	1	piece
2CKA001751A3160	Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 ST-84	1	piece
2CKA001751A3161	Mechanical Controls Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 ST-84-500	1	piece
2CKA001751A2755	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 TR-84	1	piece
2CKA001751A2814	Rocker with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1789-84	1	piece
2CKA001751A3091	Mechanical Controls with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1789-84-500	1	piece
2CKA001710A4111	Cover plate studio white - Platform 63	1790-590-84	1	piece
2CKA001710A4112	Cover plate studio white - Platform 63	1790-591-84	1	piece
2CKA001710A4113	Cover plate studio white - Platform 63	1790-592-84	1	piece
2CKA001710A4114	Cover plate studio white - Platform 63	1790-593-84	1	piece
2CKA001710A4115	Cover plate studio white - Platform 63	1790-594-84	1	piece
2CKA001710A4116	Cover plate studio white - Platform 63	1790-595-84	1	piece
2CKA001710A4127	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card studio white - Platform 63	1792 RFID-84	1	piece
2CKA001710A3641	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card studio white - Platform 63	1792-84	1	piece
2CKA006430A0420	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate studio white - Platform 63	1794 MDRT-84	1	piece
2CKA006430A0421	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Thermostat Central cover plate studio white - Platform 63	1794 MDRT-84-500	1	piece
2CKA001710A4201	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1794 R-84	1	piece
2CKA001710A4202	Cover plate Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1794 R-84-500	1	piece
2CKA001710A3698	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1794 TA-84	1	piece
2CKA001710A3544	Cover plate Characters 1 ... 6 for Thermostat studio white - Platform 63	1794-84	1	piece
2CKA001710A4017	Cover plate Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1795 HK-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A4049	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1795 HKEA-84	1	piece
2CKA001710A3725	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1795 TA-84	1	piece
2CKA001710A3569	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Platform 63	1795-84	1	piece
2CKA001753A0311	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord studio white - Platform 63	1796-84	1	piece
2CKA001710A3176	Cover plate with labelling field Keystone 2 gang studio white - Platform 63	1800-84	1	piece
2CKA001710A3990	Data / Telecommunication / Antenna Keystone 2 gang studio white - Platform 63	1800-84-500	1	piece
2CKA001710A3164	Cover plate with labelling field for data connection housing 2 gang studio white - Platform 63	1803-02-84	1	piece
2CKA001710A1551	Data / Telecommunication / Antenna UAE/IAE (ISDN) 2 gang studio white - Platform 63	1803-02-84-500	1	piece
2CKA001710A3165	Cover plate with labelling field for data connection housing 1 gang studio white - Platform 63	1803-84	1	piece
2CKA001710A1550	Data / Telecommunication / Antenna UAE/IAE (ISDN) 1 gang studio white - Platform 63	1803-84-500	1	piece
2CKA002013A5407	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter studio white - Platform 63	20 EUAB-84	1	piece
2CKA002011A6273	SCHUKO® USB socket insert Safety Shutter with USB A/A studio white - Platform 63	20 EUCB2USB-84	1	piece
2CKA002011A6274	Socket insert Safety Shutter with USB A/A studio white - Platform 63	20 EUCB2USB-84-500	1	piece
2CKA002011A6306	SCHUKO® USB socket insert Safety Shutter with USB A/C studio white - Platform 63	20 EUCB2USBAC-84	1	piece
2CKA002011A6307	Socket insert Safety Shutter with USB A/C studio white - Platform 63	20 EUCB2USBAC-84-500	1	piece
2CKA002013A5418	Busch-Service-Socket SCHUKO® socket insert Safety Shutter studio white - Platform 63	20 EUCBDR-84	1	piece
2CKA002013A5286	SCHUKO® socket insert Safety Shutter with LED Control light /Green studio white - Platform 63	20 EUCBL-84	1	piece
2CKA002013A5294	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White studio white - Platform 63	20 EUCBLI-84	1	piece
2CKA002011A6161	Socket insert Safety Shutter with USB A studio white - Platform 63	20 EUCBUSB-84	1	piece
2CKA002011A6179	Socket Outlets Safety Shutter with USB A studio white - Platform 63	20 EUCBUSB-84-500	1	piece
2CKA002013A5268	SCHUKO® Socket insert with legend EDV Safety Shutter studio white - Platform 63	20 EUCKS/DV-84	1	piece
2CKA002013A5430	SCHUKO® Socket insert with labelling field Safety Shutter with label space studio white - Platform 63	20 EUCNB-84	1	piece
2CKA002013A5431	Socket Outlets Safety Shutter with label space studio white - Platform 63	20 EUCNB-84-500	1	piece
2CKA002011A3780	Socket Outlets without claw studio white - Platform 63	20 EUCR-84-503	1	piece
2CKA002013A5440	SCHUKO® socket insert Safety Shutter without claw studio white - Platform 63	20 EUCRB-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002013A5441	Socket Outlets Safety Shutter studio white - Platform 63	20 EUCRB-84-500	1	piece
2CKA002018A1467	SCHUKO® socket insert with Hinged Lid studio white - Platform 63	20 EUK-84	1	piece
2CKA002018A1509	Socket Outlets with Hinged Lid studio white - Platform 63	20 EUK-84-500	1	piece
2CKA002018A1520	SCHUKO® socket insert Safety Shutter with Hinged Lid studio white - Platform 63	20 EUKB-84	1	piece
2CKA002018A1529	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw studio white - Platform 63	20 EUKBR-84	1	piece
2CKA002018A1540	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space studio white - Platform 63	20 EUKNB-84	1	piece
2CKA002018A1551	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space studio white - Platform 63	20 EUKNBL-84	1	piece
2CKA002018A1563	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Different Locking with label space studio white - Platform 63	20 EUKNBSL-84	1	piece
2CKA002018A1564	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space studio white - Platform 63	20 EUKNBSL-84-101	1	piece
2CKA002011A3727	SCHUKO® Socket insert with labelling field with label space studio white - Platform 63	20 EUN-84	1	piece
2CKA002011A6209	Socket Outlets with label space studio white - Platform 63	20 EUN-84-500	1	piece
2CKA002017A1891	Socket Safety Shutter with USB A/A studio white - Platform 63	20 MUCB2USB-84-500	1	piece
2CKA002017A1916	Socket Safety Shutter with USB A/C studio white - Platform 63	20 MUCB2USBAC-84-500	1	piece
2CKA002014A1487	SCHUKO® socket insert studio white - Platform 63	20-2 EUC-84	1	piece
2CKA002014A1466	Socket Outlets studio white - future linear	20-2 EUCJ-184K-503	1	piece
2CKA001751A3170	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO studio white - Platform 63	2029 UC-84	1	piece
2CKA001751A3231	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P studio white - Platform 63	2029/12 UC-84	1	piece
2CKA001751A3220	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker studio white - Platform 63	2058-24-84	1	piece
2CKA001751A3240	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker studio white - Platform 63	2059 UC-84	1	piece
2CKA001510A0005	Cover Busch-iceLight® Reflector Ambient / orientation lightning / White transparent - Platform 63	2068/11-84	1	piece
2CKA001510A0008	Cover Busch-iceLight® Reflector Ambient / orientation lightning, Infolight transparent - Platform 63	2068/14-84	1	piece
2CKA001510A0017	Cover Busch-iceLight® Ambient lightning transparent - Platform 63	2068/22-84	1	piece
2CKA001510A0015	Set Busch-iceLight® Reflector LED Night light / White studio white - future linear	2069/11-84	1	piece
2CKA001761A1495	Cable Entry studio white - future linear	2087-84	1	piece
2CKA001761A1500	Cable Entry studio white - future linear	2088-84	1	piece
2CKA002495A0086	Equipotential socket insert studio white - Platform 63	2095 UC-84	1	piece
2CKA006599A3029	Electronic Controls studio white - future linear	2112UJGL-84-101	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006599A3031	Electronic Controls with LED Orientation light studio white - future linear	2116/11UJGL-84	1	piece
2CKA002190A0215	Socket Outlets with screw terminals studio white - Platform 63	2190 EUC-84	1	piece
2CKA002013A5477	SCHUKO® socket insert Safety Shutter with screw terminals studio white - Platform 63	23 EUCB-84	1	piece
2CKA002013A5451	SCHUKO® socket insert Safety Shutter with screw terminals studio white - Platform 63	2300 EUCB-84	1	piece
2CKA002113A0511	Socket Outlets Safety Shutter with screw terminals studio white - Platform 63	2300 UCRKS-84-503	1	piece
2CKA002011A3833	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals studio white - Platform 63	2310 EUGL/VA-84-11	1	piece
2CKA002130A0292	Socket Outlets Various symbols with screw terminals studio white - future linear	2332 UJBS-84	1	piece
2CKA002099A0198	Flush Mounted Inserts	2397 UCKS-84-505	1	piece
2CKA002013A5361	Flush Mounted Inserts Safety Shutter with screw terminals studio white	2398 CKS-84	1	piece
2CKA002099A0214	Socket insert Safety Shutter studio white - Platform 63	2399 UCKS-84	1	piece
2CKA002099A0192	Socket Outlets Safety Shutter studio white - Platform 63	2399 UCKS-84-505	1	piece
2CKA001719A0220	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring studio white - Platform 63	2518-WD-84	1	piece
2CKA001751A3179	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white - Platform 63	2520 KI-84	1	piece
2CKA001751A3180	Rocker with legend Symbol "bell" for Switch/push button Single rocker studio white - Platform 63	2520 KI-84-500	1	piece
2CKA001751A3189	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white - Platform 63	2520 LI-84	1	piece
2CKA001751A3190	Mechanical Controls Symbol "light" for Switch/push button, Single rocker studio white - Platform 63	2520 LI-84-500	1	piece
2CKA001751A3199	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - Platform 63	2520 TR-84	1	piece
2CKA001724A4256	Cover plate Pilot devices 1 gang studio white - Platform 63	2533-84	1	piece
2CKA001710A3646	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - Platform 63	2542 DR/01-84	1	piece
2CKA001710A3651	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - Platform 63	2542 DR/02-84	1	piece
2CKA001724A4383	Cover plate Call unit studio white - Platform 63	2548-020 D-84	1	piece
2CKA001724A4384	Cover plate Call unit studio white - Platform 63	2548-020 E-84	1	piece
2CKA001724A4385	Cover plate Call unit studio white - Platform 63	2548-020 F-84	1	piece
2CKA001724A4386	Cover plate Call unit studio white - Platform 63	2548-021 G-84	1	piece
2CKA001724A4387	Cover plate / Red 1 gang studio white - Platform 63	2548-022 A-84	1	piece
2CKA001724A4388	Cover plate Doctor / Blue 1 gang studio white - Platform 63	2548-022 AR-84	1	piece
2CKA001724A4389	Cover plate Call module / Red 1 gang studio white - Platform 63	2548-022 B-84	1	piece
2CKA001724A4390	Cover plate Pull-cord switch studio white - Platform 63	2548-046 A-84	1	piece
2CKA001724A4391	Cover plate Call module / Red 1 gang studio white - Platform 63	2548-071 D-84	1	piece
2CKA001724A4392	Cover plate Call module / Red 1 gang studio white - Platform 63	2548-071 E-84	1	piece
2CKA001724A4393	Cover plate Call / reset / Red / Green 2 gang studio white - Platform 63	2548-642 B-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001724A4394	Cover plate Duty room unit / White / Green 2 gang studio white - Platform 63	2548-642 BD-84	1	piece
2CKA001724A4395	Cover plate Reset / Green 1 gang studio white - Platform 63	2548-642 C-84	1	piece
2CKA001724A4396	Cover plate Reset / Yellow 1 gang studio white - Platform 63	2548-642 D-84	1	piece
2CKA001724A4397	Cover plate Reset / Yellow / Green 2 gang studio white - Platform 63	2548-642 E-84	1	piece
2CKA001724A4402	Cover plate XLR 1 gang studio white - Platform 63	2553-84	1	piece
2CKA001753A0394	Cover plate Keystone 2 gang studio white - Platform 63	2561-02-84	1	piece
2CKA001753A0403	Cover plate Keystone 1 gang studio white - Platform 63	2561-84	1	piece
2CKA001751A3258	Rocker with Small Transparent Calotte for Electronic push button insert Single rocker studio white - Platform 63	2570-10-84	1	piece
2CKA001751A3269	Rocker with Small Transparent Calotte for Electronic push button insert Two-part rocker studio white - Platform 63	2570-20-84	1	piece
2CKA001751A3280	Rocker with Small Transparent Calotte for Electronic push button insert Three-part rocker studio white - Platform 63	2570-30-84	1	piece
2CKA001710A3505	Data / Telecommunication / Antenna TAE 1 gang studio white - Platform 63	2767-84-503	1	piece
2CKA003116A0662	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter studio white - Platform 63	3120 EUCB-84	1	piece
2CKA003117A0006	Buschmat RCD - Insert RCD 16 A 30 mA studio white - Platform 63	3151 UC-84	1	piece
2CKA006115A0467	Cover plate Symbols "up, down, menu left, menu right, " 1-gang for Control element 6gang studio white - Platform 63	6108/61-84	1	piece
2CKA006115A0486	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang studio white - Platform 63	6108/61-84-500	1	piece
2CKA006155A0044	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller studio white - Platform 63	6109/03-84	1	piece
2CKA006155A0063	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller studio white - Platform 63	6109/03-84-500	1	piece
2CKA006132A0249	Watchdog 180 Standard FM	6122/01-84	1	piece
2CKA006132A0355	WD sens KNX 180 standard	6122/01-840-500	1	piece
2CKA006132A0262	Busch-Watchdog 180 ° Motion detector Twisted Pair Wiring studio white	6122/02-84	1	piece
2CKA006132A0263	Presence Detection Twisted Pair Wiring studio white	6122/02-84-500	1	piece
2CKA006132A0366	Busch-Watchdog Motion detector Twisted Pair Wiring studio white	6122/10-84	1	piece
2CKA006132A0379	Busch-Watchdog Motion detector Twisted Pair Wiring studio white	6122/10-84-500	1	piece
2CKA006133A0144	Interface RS 232, FM	6123-84	1	piece
2CKA006133A0164	Interface RS 232, FM	6123-84-500	1	piece
2CKA006134A0247	Room Thermostat	6124/01-84	1	piece
2CKA006134A0222	Room Thermostat with Display	6124-84-101	1	piece
2CKA006134A0223	6124-84-500-101 Room Thermostat with Display	6124-84-500-101	1	piece
2CKA006115A0182	Control Element with Bus Coupler 2gang Twisted Pair Wiring studio white - Platform 63	6125/01-84	1	piece
2CKA006115A0183	Upper end strip 2gang Twisted Pair Wiring studio white - Platform 63	6125/01-84-500	1	piece
2CKA006115A0196	Control Element 2gang studio white - Platform 63	6125/02-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006115A0219	Control Element 2gang studio white - Platform 63	6125/02-84-500	1	piece
2CKA006115A0167	Switch Sensor 1-fold, FM	6125-84-101	1	piece
2CKA006116A0173	Control Element with Bus Coupler 4gang Twisted Pair Wiring studio white - Platform 63	6126/01-84	1	piece
2CKA006116A0174	Surface box 4gang Twisted Pair Wiring studio white - Platform 63	6126/01-84-500	1	piece
2CKA006116A0186	Control Element 4gang studio white - Platform 63	6126/02-84	1	piece
2CKA006116A0209	Labeling Cover 4gang studio white - Platform 63	6126/02-84-500	1	piece
2CKA006117A0199	Control Element with Bus Coupler 8gang Twisted Pair Wiring studio white - Platform 63	6127/01-84	1	piece
2CKA006117A0200	HVAC-device 8gang Twisted Pair Wiring studio white - Platform 63	6127/01-84-500	1	piece
2CKA006117A0212	Control Element 8gang studio white - Platform 63	6127/02-84	1	piece
2CKA006117A0235	HVAC-Slave-device 8gang studio white - Platform 63	6127/02-84-500	1	piece
2CKA006134A0260	RTC Control element 2/4g	6128/01-84	1	piece
2CKA006134A0311	cont.-element KNX 2g temp	6128/01-840-500	1	piece
2CKA006134A0324	Control Element 4gang studio white - Platform 63	6128/28-84	1	piece
2CKA006134A0334	HVAC-Slave-device 4gang studio white - Platform 63	6128/28-84-500	1	piece
2CKA006134A0211	6128-84-101 RoomThermostat/Switch Sensor	6128-84-101	1	piece
2CKA006134A0212	6128-84-500-101 RoomThermostat/Switch Sensor	6128-84-500-101	1	piece
2CKA006135A0145	Control Element 3gang studio white - Platform 63	6129/01-84	1	piece
2CKA006135A0146	Solo 3gang studio white - Platform 63	6129/01-84-500	1	piece
2CKA006135A0131	IR-Switch Sensor 3fold, FM	6129-84-101	1	piece
2CKA006138A0002	RTR Fan Coil with Display, SM	6138/11-84	1	piece
2CKA006138A0003	RTR Fan Coil with Display, SM	6138/11-84-500	1	piece
2CKA006220A0112	Motion detector 1gang Movement sensor 1 channel Twisted Pair Wiring studio white - Platform 63	6215/1.1-84	1	piece
2CKA006200A0056	WL-Mov. detector/act. 1g	6215/1.1-84-WL	1	piece
2CKA006220A0109	Motion detector Movement sensor 1 channel Twisted Pair Wiring studio white - Platform 63	6225/1.0-84	1	piece
2CKA006220A0034	Rocker with Small Transparent Calotte 1gang studio white - Platform 63	6230-10-84	1	piece
2CKA006220A0049	Rocker with Small Transparent Calotte 2gang studio white - Platform 63	6230-20-84	1	piece
2CKA006220A0037	Rocker Symbol "light" with Small Transparent Calotte 1gang studio white - Platform 63	6231-10-84	1	piece
2CKA006220A0052	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white - Platform 63	6231-21-84	1	piece
2CKA006220A0064	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white - Platform 63	6231-22-84	1	piece
2CKA006220A0040	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang studio white - Platform 63	6232-10-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0055	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang studio white - Platform 63	6232-20-84	1	piece
2CKA006220A0043	Rocker Symbol "scene" with Small Transparent Calotte 1gang studio white - Platform 63	6233-10-84	1	piece
2CKA006220A0058	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white - Platform 63	6233-21-84	1	piece
2CKA006220A0070	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white - Platform 63	6233-22-84	1	piece
2CKA006220A0046	Rocker Symbol "dimming" with Small Transparent Calotte 1gang studio white - Platform 63	6234-10-84	1	piece
2CKA006220A0061	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white - Platform 63	6234-21-84	1	piece
2CKA006220A0255	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white - Platform 63	6234-22-84	1	piece
2CKA006220A0076	Cover plate with legend Symbols "up, down, ECO, Power" 2gang for Room temperature controller studio white - Platform 63	6235-84	1	piece
2CKA006220A0250	Cover plate Symbols "up, down, ECO, menu" 2gang studio white - Platform 63	6236-84	1	piece
2CKA006220A0739	Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white - Platform 63	6237-21-84	1	piece
2CKA006220A0740	Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white - Platform 63	6237-22-84	1	piece
2CKA006200A0284	Blind insert flex set 2gang 2 rocker Wireless studio white - future linear	62731/UJ-84-WL	1	piece
2CKA006200A0285	Kits 1-gang 2gang 2 rocker Wireless studio white - future linear	62731/UJ-84-WL-500	1	piece
2CKA006200A0195	Motion detector sensor set 1gang Movement sensor Wireless studio white - future linear	62762 UJ-84-WL	1	piece
2CKA006200A0196	Kits 1gang Movement sensor Wireless studio white - future linear	62762 UJ-84-WL-500	1	piece
2CKA006200A0171	Motion detector Movement sensor Wireless studio white - Platform 63	62762-84-WL	1	piece
2CKA006200A0172	Presence Detector Movement sensor Wireless studio white - Platform 63	62762-84-WL-500	1	piece
2CKA006200A0263	Motion detector sensor set 1gang Movement sensor Wireless studio white - future linear	62764 UJ-84-WL	1	piece
2CKA006200A0264	Kits 1gang Movement sensor Wireless studio white - future linear	62764 UJ-84-WL-500	1	piece
2CKA006200A0239	Motion detector Enrolment device Wireless studio white - Platform 63	62764-84-WL	1	piece
2CKA006200A0240	Motion Detectors Enrolment device Wireless studio white - Platform 63	62764-84-WL-500	1	piece
2CKA006200A0294	LED Dimmer set 1gang Wireless studio white - future linear	62851 UJ-84-WL	1	piece
2CKA006200A0295	Kits 1gang Wireless studio white - future linear	62851 UJ-84-WL-500	1	piece
2CKA006410A0408	Busch-Jalousiecontrol® II Blind timer set studio white - future linear	6411 UJ-84-101	1	piece
2CKA006410A0413	Blind timer set 2gang studio white - future linear	6422 UJ-84	1	piece
2CKA006430A0329	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker studio white - Platform 63	6430-84-102	1	piece
2CKA006430A0400	Electronic Controls Symbol "arrows" for Venetian blind One-part rocker studio white - Platform 63	6430-84-102-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006430A0306	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate studio white - Platform 63	6435-84	1	piece
2CKA006800A2950	Busch-Watchdog 180 flex Set, Basic sensor with select lens 1gang Movement sensor studio white - future linear	64761 UJ-84	1	piece
2CKA006800A2951	Electronic Controls 1gang Movement sensor studio white - future linear	64761 UJ-84-500	1	piece
2CKA006800A2926	Busch-Watchdog 180 flex Cover plate Movement sensor studio white - Platform 63	64761-84	1	piece
2CKA006800A2927	Electronic Controls Movement sensor studio white - Platform 63	64761-84-500	1	piece
2CKA006800A2987	Busch-Watchdog 180 flex Set, Comfort sensor with select lens 1gang Movement sensor studio white - future linear	64762 UJ-84	1	piece
2CKA006800A2988	Control Element 1gang Movement sensor Wireless studio white - future linear	64762 UJ-84-500	1	piece
2CKA006800A2963	Busch-Watchdog 180 flex Cover plate Movement sensor studio white - Platform 63	64762-84	1	piece
2CKA006800A2964	Busch-Watchdog Cover plate Movement sensor studio white - Platform 63	64762-84-500	1	piece
2CKA006800A3024	Busch-Watchdog 180 flex Set, Multi sensor with select lens 1gang Movement sensor studio white - future linear	64764 UJ-84	1	piece
2CKA006800A3025	Kits 1gang Movement sensor studio white - future linear	64764 UJ-84-500	1	piece
2CKA006800A3000	Busch-Watchdog 180 flex Cover plate Movement sensor studio white - Platform 63	64764-84	1	piece
2CKA006800A3001	Electronic Controls Movement sensor studio white - Platform 63	64764-84-500	1	piece
2CKA006800A2913	Motion detector switch set with relais insert 1gang Movement sensor studio white - future linear	64765 UJ-84	1	piece
2CKA006800A2888	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light studio white - Platform 63	64765-84	1	piece
2CKA006800A2889	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light studio white - Platform 63	64765-84-500	1	piece
2CKA006470A0004	Cover plate for Proximity switch studio white - Platform 63	6476-84	1	piece
2CKA006400A0059	Cover plate PowerDock 1 gang studio white - Platform 63	6477-84	1	piece
2CKA006400A0449	Cover plate USB power supply insert 1 gang with USB C studio white - Platform 63	6479-84	1	piece
2CKA006400A0046	Busch-powerDock set Busch-powerDock with USB C studio white - future linear	6480/11-84	1	piece
2CKA006400A0047	Multimedia Devices Busch-powerDock with USB C studio white - future linear	6480/11-84-500	1	piece
2CKA006400A0044	Set Busch-powerDock Apple Lightning with Lightning studio white - future linear	6480-84	1	piece
2CKA006400A0045	Multimedia Devices Busch-powerDock Apple Lightning with Lightning studio white - future linear	6480-84-500	1	piece
2CKA006512A0350	LED Dimmer set with Neon lamp studio white - future linear	6523 UJ-84-102	1	piece
2CKA006512A0357	Busch-Rotary dimmer Electronic Controls studio white	6523 URCGL-84-104	1	piece
2CKA006512A0347	Busch-Rotary dimmer Electronic Controls studio white - future linear	6523URCGL-84-103	1	piece
2CKA006599A2953	Cover plate for Dimmer Turn button with Neon lamp studio white - Platform 63	6540-84-102	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006599A3009	Electronic Controls for Dimmer Turn button with Neon lamp studio white - Platform 63	6540-84-102-500	1	piece
2CKA006599A2835	Cover plate for Cooling Central cover plate studio white - Platform 63	6541-84	1	piece
2CKA006599A2834	Control Element for Switch/dimmer Single push button with Neon lamp studio white - Platform 63	6543-84-101	1	piece
2CKA006599A3010	Electronic Controls for Switch/dimmer Single push button with Neon lamp studio white - Platform 63	6543-84-101-500	1	piece
2CKA006599A2908	Control Element for Dimmer Two-part button with Neon lamp studio white - Platform 63	6545-84	1	piece
2CKA006710A0010	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless studio white - future linear	6716 UJ-84	1	piece
2CKA006710A0011	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless studio white - future linear	6716 UJ-84-500	1	piece
2CKA006730A0154	Bluetooth Low Energie (BLE/Casambi) Smart Switch set for Bluetooth Low Energy (BLE) 4 channel Wireless studio white - future linear	6716/01 UJ-84	1	piece
2CKA006730A0156	Bluetooth Low Energie (BLE/Casambi) Smart Switch set for Bluetooth Low Energy (BLE) 4 channel Wireless studio white - future linear	6716/01 UJ-84-500	1	piece
2CKA006730A0158	Bluetooth Low Energie (BLE/Casambi) Smart Switch set for Bluetooth Low Energy (BLE) 4 channel Wireless studio white - Impressivo	6716/01 UJ-84-510	1	piece
2CKA006710A0020	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless studio white - future linear	6716/03 UJ-84	1	piece
2CKA006710A0004	Plug-in unit switch studio white	6717-84	1	piece
2CKA006710A0008	Plug-in unit switch studio white	6717-84-500	1	piece
2CKA006730A0054	WaveLine Wall sensor 1-gang 1 channel Wireless studio white - Platform 63	6731-84	1	piece
2CKA006730A0038	WaveLine Wall sensor 1 channel Wireless studio white - Platform 63	6731-84-500	1	piece
2CKA006730A0055	WaveLine Wall sensor 2-gang Wireless studio white - Platform 63	6732-84	1	piece
2CKA006730A0039	WaveLine Wall sensor 2 channel Wireless studio white - Platform 63	6732-84-500	1	piece
2CKA006730A0056	WaveLine Wall sensor 4-gang Wireless studio white - Platform 63	6733-84	1	piece
2CKA006730A0040	WaveLine Wall sensor 4 channel Wireless studio white - Platform 63	6733-84-500	1	piece
2CKA006730A0145	Rocker for Smart switch Single rocker studio white - Platform 63	6735 BT-84	1	piece
2CKA006730A0082	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless studio white - Platform 63	6735/01-84	1	piece
2CKA006730A0164	Rocker Symbol "arrows" for Smart switch Single rocker studio white - Platform 63	6735/10-84	1	piece
2CKA006220A0988	Rocker 1g blinds Symbol "venetian blind" for Smart switch Single rocker studio white - Platform 63	6735-11-84	1	piece
2CKA006730A0070	Control Element 1-gang for Switch/dimmer Wireless studio white - Platform 63	6735-84	1	piece
2CKA006730A0136	Rocker for Smart switch Two-part rocker studio white - Platform 63	6736 FoH-84	1	piece
2CKA006730A0086	Wall sensor 2-gang 2 channel Wireless studio white - Platform 63	6736/01-84	1	piece
2CKA006730A0165	Rocker for Smart switch Two-part rocker studio white - Platform 63	6736/10-84	1	piece
2CKA006730A0074	Control Element 2-gang for Switch/dimmer Wireless studio white - Platform 63	6736-84	1	piece
2CKA006730A0090	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless studio white - Platform 63	6737/01-84	1	piece
2CKA006730A0078	Control Element 4-gang for Switch/dimmer Wireless studio white - Platform 63	6737-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006800A2101	Electronic Controls - Platform 63	6800-84-104	1	piece
2CKA006800A2833	Electronic Controls studio white - Platform 63	6815-84-101	1	piece
2CKA006800A2834	Electronic Controls studio white - Platform 63	6815-84-101-500	1	piece
2CKA006800A2873	Busch-Alarm Push Button, Mute and Service Functions, studio white	6824/11-84	1	piece
2CKA006800A2516	Alarm Devices, studio white	6824-84	1	piece
2CKA006800A2515	Busch-Alarm Relay Module, studio white	6829-84	1	piece
2CKA006800A2716	Overvoltage Release, studio white	6834-84	1	piece
2CKA006800A2722	heat detector - Lithium +C	6835/01-84	1	piece
2CKA006800A2723	Alarm Devices, studio white	6835/01-84-500	1	piece
2CKA006800A2870	Busch-CO Alarm Alarm Devices, Networkable, studio white	6839/01-84-500	1	piece
2CKA008200A0233	Busch-Radio set DAB+ studio white - future linear	8220 UJ-84-101	1	piece
2CKA008200A0234	Busch-Radio set DAB+ studio white - future linear	8220 UJ-84-101-500	1	piece
2CKA008200A0155	Busch-Radio set Internet Radio Wireless LAN studio white - future linear	8240-84	1	piece
2CKA008200A0156	Busch-Radio set Internet Radio Wireless LAN studio white - future linear	8240-84-500	1	piece
2CKA008200A0254	Cover plate with legend Busch-Radio Radio studio white - Platform 63	8252-84-101	1	piece
2CKA008200A0255	Cover plate with legend Radio 0 gang studio white - Platform 63	8252-84-101-500	1	piece
2CKA008200A0081	Cover plate Loudspeaker studio white - Platform 63	8253-84	1	piece
2CKA008200A0224	Cover plate Multimedia 3 gang studio white - Platform 63	8256-84	1	piece
2CKA008200A0236	Busch-Radio set DAB+, Bluetooth Bluetooth studio white - future linear	8270 UJ-84-101	1	piece
2CKA008200A0237	Busch-Radio set DAB+, Bluetooth Bluetooth studio white - future linear	8270 UJ-84-101-500	1	piece
2CKA008300A0213	Cover plate, studio white	83260-84	1	piece
2CKA008300A0365	Cover plate	83260-840-500	1	piece
2CKA008300A0225	Welcome, studio white	83260-84-515	1	piece
2CKA006220A0244	User Operation Symbols "up, down, ECO, menu" 1gang studio white - Platform 63	CP-FCC-84	1	piece
2CKA006220A0181	User Operation Symbols "up, down, ECO, Power" 1gang studio white - Platform 63	CP-RTC-84	1	piece
2CKA006115A0504	Keypad white - Trevion	KK/U4.63.1	1	piece
2CKA006115A0503	Keypad KNX (TP)	KK/U4.63.11	1	piece
2CKA006199A0210	Cover plate Symbol "arrows" studio white - Platform 63	LFAW/A.1.63.11-84	1	piece
2CKA006199A0282	Trevion® studio white	LFAW/A.1.63.1-84	1	piece
2CKA006199A0250	Cover plate Symbol "arrows" studio white - Platform 63	LFAW/A.2.63.11-84	1	piece
2CKA006199A0322	Cover plate Symbol "arrows" studio white - Platform 63	LFAW/A.2.63.1-84	1	piece
2CKA006199A0077	Cover plate Symbol "light" studio white - Platform 63	LFBT/A.1.63.11-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0137	Cover plate Symbol "light" studio white - Platform 63	LFBT/A.1.63.1-84	1	piece
2CKA006199A0218	Cover plate Symbol "light" studio white - Platform 63	LFBT/A.2.63.11-84	1	piece
2CKA006199A0290	Cover plate Symbol "light" studio white - Platform 63	LFBT/A.2.63.1-84	1	piece
2CKA006199A0194	Cover plate Symbol "dimming" studio white - Platform 63	LFDW/A.1.63.11-84	1	piece
2CKA006199A0266	Cover plate Symbol "dimming" studio white - Platform 63	LFDW/A.1.63.1-84	1	piece
2CKA006199A0242	Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white - Platform 63	LFDW/A.2.63.1-84	1	piece
2CKA006199A0314	Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white - Platform 63	LFDW/A.2.63.1-84	1	piece
2CKA006199A0085	Cover plate Symbol "venetian blind" studio white - Platform 63	LFJT/A.1.63.11-84	1	piece
2CKA006199A0146	Cover plate Symbol "venetian blind" studio white - Platform 63	LFJT/A.1.63.1-84	1	piece
2CKA006199A0226	Cover plate Symbol "venetian blind" studio white - Platform 63	LFJT/A.2.63.11-84	1	piece
2CKA006199A0298	Cover plate Symbol "venetian blind" studio white - Platform 63	LFJT/A.2.63.1-84	1	piece
2CKA006199A0202	Cover plate Symbol "venetian blind" studio white - Platform 63	LFJW/A.1.63.11-84	1	piece
2CKA006199A0274	Cover plate Symbol "venetian blind" studio white - Platform 63	LFJW/A.1.63.1-84	1	piece
2CKA006199A0258	Cover plate Symbols "music control" studio white - Platform 63	LFMW/A.4.63.1-84	1	piece
2CKA006199A0330	Cover plate Symbols "music control" studio white - Platform 63	LFMW/A.4.63.1-84	1	piece
2CKA006199A0093	Cover plate Symbol "scene" studio white - Platform 63	LFST/A.1.63.11-84	1	piece
2CKA006199A0155	Cover plate Symbol "scene" studio white - Platform 63	LFST/A.1.63.1-84	1	piece
2CKA006199A0234	Cover plate Symbol "scene" studio white - Platform 63	LFST/A.2.63.11-84	1	piece
2CKA006199A0306	Cover plate Symbol "scene" studio white - Platform 63	LFST/A.2.63.1-84	1	piece
2CKA006199A0040	Cover plate None - Platform 63	LFW/A.0.63.11-CK	1	piece
2CKA006199A0513	Cover plate None - Platform 63	LFW/A.0.63.11-CKL	1	piece
2CKA006199A0041	Cover plate None - Platform 63	LFW/A.0.63.1-CK	1	piece
2CKA006199A0514	Cover plate None - Platform 63	LFW/A.0.63.1-CKL	1	piece
2CKA006199A0045	Cover plate studio white - Platform 63	LFW/A.1.63.11-84	1	piece
2CKA006199A0101	Cover plate studio white - Platform 63	LFW/A.1.63.1-84	1	piece
2CKA006199A0053	Cover plate studio white - Platform 63	LFW/A.2.63.11-84	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0110	Cover plate studio white - Platform 63	LFW/A.2.63.1-84	1	piece
2CKA006199A0061	Cover plate studio white - Platform 63	LFW/A.3.63.11-84	1	piece
2CKA006199A0119	Cover plate studio white - Platform 63	LFW/A.3.63.1-84	1	piece
2CKA006199A0069	Cover plate studio white - Platform 63	LFW/A.4.63.11-84	1	piece
2CKA006199A0128	Cover plate studio white - Platform 63	LFW/A.4.63.1-84	1	piece
2CKA006220A0214	Motion Detectors Movement sensor Twisted Pair Wiring studio white - Platform 63	MD-F-1.0.1-84	1	piece
2CKA006220A0217	Motion Detectors 1gang Movement sensor 1 channel Twisted Pair Wiring studio white - Platform 63	MSA-F-1.1.1-84	1	piece
2CKA006200A0086	WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	piece
2TMA310010B0003	SD/U12.63.11-825,RoomTouch 2.4,12 gang glass black - Platform 63	SD/U12.63.11-825	1	piece
2TMA310011B0002	RoomTouch 2.4 2.4 in "glass black - Trevion	SD/U12.63.1-825	1	piece
2CKA006220A0139	Rocker with Small Transparent Calotte 1gang studio white - Platform 63	SR-1-84	1	piece
2CKA006220A0154	Rocker with Small Transparent Calotte 2gang studio white - Platform 63	SR-2-84	1	piece
2CKA006220A0145	Rocker with Small Transparent Calotte 1gang studio white - Platform 63	SRB-1-84	1	piece
2CKA006220A0160	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang studio white - Platform 63	SRB-2-84	1	piece
2CKA006220A0151	Rocker Symbol "dimming" with Small Transparent Calotte 1gang studio white - Platform 63	SRD-1-84	1	piece
2CKA006220A0166	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white - Platform 63	SRD-2-L-84	1	piece
2CKA006220A0260	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white - Platform 63	SRD-2-R-84	1	piece
2CKA006220A0142	Rocker Symbol "light" with Small Transparent Calotte 1gang studio white - Platform 63	SRL-1-84	1	piece
2CKA006220A0157	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white - Platform 63	SRL-2-L-84	1	piece
2CKA006220A0169	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white - Platform 63	SRL-2-R-84	1	piece
2CKA006220A0148	Rocker Symbol "scene" with Small Transparent Calotte 1gang studio white - Platform 63	SRS-1-84	1	piece
2CKA006220A0163	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white - Platform 63	SRS-2-L-84	1	piece
2CKA006220A0175	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white - Platform 63	SRS-2-R-84	1	piece
2CKA001731A1921	Cover Busch-Infolicht® anthracite - Platform 63	1716-81	1	piece
2CKA001731A1922	Cover Busch-Infolicht® ivory white - Platform 63	1716-82	1	piece
2CKA001731A1914	Rocker open for red pull button calotte, Pull cord anthracite - Platform 63	1720-81	1	piece
2CKA001731A1915	Rocker open for red pull button calotte, Pull cord ivory white - Platform 63	1720-82	1	piece
2CKA001710A4120	Cover plate with legend Loudspeaker Turn button anthracite - Platform 63	1740 DR/03-81	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3807	Cover plate with legend Loudspeaker Turn button ivory white - Platform 63	1740 DR/03-82	1	piece
2CKA001710A4122	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button anthracite - Platform 63	1740 DRL-81-503	1	piece
2CKA001710A3511	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button ivory white - Platform 63	1740 DRL-82-503	1	piece
2CKA001710A3623	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button anthracite - Platform 63	1740-81	1	piece
2CKA001710A3154	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button ivory white - Platform 63	1740-82	1	piece
2CKA001710A3612	Cover plate for Blind cap 1-gang with Mounting plate anthracite - Platform 63	1742-81	1	piece
2CKA001710A3143	Cover plate for Blind cap 1-gang with Mounting plate ivory white - Platform 63	1742-82	1	piece
2CKA001724A4365	Cover plate SAT 4 gang anthracite - Platform 63	1743/10-04-81	1	piece
2CKA001724A4366	Cover plate SAT 4 gang ivory white - Platform 63	1743/10-04-82	1	piece
2CKA001724A4374	Cover plate SAT 4 gang anthracite - Platform 63	1743-04-81	1	piece
2CKA001724A4375	Cover plate SAT 4 gang ivory white - Platform 63	1743-04-82	1	piece
2CKA001724A4252	Cover plate SAT 3 gang anthracite - Platform 63	1743-81	1	piece
2CKA001724A2758	Cover plate SAT 3 gang ivory white - Platform 63	1743-82	1	piece
2CKA001710A3624	Cover plate telephone connector boxes (VDo) anthracite - Platform 63	1745-81	1	piece
2CKA001710A3155	Cover plate telephone connector boxes (VDo) ivory white - Platform 63	1745-82	1	piece
2CKA001710A3628	Cover plate 50x50 mm for data connection housing anthracite - Platform 63	1746/10-81	1	piece
2CKA001710A3521	Cover plate 50x50 mm for data connection housing ivory white - Platform 63	1746/10-82	1	piece
2CKA001710A3618	Cover plate 50x50 mm with Hinged Lid for data connection housing anthracite - Platform 63	1746-81	1	piece
2CKA001710A3149	Cover plate 50x50 mm with Hinged Lid for data connection housing ivory white - Platform 63	1746-82	1	piece
2CKA001710A4093	Intermediate Ring for cover plates Busch-Balance® SI 1-gang anthracite - Platform 63	1747 BSI-81	1	piece
2CKA001710A4094	Intermediate Ring for cover plates Busch-Balance® SI 1-gang ivory white - Platform 63	1747 BSI-82	1	piece
2CKA001710A3862	Intermediate Ring for Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - Platform 63	1747 SI-82	1	piece
2CKA001710A3860	Intermediate Ring ivory white - Platform 63	1747-82	1	piece
2CKA001710A3654	Cover plate Data connection 2 gang anthracite - Platform 63	1748-81	1	piece
2CKA001710A3655	Cover plate Data connection 2 gang ivory white - Platform 63	1748-82	1	piece
2CKA001710A3614	Cover plate for Cable outlet 1-gang with Mounting plate anthracite - Platform 63	1749-81	1	piece
2CKA001710A3145	Cover plate for Cable outlet 1-gang with Mounting plate ivory white - Platform 63	1749-82	1	piece
2CKA001710A3617	Cover plate BNC/TNC 2 gang anthracite - Platform 63	1750-81	1	piece
2CKA001710A3148	Cover plate BNC/TNC 2 gang ivory white - Platform 63	1750-82	1	piece
2CKA001723A0253	Cover plate Loudspeaker 2 gang anthracite - Platform 63	1751-81	1	piece
2CKA001723A0239	Cover plate Loudspeaker 2 gang ivory white - Platform 63	1751-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3626	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key anthracite - Platform 63	1755 SL/PZ-81-101	1	piece
2CKA001710A3157	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key ivory white - Platform 63	1755 SL/PZ-82-101	1	piece
2CKA001753A0089	Cover plate Busch-Infolicht® anthracite - Platform 63	1756-81	1	piece
2CKA001753A0090	Cover plate Busch-Infolicht® ivory white - Platform 63	1756-82	1	piece
2CKA001724A4253	Cover plate with labelling field for data connection housing anthracite - Platform 63	1758-81	1	piece
2CKA001724A2759	Cover plate with labelling field for data connection housing ivory white - Platform 63	1758-82	1	piece
2CKA001710A4103	Data / Telecommunication / Antenna TDO anthracite - Platform 63	1762-81-506	1	piece
2CKA001710A4104	Data / Telecommunication / Antenna TDO ivory white - Platform 63	1762-82-506	1	piece
2CKA001731A3998	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker anthracite - Platform 63	1764 NLI/KI-81	1	piece
2CKA001731A3999	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker ivory white - Platform 63	1764 NLI/KI-82	1	piece
2CKA001731A4011	Rocker with labelling field for Switch/push button, Single rocker red - Platform 63	1764 NLI-12-82-101	1	piece
2CKA001731A4007	Rocker with labelling field for Switch/push button, Single rocker green - Platform 63	1764 NLI-13-82	1	piece
2CKA001731A1552	Rocker with labelling field for Switch/push button, Single rocker anthracite - Platform 63	1764 NLI-81	1	piece
2CKA001731A1876	Rocker with labelling field for Switch/push button, Single rocker ivory white - Platform 63	1764 NLI-82	1	piece
2CKA001710A3613	Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang anthracite - Platform 63	1766-81	1	piece
2CKA001710A3144	Cover plate D-Sub 15-pole 1 gang ivory white - Platform 63	1766-82	1	piece
2CKA001753A0255	Cover plate with legend 0 ... 15 Min for Time switch, Turning handle anthracite - Platform 63	1770-81-103	1	piece
2CKA001753A0256	Cover plate with legend 0 ... 15 Min for Time switch, Turning handle ivory white - Platform 63	1770-82-103	1	piece
2CKA001753A0265	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle anthracite - Platform 63	1771-81-103	1	piece
2CKA001753A0266	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle ivory white - Platform 63	1771-82-103	1	piece
2CKA001751A2977	Multimedia Devices anthracite	1785 ENO-81	1	piece
2CKA001751A2978	Multimedia Devices ivory white	1785 ENO-82	1	piece
2CKA001751A3101	Rocker with legend Symbol "arrows" for KNX push-button coupling unit, Two-part rocker ivory white - Platform 63	1785 JA/02-82	1	piece
2CKA001751A2934	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker anthracite - Platform 63	1785 JA-81	1	piece
2CKA001751A2748	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory white - Platform 63	1785 JA-82	1	piece
2CKA001751A3121	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker anthracite - Platform 63	1785 K-81	1	piece
2CKA001751A3122	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker anthracite - Platform 63	1785 K-81-500	1	piece
2CKA001751A3123	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker ivory white - Platform 63	1785 K-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3124	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker ivory white - Platform 63	1785 K-82-500	1	piece
2CKA001751A3212	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker anthracite - Platform 63	1785/11 K-81	1	piece
2CKA001751A3214	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker ivory white - Platform 63	1785/11 K-82	1	piece
2CKA001751A3205	Rocker with legend DND, MUR for Switch/push button, Two-part rocker anthracite - Platform 63	1785/11-81	1	piece
2CKA001751A2991	Rocker with legend DND, MUR for Switch/push button, Two-part rocker ivory white - Platform 63	1785/11-82	1	piece
2CKA001751A2744	Rocker for Switch/push button, Two-part rocker ivory white - Platform 63	1785-82	1	piece
2CKA001751A2965	Multimedia Devices anthracite	1786 ENO-81	1	piece
2CKA001751A2966	Multimedia Devices ivory white	1786 ENO-82	1	piece
2CKA001751A3100	Rocker with legend Symbol "arrows" for KNX push-button coupling unit, Single rocker ivory white - Platform 63	1786 JA/02-82	1	piece
2CKA001751A3207	Rocker with legend DND for Switch/push button, Single rocker anthracite - Platform 63	1786/11-81	1	piece
2CKA001751A2997	Rocker with legend DND for Switch/push button, Single rocker ivory white - Platform 63	1786/11-82	1	piece
2CKA001751A2741	Rocker for Switch/push button, Single rocker ivory white - Platform 63	1786-82	1	piece
2CKA001751A3083	Control Elements for Switch/push button, Single rocker ivory white - Platform 63	1786-82-500	1	piece
2CKA001751A2927	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1788-81	1	piece
2CKA001751A2742	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1788-82	1	piece
2CKA001751A2929	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 H-81	1	piece
2CKA001751A2743	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 H-82	1	piece
2CKA001751A2932	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 KI-81	1	piece
2CKA001751A2746	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 KI-82	1	piece
2CKA001751A2931	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 LI-81	1	piece
2CKA001751A2745	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 LI-82	1	piece
2CKA001751A3147	Rocker with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 N-81	1	piece
2CKA001751A3148	Rocker with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 N-82	1	piece
2CKA001751A3157	Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 ST-81	1	piece
2CKA001751A3158	Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 ST-82	1	piece
2CKA001751A2933	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 TR-81	1	piece
2CKA001751A2747	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 TR-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A2928	Rocker with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789-81	1	piece
2CKA001751A2813	Rocker with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789-82	1	piece
2CKA001710A4130	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card anthracite - Platform 63	1792 RFID-81	1	piece
2CKA001710A4132	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card ivory white - Platform 63	1792 RFID-82	1	piece
2CKA001710A3639	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card anthracite - Platform 63	1792-81	1	piece
2CKA001710A3640	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card ivory white - Platform 63	1792-82	1	piece
2CKA006430A0417	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate anthracite - Platform 63	1794 MDRT-81	1	piece
2CKA006430A0418	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate ivory white - Platform 63	1794 MDRT-82	1	piece
2CKA001710A4198	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1794 R-81	1	piece
2CKA001710A4199	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1794 R-82	1	piece
2CKA001710A3695	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1794 TA-81	1	piece
2CKA001710A3696	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1794 TA-82	1	piece
2CKA001710A3629	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1794-81	1	piece
2CKA001710A3543	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1794-82	1	piece
2CKA001710A4013	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1795 HK-81	1	piece
2CKA001710A4015	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1795 HK-82	1	piece
2CKA001710A4045	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1795 HKEA-81	1	piece
2CKA001710A4047	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1795 HKEA-82	1	piece
2CKA001710A3722	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1795 TA-81	1	piece
2CKA001710A3723	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1795 TA-82	1	piece
2CKA001710A3630	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - Platform 63	1795-81	1	piece
2CKA001710A3568	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - Platform 63	1795-82	1	piece
2CKA001753A0308	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord anthracite - Platform 63	1796-81	1	piece
2CKA001753A0309	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord ivory white - Platform 63	1796-82	1	piece
2CKA001710A3627	Cover plate with labelling field Keystone 2 gang anthracite - Platform 63	1800-81	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3158	Cover plate with labelling field Modular Jack 2 gang ivory white - Platform 63	1800-82	1	piece
2CKA001710A3615	Cover plate with labelling field for data connection housing 2 gang anthracite - Platform 63	1803-02-81	1	piece
2CKA001710A3146	Cover plate with labelling field UAE/IAE (ISDN) 2 gang ivory white - Platform 63	1803-02-82	1	piece
2CKA001710A3616	Cover plate with labelling field for data connection housing 1 gang anthracite - Platform 63	1803-81	1	piece
2CKA001710A3147	Cover plate with labelling field UAE/IAE (ISDN) 1 gang ivory white - Platform 63	1803-82	1	piece
2CKA002013A5404	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter anthracite - Platform 63	20 EUAB-81	1	piece
2CKA002013A5405	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter ivory white - Platform 63	20 EUAB-82	1	piece
2CKA002011A6267	SCHUKO® USB socket insert Safety Shutter with USB A/A anthracite - Platform 63	20 EUCB2USB-81	1	piece
2CKA002011A6268	Socket insert Safety Shutter with USB A/A anthracite - Platform 63	20 EUCB2USB-81-500	1	piece
2CKA002011A6269	SCHUKO® USB socket insert Safety Shutter with USB A/A ivory white - Platform 63	20 EUCB2USB-82	1	piece
2CKA002011A6270	Socket insert Safety Shutter with USB A/A ivory white - Platform 63	20 EUCB2USB-82-500	1	piece
2CKA002011A6300	SCHUKO® USB socket insert Safety Shutter with USB A/C anthracite - Platform 63	20 EUCB2USBAC-81	1	piece
2CKA002011A6301	Socket insert Safety Shutter with USB A/C anthracite - Platform 63	20 EUCB2USBAC-81-500	1	piece
2CKA002011A6302	SCHUKO® USB socket insert Safety Shutter with USB A/C ivory white - Platform 63	20 EUCB2USBAC-82	1	piece
2CKA002011A6303	Socket insert Safety Shutter with USB A/C ivory white - Platform 63	20 EUCB2USBAC-82-500	1	piece
2CKA002013A5415	Busch-Service-Socket SCHUKO® socket insert Safety Shutter anthracite - Platform 63	20 EUCBDR-81	1	piece
2CKA002013A5416	Busch-Service-Socket SCHUKO® socket insert Safety Shutter ivory white - Platform 63	20 EUCBDR-82	1	piece
2CKA002013A5467	SCHUKO® socket insert Safety Shutter with LED Control light /Green green - Platform 63	20 EUCBL-13-84-101	1	piece
2CKA002013A5288	SCHUKO® socket insert Safety Shutter with LED Control light /Green orange - Platform 63	20 EUCBL-14-84	1	piece
2CKA002013A5457	SCHUKO® socket insert Safety Shutter with LED Control light /Green anthracite - Platform 63	20 EUCBL-81	1	piece
2CKA002013A5284	SCHUKO® socket insert Safety Shutter with LED Control light /Green ivory white - Platform 63	20 EUCBL-82	1	piece
2CKA002013A5459	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White anthracite - Platform 63	20 EUCBLI-81	1	piece
2CKA002013A5292	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White ivory white - Platform 63	20 EUCBLI-82	1	piece
2CKA002011A6158	Socket insert Safety Shutter with USB A anthracite - Platform 63	20 EUCBUSB-81	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002011A6176	Socket Outlets Safety Shutter with USB A anthracite - Platform 63	20 EUCBUSB-81-500	1	piece
2CKA002011A6159	Socket insert Safety Shutter with USB A ivory white - Platform 63	20 EUCBUSB-82	1	piece
2CKA002011A6177	Socket Outlets Safety Shutter with USB A ivory white - Platform 63	20 EUCBUSB-82-500	1	piece
2CKA002013A5463	SCHUKO® socket insert EDV Safety Shutter red - Platform 63	20 EUCKS/DV-12-82-101	1	piece
2CKA002013A5266	SCHUKO® Socket insert with legend EDV Safety Shutter anthracite - Platform 63	20 EUCKS/DV-81	1	piece
2CKA002013A5267	SCHUKO® Socket insert with legend EDV Safety Shutter ivory white - Platform 63	20 EUCKS/DV-82	1	piece
2CKA002013A5423	SCHUKO® Socket insert with labelling field Safety Shutter with label space red - Platform 63	20 EUCNB-12-82	1	piece
2CKA002013A5424	SCHUKO® Socket insert with labelling field Safety Shutter with label space green - Platform 63	20 EUCNB-13-82	1	piece
2CKA002013A5425	SCHUKO® Socket insert with labelling field Safety Shutter with label space orange - Platform 63	20 EUCNB-14-82	1	piece
2CKA002013A5427	SCHUKO® Socket insert with labelling field Safety Shutter with label space anthracite - Platform 63	20 EUCNB-81	1	piece
2CKA002013A5428	SCHUKO® Socket insert with labelling field Safety Shutter with label space ivory white - Platform 63	20 EUCNB-82	1	piece
2CKA002011A3779	Socket Outlets without claw ivory white - Platform 63	20 EUCR-82-503	1	piece
2CKA002013A5437	SCHUKO® socket insert Safety Shutter without claw anthracite - Platform 63	20 EUCRB-81	1	piece
2CKA002013A5438	SCHUKO® socket insert Safety Shutter without claw ivory white - Platform 63	20 EUCRB-82	1	piece
2CKA002018A1486	SCHUKO® socket insert with Hinged Lid anthracite - Platform 63	20 EUK-81	1	piece
2CKA002018A1465	SCHUKO® socket insert with Hinged Lid ivory white - Platform 63	20 EUK-82	1	piece
2CKA002018A1517	SCHUKO® socket insert Safety Shutter with Hinged Lid anthracite - Platform 63	20 EUKB-81	1	piece
2CKA002018A1518	SCHUKO® socket insert Safety Shutter with Hinged Lid ivory white - Platform 63	20 EUKB-82	1	piece
2CKA002018A1526	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw anthracite - Platform 63	20 EUKBR-81	1	piece
2CKA002018A1527	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw ivory white - Platform 63	20 EUKBR-82	1	piece
2CKA002018A1533	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space red - Platform 63	20 EUKNB-12-82	1	piece
2CKA002018A1534	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space green - Platform 63	20 EUKNB-13-82	1	piece
2CKA002018A1535	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space orange - Platform 63	20 EUKNB-14-82	1	piece
2CKA002018A1537	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space anthracite - Platform 63	20 EUKNB-81	1	piece
2CKA002018A1538	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space ivory white - Platform 63	20 EUKNB-82	1	piece
2CKA002018A1544	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space red - Platform 63	20 EUKNBL-12-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002018A1545	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space green - Platform 63	20 EUKNBL-13-82	1	piece
2CKA002018A1546	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space orange - Platform 63	20 EUKNBL-14-82	1	piece
2CKA002018A1548	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space anthracite - Platform 63	20 EUKNBL-81	1	piece
2CKA002018A1549	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space ivory white - Platform 63	20 EUKNBL-82	1	piece
2CKA002018A1557	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Different Locking with label space anthracite - Platform 63	20 EUKNBSL-81	1	piece
2CKA002018A1558	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space anthracite - Platform 63	20 EUKNBSL-81-101	1	piece
2CKA002018A1559	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Different Locking with label space ivory white - Platform 63	20 EUKNBSL-82	1	piece
2CKA002018A1560	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space ivory white - Platform 63	20 EUKNBSL-82-101	1	piece
2CKA002011A3802	SCHUKO® Socket insert with labelling field with label space anthracite - Platform 63	20 EUN-81	1	piece
2CKA002011A3726	SCHUKO® Socket insert with labelling field with label space ivory white - Platform 63	20 EUN-82	1	piece
2CKA002011A6290	Socket Outlets Safety Shutter with USB A/A anthracite - Platform 63	20 MUCB2USB-81-500	1	piece
2CKA002017A1903	Socket Safety Shutter with USB A/A anthracite - Platform 63	20 MUCB2USB-81-500	1	piece
2CKA002017A1889	Socket Safety Shutter with USB A/A ivory white - Platform 63	20 MUCB2USB-82-500	1	piece
2CKA002017A1913	Socket Safety Shutter with USB A/C anthracite - Platform 63	20 MUCB2USBAC-81-500	1	piece
2CKA002017A1914	Socket Safety Shutter with USB A/C ivory white - Platform 63	20 MUCB2USBAC-82-500	1	piece
2CKA002017A0893	Socket Outlets Safety Shutter with USB A anthracite - Platform 63	20 MUCBUSB-81-500	1	piece
2CKA002017A0875	Socket Outlets Safety Shutter with USB A ivory white - Platform 63	20 MUCBUSB-82-500	1	piece
2CKA002014A1467	Socket Outlets ivory white - future linear	20-2 EUCJ-182K-503	1	piece
2CKA001751A3167	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P 1NO anthracite - Platform 63	2029 UC-81	1	piece
2CKA001751A3168	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P 1NO ivory white - Platform 63	2029 UC-82	1	piece
2CKA001751A3234	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P anthracite - Platform 63	2029/12 UC-81	1	piece
2CKA001751A3236	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P ivory white - Platform 63	2029/12 UC-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3223	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker anthracite - Platform 63	2058-24-81	1	piece
2CKA001751A3225	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker ivory white - Platform 63	2058-24-82	1	piece
2CKA001751A3243	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker anthracite - Platform 63	2059 UC-81	1	piece
2CKA001751A3245	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker ivory white - Platform 63	2059 UC-82	1	piece
2CKA002495A0084	Equipotential socket insert anthracite - Platform 63	2095 UC-81	1	piece
2CKA002495A0085	Equipotential socket insert ivory white - Platform 63	2095 UC-82	1	piece
2CKA002190A0216	Socket Outlets without claw anthracite - Platform 63	2190 EUC-81	1	piece
2CKA002190A0213	Socket Outlets without claw ivory white - Platform 63	2190 EUC-82	1	piece
2CKA002013A5474	SCHUKO® socket insert Safety Shutter with screw terminals anthracite - Platform 63	23 EUCB-81	1	piece
2CKA002013A5475	SCHUKO® socket insert Safety Shutter with screw terminals ivory white - Platform 63	23 EUCB-82	1	piece
2CKA002013A5448	SCHUKO® socket insert Safety Shutter with screw terminals anthracite - Platform 63	2300 EUCB-81	1	piece
2CKA002013A5449	SCHUKO® socket insert Safety Shutter with screw terminals ivory white - Platform 63	2300 EUCB-82	1	piece
2CKA002113A5339	Socket Outlets Safety Shutter without claw anthracite - Platform 63	2300 UCRKS-81-503	1	piece
2CKA002113A0510	Socket Outlets Safety Shutter without claw ivory white - Platform 63	2300 UCRKS-82-503	1	piece
2CKA002011A6257	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals red - Platform 63	2310 EUGL/VA-12-82-101	1	piece
2CKA002011A3830	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals anthracite - Platform 63	2310 EUGL/VA-81-11	1	piece
2CKA002011A3831	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals ivory white - Platform 63	2310 EUGL/VA-82-11	1	piece
2CKA002099A0197	Flush Mounted Inserts	2397 UCKS-82-505	1	piece
2CKA002013A5357	Flush Mounted Inserts Safety Shutter with screw terminals anthracite	2398 CKS-81	1	piece
2CKA002013A5359	Flush Mounted Inserts Safety Shutter with screw terminals ivory white	2398 CKS-82	1	piece
2CKA002099A0216	Socket Outlets Safety Shutter anthracite - Platform 63	2399 UCKS-81	1	piece
2CKA002099A0211	Socket Outlets Safety Shutter ivory white - Platform 63	2399 UCKS-82	1	piece
2CKA002099A0191	Socket Outlets Safety Shutter ivory white - Platform 63	2399 UCKS-82-505	1	piece
2CKA001719A0217	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring anthracite - Platform 63	2518-WD-81	1	piece
2CKA001719A0218	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring ivory white - Platform 63	2518-WD-82	1	piece
2CKA001751A3176	Rocker with legend Symbol "bell" for Switch/push button, Single rocker anthracite - Platform 63	2520 KI-81	1	piece
2CKA001751A3177	Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory white - Platform 63	2520 KI-82	1	piece
2CKA001751A3186	Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - Platform 63	2520 LI-81	1	piece
2CKA001751A3187	Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - Platform 63	2520 LI-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3196	Rocker with legend Symbol "key" for Switch/push button, Single rocker anthracite - Platform 63	2520 TR-81	1	piece
2CKA001751A3197	Rocker with legend Symbol "key" for Switch/push button, Single rocker ivory white - Platform 63	2520 TR-82	1	piece
2CKA001724A4254	Cover plate Pilot devices 1 gang anthracite - Platform 63	2533-81	1	piece
2CKA001724A4255	Cover plate Pilot devices 1 gang ivory white - Platform 63	2533-82	1	piece
2CKA001724A4382	Cover plate Pilot devices 1 gang yellow - Platform 63	2533-82-15	1	piece
2CKA001710A3644	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button anthracite - Platform 63	2542 DR/01-81	1	piece
2CKA001710A3645	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button ivory white - Platform 63	2542 DR/01-82	1	piece
2CKA001710A3649	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button anthracite - Platform 63	2542 DR/02-81	1	piece
2CKA001710A3650	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button ivory white - Platform 63	2542 DR/02-82	1	piece
2CKA001724A4399	Cover plate XLR 1 gang anthracite - Platform 63	2553-81	1	piece
2CKA001724A4400	Cover plate XLR 1 gang ivory white - Platform 63	2553-82	1	piece
2CKA001753A0317	Cover plate Keystone 2 gang anthracite - Platform 63	2561-02-81	1	piece
2CKA001753A0392	Cover plate Modular Jack 2 gang ivory white - Platform 63	2561-02-82	1	piece
2CKA001753A0400	Cover plate Keystone 1 gang anthracite - Platform 63	2561-81	1	piece
2CKA001753A0401	Cover plate Modular Jack 1 gang ivory white - Platform 63	2561-82	1	piece
2CKA001751A3261	Rocker with Small Transparent Calotte for Electronic push button insert Single rocker anthracite - Platform 63	2570-10-81	1	piece
2CKA001751A3263	Rocker with Small Transparent Calotte for Electronic push button insert Single rocker ivory white - Platform 63	2570-10-82	1	piece
2CKA001751A3272	Rocker with Small Transparent Calotte for Electronic push button insert Two-part rocker anthracite - Platform 63	2570-20-81	1	piece
2CKA001751A3274	Rocker with Small Transparent Calotte for Electronic push button insert Two-part rocker ivory white - Platform 63	2570-20-82	1	piece
2CKA001751A3283	Rocker with Small Transparent Calotte for Electronic push button insert Three-part rocker anthracite - Platform 63	2570-30-81	1	piece
2CKA001751A3285	Rocker with Small Transparent Calotte for Electronic push button insert Three-part rocker ivory white - Platform 63	2570-30-82	1	piece
2CKA001710A3504	Data / Telecommunication / Antenna TAE 1 gang ivory white - Platform 63	2767-82-503	1	piece
2CKA003116A0667	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter anthracite - Platform 63	3120 EUCB-81	1	piece
2CKA003116A0661	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter ivory white - Platform 63	3120 EUCB-82	1	piece
2CKA003117A0009	Buschmat RCD - Insert RCD 16 A 30 mA anthracite - Platform 63	3151 UC-81	1	piece
2CKA003117A0005	Buschmat RCD - Insert RCD 16 A 30 mA ivory white - Platform 63	3151 UC-82	1	piece
2CKA006115A0464	Cover plate Symbols "up, down, menu left, menu right, " 1-gang for Control element 6gang anthracite - Platform 63	6108/61-81	1	piece
2CKA006115A0483	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang anthracite - Platform 63	6108/61-81-500	1	piece
2CKA006115A0465	Coverplate f. CE	6108/61-82	1	piece
2CKA006115A0484	Coverplate f. CE	6108/61-82-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006155A0041	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller anthracite - Platform 63	6109/03-81	1	piece
2CKA006155A0060	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller anthracite - Platform 63	6109/03-81-500	1	piece
2CKA006155A0042	Coverplate f. RTC	6109/03-82	1	piece
2CKA006155A0061	Coverplate f. RTC	6109/03-82-500	1	piece
2CKA006132A0246	Watchdog 180 Standard FM	6122/01-81	1	piece
2CKA006132A0272	Watchdog 180 Standard FM	6122/01-81-500	1	piece
2CKA006132A0247	6122/01-82 Watchdog 180 Standard FM	6122/01-82	1	piece
2CKA006132A0273	6122/01-82-500 Watchdog 180 Standard FM	6122/01-82-500	1	piece
2CKA006132A0259	Busch-Watchdog 180 ° Motion detector Twisted Pair Wiring anthracite	6122/02-81	1	piece
2CKA006132A0283	Presence Detection Twisted Pair Wiring anthracite	6122/02-81-500	1	piece
2CKA006132A0260	Busch-Watchdog 180 ° Motion detector Twisted Pair Wiring ivory white	6122/02-82	1	piece
2CKA006132A0284	Presence Detection Twisted Pair Wiring ivory white	6122/02-82-500	1	piece
2CKA006132A0363	Busch-Watchdog Motion detector Twisted Pair Wiring anthracite	6122/10-81	1	piece
2CKA006132A0376	Busch-Watchdog Motion detector Twisted Pair Wiring anthracite	6122/10-81-500	1	piece
2CKA006132A0364	Busch-Watchdog Motion detector Twisted Pair Wiring ivory white	6122/10-82	1	piece
2CKA006132A0377	Busch-Watchdog Motion detector Twisted Pair Wiring ivory white	6122/10-82-500	1	piece
2CKA006134A0244	Room Thermostat	6124/01-81	1	piece
2CKA006134A0295	Room Thermostat	6124/01-81-500	1	piece
2CKA006134A0245	Room Thermostat	6124/01-82	1	piece
2CKA006134A0274	Room Thermostat	6124/01-82-500	1	piece
2CKA006115A0179	Control Element with Bus Coupler 2gang Twisted Pair Wiring anthracite - Platform 63	6125/01-81	1	piece
2CKA006115A0205	Control Element 2gang Twisted Pair Wiring anthracite - Platform 63	6125/01-81-500	1	piece
2CKA006115A0180	Control Element with Bus Coupler 2gang Twisted Pair Wiring ivory white - Platform 63	6125/01-82	1	piece
2CKA006115A0206	Solo 2gang Twisted Pair Wiring ivory white - Platform 63	6125/01-82-500	1	piece
2CKA006115A0193	Control Element 2gang anthracite - Platform 63	6125/02-81	1	piece
2CKA006115A0216	Surface box 2gang anthracite - Platform 63	6125/02-81-500	1	piece
2CKA006115A0194	Control Element 2gang ivory white - Platform 63	6125/02-82	1	piece
2CKA006115A0217	Solo 2gang ivory white - Platform 63	6125/02-82-500	1	piece
2CKA006115A0164	Switch Sensor 1-fold, FM	6125-81-101	1	piece
2CKA006115A0165	Switch Sensor 1-fold, FM	6125-82-101	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006116A0170	Control Element with Bus Coupler 4gang Twisted Pair Wiring anthracite - Platform 63	6126/01-81	1	piece
2CKA006116A0195	HVAC-Slave-device 4gang Twisted Pair Wiring anthracite - Platform 63	6126/01-81-500	1	piece
2CKA006116A0171	Control Element with Bus Coupler 4gang Twisted Pair Wiring ivory white - Platform 63	6126/01-82	1	piece
2CKA006116A0196	Solo 4gang Twisted Pair Wiring ivory white - Platform 63	6126/01-82-500	1	piece
2CKA006116A0183	Control Element 4gang anthracite - Platform 63	6126/02-81	1	piece
2CKA006116A0206	HVAC-Slave-device 4gang anthracite - Platform 63	6126/02-81-500	1	piece
2CKA006116A0184	Control Element 4gang ivory white - Platform 63	6126/02-82	1	piece
2CKA006116A0207	Solo 4gang ivory white - Platform 63	6126/02-82-500	1	piece
2CKA006116A0154	Switch Sensor 2-fold, FM	6126-81-101	1	piece
2CKA006116A0155	6126-82-101 Switch Sensor 2-fold, FM	6126-82-101	1	piece
2CKA006117A0176	MF-Switch Sensor 4fold, FM	6127 MF-81-101	1	piece
2CKA006117A0177	MF-Switch Sensor 4fold, FM	6127 MF-82-101	1	piece
2CKA006117A0196	Control Element with Bus Coupler 8gang Twisted Pair Wiring anthracite - Platform 63	6127/01-81	1	piece
2CKA006117A0221	HVAC-Slave-device 8gang Twisted Pair Wiring anthracite - Platform 63	6127/01-81-500	1	piece
2CKA006117A0197	Control Element with Bus Coupler 8gang Twisted Pair Wiring ivory white - Platform 63	6127/01-82	1	piece
2CKA006117A0222	Solo 8gang Twisted Pair Wiring ivory white - Platform 63	6127/01-82-500	1	piece
2CKA006117A0209	Control Element 8gang anthracite - Platform 63	6127/02-81	1	piece
2CKA006117A0232	HVAC-device 8gang anthracite - Platform 63	6127/02-81-500	1	piece
2CKA006117A0210	Control Element 8gang ivory white - Platform 63	6127/02-82	1	piece
2CKA006117A0233	Solo 8gang ivory white - Platform 63	6127/02-82-500	1	piece
2CKA006117A0165	Switch Sensor 4-fold, FM	6127-81-101	1	piece
2CKA006117A0166	Switch Sensor 4-fold, FM	6127-82-101	1	piece
2CKA006134A0257	RTC Control element 2/4g	6128/01-81	1	piece
2CKA006134A0284	RTC Control element 2/4g	6128/01-81-500	1	piece
2CKA006134A0258	RTC Control element 2/4g	6128/01-82	1	piece
2CKA006134A0285	6128/01-82-500 RTC Control element 2/4g	6128/01-82-500	1	piece
2CKA006136A0170	Timer w. Display/Switch Sensor	6128/10-82-101	1	piece
2CKA006134A0321	Control Element 4gang anthracite - Platform 63	6128/28-81	1	piece
2CKA006134A0331	HVAC-device 4gang anthracite - Platform 63	6128/28-81-500	1	piece
2CKA006134A0322	Control Element 4gang ivory white - Platform 63	6128/28-82	1	piece
2CKA006134A0332	Solo 4gang ivory white - Platform 63	6128/28-82-500	1	piece
2CKA006134A0208	RoomThermostat/Switch Sensor	6128-81-101	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006134A0209	RoomThermostat/Switch Sensor	6128-82-101	1	piece
2CKA006135A0142	Control Element 3gang anthracite - Platform 63	6129/01-81	1	piece
2CKA006135A0156	Solo 3gang anthracite - Platform 63	6129/01-81-500	1	piece
2CKA006135A0143	Control Element 3gang ivory white - Platform 63	6129/01-82	1	piece
2CKA006135A0157	Solo 3gang ivory white - Platform 63	6129/01-82-500	1	piece
2CKA006135A0128	6129-81-101 IR-Switch Sensor 3fold, FM	6129-81-101	1	piece
2CKA006135A0129	6129-82-101 IR-Switch Sensor 3fold, FM	6129-82-101	1	piece
2CKA006220A0110	Motion detector 1gang Movement sensor 1 channel Twisted Pair Wiring anthracite - Platform 63	6215/1.1-81	1	piece
2CKA006200A0053	WL-Mov. detector/act. 1g	6215/1.1-81-WL	1	piece
2CKA006220A0411	Mov. detector/actuator 1g	6215/1.1-82	1	piece
2CKA006200A0054	WL-Mov. detector/act. 1g	6215/1.1-82-WL	1	piece
2CKA006220A0107	Motion detector Movement sensor 1 channel Twisted Pair Wiring anthracite - Platform 63	6225/1.0-81	1	piece
2CKA006220A0410	Movement detector	6225/1.0-82	1	piece
2CKA006220A0032	Rocker with Small Transparent Calotte 1gang anthracite - Platform 63	6230-10-81	1	piece
2CKA006220A0396	Rocker 1gang ivory white - Platform 63	6230-10-82	1	piece
2CKA006220A0047	Rocker with Small Transparent Calotte 2gang anthracite - Platform 63	6230-20-81	1	piece
2CKA006220A0401	Rocker 2gang ivory white - Platform 63	6230-20-82	1	piece
2CKA006220A0035	Rocker Symbol "light" with Small Transparent Calotte 1gang anthracite - Platform 63	6231-10-81	1	piece
2CKA006220A0397	Rocker Symbol "light" 1gang ivory white - Platform 63	6231-10-82	1	piece
2CKA006220A0050	Rocker Symbol "light" with Small Transparent Calotte 2gang anthracite - Platform 63	6231-21-81	1	piece
2CKA006220A0402	Rocker Symbol "light" 2gang ivory white - Platform 63	6231-21-82	1	piece
2CKA006220A0062	Rocker Symbol "light" with Small Transparent Calotte 2gang anthracite - Platform 63	6231-22-81	1	piece
2CKA006220A0407	Rocker Symbol "light" 2gang ivory white - Platform 63	6231-22-82	1	piece
2CKA006220A0038	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang anthracite - Platform 63	6232-10-81	1	piece
2CKA006220A0398	Rocker Symbol "venetian blind" 1gang ivory white - Platform 63	6232-10-82	1	piece
2CKA006220A0053	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang anthracite - Platform 63	6232-20-81	1	piece
2CKA006220A0403	Rocker Symbol "venetian blind" 2gang ivory white - Platform 63	6232-20-82	1	piece
2CKA006220A0041	Rocker Symbol "scene" with Small Transparent Calotte 1gang anthracite - Platform 63	6233-10-81	1	piece
2CKA006220A0399	Rocker Symbol "scene" 1gang ivory white - Platform 63	6233-10-82	1	piece
2CKA006220A0056	Rocker Symbol "scene" with Small Transparent Calotte 2gang anthracite - Platform 63	6233-21-81	1	piece
2CKA006220A0404	Rocker Symbol "scene" 2gang ivory white - Platform 63	6233-21-82	1	piece
2CKA006220A0068	Rocker Symbol "scene" with Small Transparent Calotte 2gang anthracite - Platform 63	6233-22-81	1	piece
2CKA006220A0408	Rocker Symbol "scene" 2gang ivory white - Platform 63	6233-22-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0044	Rocker Symbol "dimming" with Small Transparent Calotte 1gang anthracite - Platform 63	6234-10-81	1	piece
2CKA006220A0400	Rocker Symbol "dimming" 1gang ivory white - Platform 63	6234-10-82	1	piece
2CKA006220A0059	Rocker Symbol "dimming" with Small Transparent Calotte 2gang anthracite - Platform 63	6234-21-81	1	piece
2CKA006220A0405	Rocker Symbol "dimming" 2gang ivory white - Platform 63	6234-21-82	1	piece
2CKA006220A0253	Rocker Symbol "dimming" with Small Transparent Calotte 2gang anthracite - Platform 63	6234-22-81	1	piece
2CKA006220A0406	Rocker Symbol "dimming" 2gang ivory white - Platform 63	6234-22-82	1	piece
2CKA006220A0074	Cover plate Symbols "up, down, ECO, Power" 2gang anthracite - Platform 63	6235-81	1	piece
2CKA006220A0409	Cover plate Symbols "up, down, ECO, Power" 2gang ivory white - Platform 63	6235-82	1	piece
2CKA006220A0248	Cover plate Symbols "up, down, ECO, menu" 2gang anthracite - Platform 63	6236-81	1	piece
2CKA006220A0412	Cover plate Symbols "up, down, ECO, menu" 2gang ivory white - Platform 63	6236-82	1	piece
2CKA006220A0733	Rocker Symbols "music control" with Small Transparent Calotte 2gang anthracite - Platform 63	6237-21-81	1	piece
2CKA006220A0735	Rocker Symbols "music control" 2gang ivory white - Platform 63	6237-21-82	1	piece
2CKA006220A0734	Rocker Symbols "music control" with Small Transparent Calotte 2gang anthracite - Platform 63	6237-22-81	1	piece
2CKA006220A0736	Rocker Symbols "music control" 2gang ivory white - Platform 63	6237-22-82	1	piece
2CKA006200A0165	Motion detector Movement sensor Wireless anthracite - Platform 63	62762-81-WL	1	piece
2CKA006200A0166	Motion Detectors Movement sensor Wireless anthracite - Platform 63	62762-81-WL-500	1	piece
2CKA006200A0167	Motion detector Movement sensor Wireless ivory white - Platform 63	62762-82-WL	1	piece
2CKA006200A0168	Motion Detectors Movement sensor Wireless ivory white - Platform 63	62762-82-WL-500	1	piece
2CKA006200A0233	Motion detector Enrolment device Wireless anthracite - Platform 63	62764-81-WL	1	piece
2CKA006200A0234	Motion Detectors Enrolment device Wireless anthracite - Platform 63	62764-81-WL-500	1	piece
2CKA006200A0235	Motion detector Enrolment device Wireless ivory white - Platform 63	62764-82-WL	1	piece
2CKA006200A0236	Motion Detectors Enrolment device Wireless ivory white - Platform 63	62764-82-WL-500	1	piece
2CKA006430A0326	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker anthracite - Platform 63	6430-81-102	1	piece
2CKA006430A0327	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker ivory white - Platform 63	6430-82-102	1	piece
2CKA006430A0303	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate anthracite - Platform 63	6435-81	1	piece
2CKA006430A0304	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate ivory white - Platform 63	6435-82	1	piece
2CKA006800A2920	Busch-Watchdog 180 flex Basic sensor with select lens Movement sensor anthracite - Platform 63	64761-81	1	piece
2CKA006800A2921	Busch-Watchdog Electronic Controls Movement sensor anthracite - Platform 63	64761-81-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006800A2922	Busch-Watchdog 180 flex Basic sensor with select lens Movement sensor ivory white - Platform 63	64761-82	1	piece
2CKA006800A2923	Busch-Watchdog Electronic Controls Movement sensor ivory white - Platform 63	64761-82-500	1	piece
2CKA006800A2957	Busch-Watchdog 180 flex Comfort sensor with select lens Movement sensor anthracite - Platform 63	64762-81	1	piece
2CKA006800A2958	Busch-Watchdog Cover plate Movement sensor anthracite - Platform 63	64762-81-500	1	piece
2CKA006800A2959	Busch-Watchdog 180 flex Comfort sensor with select lens Movement sensor ivory white - Platform 63	64762-82	1	piece
2CKA006800A2960	Busch-Watchdog Cover plate Movement sensor ivory white - Platform 63	64762-82-500	1	piece
2CKA006800A2994	Busch-Watchdog 180 flex Multi sensor with select lens Movement sensor anthracite - Platform 63	64764-81	1	piece
2CKA006800A2995	Electronic Controls Movement sensor anthracite - Platform 63	64764-81-500	1	piece
2CKA006800A2996	Busch-Watchdog 180 flex Multi sensor with select lens Movement sensor ivory white - Platform 63	64764-82	1	piece
2CKA006800A2997	Electronic Controls Movement sensor ivory white - Platform 63	64764-82-500	1	piece
2CKA006800A2882	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light anthracite - Platform 63	64765-81	1	piece
2CKA006800A2883	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light anthracite - Platform 63	64765-81-500	1	piece
2CKA006800A2884	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light ivory white - Platform 63	64765-82	1	piece
2CKA006800A2885	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light ivory white - Platform 63	64765-82-500	1	piece
2CKA006470A0007	Cover plate for Proximity switch anthracite - Platform 63	6476-81	1	piece
2CKA006470A0003	Cover plate for Proximity switch ivory white - Platform 63	6476-82	1	piece
2CKA006400A0056	Cover plate PowerDock 1 gang anthracite - Platform 63	6477-81	1	piece
2CKA006400A0057	Cover plate PowerDock 1 gang ivory white - Platform 63	6477-82	1	piece
2CKA006400A0443	Cover plate USB power supply insert 1 gang with USB C anthracite - Platform 63	6479-81	1	piece
2CKA006400A0445	Cover plate USB power supply insert 1 gang with USB C ivory white - Platform 63	6479-82	1	piece
2CKA006599A2950	Cover plate for Dimmer Turn button with Neon lamp anthracite - Platform 63	6540-81-102	1	piece
2CKA006599A2951	Cover plate for Dimmer Turn button with Neon lamp ivory white - Platform 63	6540-82-102	1	piece
2CKA006599A2882	Cover plate for Cooling Central cover plate anthracite - Platform 63	6541-81	1	piece
2CKA006599A2832	Cover plate for Cooling Central cover plate ivory white - Platform 63	6541-82	1	piece
2CKA006599A2881	Control Element for Switch/dimmer Single push button with Neon lamp anthracite - Platform 63	6543-81-101	1	piece
2CKA006599A2831	Control Element for Switch/dimmer Single push button with Neon lamp ivory white - Platform 63	6543-82-101	1	piece
2CKA006599A2906	Control Element for Dimmer Two-part button with Neon lamp anthracite - Platform 63	6545-81	1	piece
2CKA006599A2907	Control Element for Dimmer Two-part button with Neon lamp ivory white - Platform 63	6545-82	1	piece
2CKA006730A0048	WaveLine Wall sensor 1-gang 1 channel Wireless ivory white - Platform 63	6731-82	1	piece
2CKA006730A0032	WaveLine Wall sensor 1 channel Wireless ivory white - Platform 63	6731-82-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006730A0049	WaveLine Wall sensor 2-gang Wireless ivory white - Platform 63	6732-82	1	piece
2CKA006730A0033	WaveLine Wall sensor 2 channel Wireless ivory white - Platform 63	6732-82-500	1	piece
2CKA006730A0050	WaveLine Wall sensor 4-gang Wireless ivory white - Platform 63	6733-82	1	piece
2CKA006730A0034	WaveLine Wall sensor 4 channel Wireless ivory white - Platform 63	6733-82-500	1	piece
2CKA006730A0142	Rocker for Smart switch Single rocker anthracite - Platform 63	6735 BT-81	1	piece
2CKA006730A0143	Rocker for Smart switch Single rocker ivory white - Platform 63	6735 BT-82	1	piece
2CKA006730A0079	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless anthracite - Platform 63	6735/01-81	1	piece
2CKA006730A0080	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless ivory white - Platform 63	6735/01-82	1	piece
2CKA006220A0985	Rocker 1g blinds Symbol "venetian blind" for Smart switch Single rocker anthracite - Platform 63	6735-11-81	1	piece
2CKA006220A0986	Rocker 1g blinds Symbol "venetian blind" for Smart switch Single rocker ivory white - Platform 63	6735-11-82	1	piece
2CKA006730A0067	Control Element 1-gang for Switch/dimmer Wireless anthracite - Platform 63	6735-81	1	piece
2CKA006730A0068	Control Element 1-gang for Switch/dimmer Wireless ivory white - Platform 63	6735-82	1	piece
2CKA006730A0133	Rocker for Smart switch Two-part rocker anthracite - Platform 63	6736 FoH-81	1	piece
2CKA006730A0134	Rocker for Smart switch Two-part rocker ivory white - Platform 63	6736 FoH-82	1	piece
2CKA006730A0083	Wall sensor 2-gang 2 channel Wireless anthracite - Platform 63	6736/01-81	1	piece
2CKA006730A0084	Wall sensor 2-gang 2 channel Wireless ivory white - Platform 63	6736/01-82	1	piece
2CKA006730A0071	Control Element 2-gang for Switch/dimmer Wireless anthracite - Platform 63	6736-81	1	piece
2CKA006730A0072	Control Element 2-gang for Switch/dimmer Wireless ivory white - Platform 63	6736-82	1	piece
2CKA006730A0087	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless anthracite - Platform 63	6737/01-81	1	piece
2CKA006730A0088	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless ivory white - Platform 63	6737/01-82	1	piece
2CKA006730A0075	Control Element 4-gang for Switch/dimmer Wireless anthracite - Platform 63	6737-81	1	piece
2CKA006730A0076	Control Element 4-gang for Switch/dimmer Wireless ivory white - Platform 63	6737-82	1	piece
2CKA006800A2830	Electronic Controls ivory white - Platform 63	6815-82-101-500	1	piece
2CKA008200A0248	Cover plate with legend Busch-Radio Radio anthracite - Platform 63	8252-81-101	1	piece
2CKA008200A0249	Cover plate with legend Radio 0 gang anthracite - Platform 63	8252-81-101-500	1	piece
2CKA008200A0250	Cover plate with legend Busch-Radio Radio ivory white - Platform 63	8252-82-101	1	piece
2CKA008200A0251	Cover plate with legend Radio 0 gang ivory white - Platform 63	8252-82-101-500	1	piece
2CKA008200A0078	Cover plate Loudspeaker anthracite - Platform 63	8253-81	1	piece
2CKA008200A0079	Cover plate Loudspeaker ivory white - Platform 63	8253-82	1	piece
2CKA008200A0227	Cover plate Multimedia 3 gang anthracite - Platform 63	8256-81	1	piece
2CKA008200A0229	Cover plate Multimedia 3 gang ivory white - Platform 63	8256-82	1	piece
2CKA008300A0214	Cover plate, anthracite	83260-81	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA008300A0226	Welcome, anthracite	83260-81-515	1	piece
2CKA006220A0242	User Operation Symbols "up, down, ECO, menu" 1gang anthracite - Platform 63	CP-FCC-81	1	piece
2CKA006220A0532	C-plate Fan Coil	CP-FCC-82	1	piece
2CKA006220A0179	User Operation Symbols "up, down, ECO, Power" 1gang anthracite - Platform 63	CP-RTC-81	1	piece
2CKA006220A0529	C-plate RT sensor unit	CP-RTC-82	1	piece
2CKA006199A0207	Cover plate with legend Symbol "arrows" anthracite - Platform 63	LFAW/A.1.63.11 1-81	1	piece
2CKA006199A0208	Cover plate Symbol "arrows" ivory white - Platform 63	LFAW/A.1.63.11 1-82	1	piece
2CKA006199A0279	Cover plate Symbol "arrows" anthracite - Platform 63	LFAW/A.1.63.1-81	1	piece
2CKA006199A0280	Cover plate Symbol "arrows" ivory white - Platform 63	LFAW/A.1.63.1-82	1	piece
2CKA006199A0247	Cover plate Symbol "arrows" anthracite - Platform 63	LFAW/A.2.63.11 1-81	1	piece
2CKA006199A0248	Cover plate Symbol "arrows" ivory white - Platform 63	LFAW/A.2.63.11 1-82	1	piece
2CKA006199A0319	Cover plate Symbol "arrows" anthracite - Platform 63	LFAW/A.2.63.1-81	1	piece
2CKA006199A0320	Cover plate Symbol "arrows" ivory white - Platform 63	LFAW/A.2.63.1-82	1	piece
2CKA006199A0074	Cover plate Symbol "light" anthracite - Platform 63	LFBT/A.1.63.11-81	1	piece
2CKA006199A0075	Cover plate Symbol "light" ivory white - Platform 63	LFBT/A.1.63.11-82	1	piece
2CKA006199A0134	Cover plate Symbol "light" anthracite - Platform 63	LFBT/A.1.63.1-81	1	piece
2CKA006199A0135	Cover plate Symbol "light" ivory white - Platform 63	LFBT/A.1.63.1-82	1	piece
2CKA006199A0215	Cover plate Symbol "light" anthracite - Platform 63	LFBT/A.2.63.11-81	1	piece
2CKA006199A0216	Cover plate Symbol "light" ivory white - Platform 63	LFBT/A.2.63.11-82	1	piece
2CKA006199A0287	Cover plate Symbol "light" anthracite - Platform 63	LFBT/A.2.63.1-81	1	piece
2CKA006199A0288	Cover plate Symbol "light" ivory white - Platform 63	LFBT/A.2.63.1-82	1	piece
2CKA006199A0191	Cover plate Symbol "dimming" anthracite - Platform 63	LFDW/A.1.63.11 1-81	1	piece
2CKA006199A0192	Cover plate Symbol "dimming" ivory white - Platform 63	LFDW/A.1.63.11 1-82	1	piece
2CKA006199A0263	Cover plate Symbol "dimming" anthracite - Platform 63	LFDW/A.1.63.1-81	1	piece
2CKA006199A0264	Cover plate Symbol "dimming" ivory white - Platform 63	LFDW/A.1.63.1-82	1	piece
2CKA006199A0239	Cover plate Symbol "arrows/venetian blind" and "dimmer" anthracite - Platform 63	LFDW/A.2.63.1 1-81	1	piece
2CKA006199A0240	Cover plate Symbol "arrows/venetian blind" and "dimmer" ivory white - Platform 63	LFDW/A.2.63.1 1-82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0311	Cover plate Symbol "arrows/venetian blind" and "dimmer" anthracite - Platform 63	LFDW/A.2.63.1- 81	1	piece
2CKA006199A0312	Cover plate Symbol "dimming" ivory white - Platform 63	LFDW/A.2.63.1- 82	1	piece
2CKA006199A0082	Cover plate Symbol "venetian blind" anthracite - Platform 63	LFJT/A.1.63.11- 81	1	piece
2CKA006199A0083	Cover plate Symbol "venetian blind" ivory white - Platform 63	LFJT/A.1.63.11- 82	1	piece
2CKA006199A0143	Cover plate Symbol "venetian blind" anthracite - Platform 63	LFJT/A.1.63.1- 81	1	piece
2CKA006199A0144	Cover plate Symbol "venetian blind" ivory white - Platform 63	LFJT/A.1.63.1- 82	1	piece
2CKA006199A0223	Cover plate Symbol "venetian blind" anthracite - Platform 63	LFJT/A.2.63.11- 81	1	piece
2CKA006199A0224	Cover plate Symbol "venetian blind" ivory white - Platform 63	LFJT/A.2.63.11- 82	1	piece
2CKA006199A0295	Cover plate Symbol "venetian blind" anthracite - Platform 63	LFJT/A.2.63.1- 81	1	piece
2CKA006199A0296	Cover plate Symbol "venetian blind" ivory white - Platform 63	LFJT/A.2.63.1- 82	1	piece
2CKA006199A0199	Cover plate Symbol "venetian blind" anthracite - Platform 63	LFJW/A.1.63.11- 81	1	piece
2CKA006199A0200	Cover plate Symbol "venetian blind" ivory white - Platform 63	LFJW/A.1.63.11- 82	1	piece
2CKA006199A0271	Cover plate Symbol "venetian blind" anthracite - Platform 63	LFJW/A.1.63.1- 81	1	piece
2CKA006199A0272	Cover plate Symbol "venetian blind" ivory white - Platform 63	LFJW/A.1.63.1- 82	1	piece
2CKA006199A0255	Cover plate Symbols "music control" anthracite - Platform 63	LFMW/A.4.63.1 1-81	1	piece
2CKA006199A0256	Cover plate Symbols "music control" ivory white - Platform 63	LFMW/A.4.63.1 1-82	1	piece
2CKA006199A0327	Cover plate Symbols "music control" anthracite - Platform 63	LFMW/A.4.63.1 1-81	1	piece
2CKA006199A0328	Cover plate Symbols "music control" ivory white - Platform 63	LFMW/A.4.63.1 1-82	1	piece
2CKA006199A0090	Cover plate Symbol "scene" anthracite - Platform 63	LFST/A.1.63.11- 81	1	piece
2CKA006199A0091	Cover plate Symbol "scene" ivory white - Platform 63	LFST/A.1.63.11- 82	1	piece
2CKA006199A0152	Cover plate Symbol "scene" anthracite - Platform 63	LFST/A.1.63.1- 81	1	piece
2CKA006199A0153	Cover plate Symbol "scene" ivory white - Platform 63	LFST/A.1.63.1- 82	1	piece
2CKA006199A0231	Cover plate Symbol "scene" anthracite - Platform 63	LFST/A.2.63.11- 81	1	piece
2CKA006199A0232	Cover plate Symbol "scene" ivory white - Platform 63	LFST/A.2.63.11- 82	1	piece
2CKA006199A0303	Cover plate Symbol "scene" anthracite - Platform 63	LFST/A.2.63.1- 81	1	piece
2CKA006199A0304	Cover plate Symbol "scene" ivory white - Platform 63	LFST/A.2.63.1- 82	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0042	Cover plate anthracite - Platform 63	LFW/A.1.63.11-81	1	piece
2CKA006199A0043	Cover plate ivory white - Platform 63	LFW/A.1.63.11-82	1	piece
2CKA006199A0098	Cover plate anthracite - Platform 63	LFW/A.1.63.1-81	1	piece
2CKA006199A0099	Cover plate ivory white - Platform 63	LFW/A.1.63.1-82	1	piece
2CKA006199A0050	Cover plate anthracite - Platform 63	LFW/A.2.63.11-81	1	piece
2CKA006199A0051	Cover plate ivory white - Platform 63	LFW/A.2.63.11-82	1	piece
2CKA006199A0107	Cover plate anthracite - Platform 63	LFW/A.2.63.1-81	1	piece
2CKA006199A0108	Cover plate ivory white - Platform 63	LFW/A.2.63.1-82	1	piece
2CKA006199A0058	Cover plate anthracite - Platform 63	LFW/A.3.63.11-81	1	piece
2CKA006199A0059	Cover plate ivory white - Platform 63	LFW/A.3.63.11-82	1	piece
2CKA006199A0116	Cover plate anthracite - Platform 63	LFW/A.3.63.1-81	1	piece
2CKA006199A0117	Cover plate ivory white - Platform 63	LFW/A.3.63.1-82	1	piece
2CKA006199A0066	Cover plate anthracite - Platform 63	LFW/A.4.63.11-81	1	piece
2CKA006199A0067	Cover plate ivory white - Platform 63	LFW/A.4.63.11-82	1	piece
2CKA006199A0125	Cover plate anthracite - Platform 63	LFW/A.4.63.1-81	1	piece
2CKA006199A0126	Cover plate ivory white - Platform 63	LFW/A.4.63.1-82	1	piece
2CKA006220A0212	Motion Detectors Movement sensor Twisted Pair Wiring anthracite - Platform 63	MD-F-1.0.1-81	1	piece
2CKA006220A0530	Movement detector	MD-F-1.0.1-82	1	piece
2CKA006220A0215	Motion Detectors 1gang Movement sensor 1 channel Twisted Pair Wiring anthracite - Platform 63	MSA-F-1.1.1-81	1	piece
2CKA006200A0083	WL-Mov. detector/act. 1g	MSA-F-1.1.1-81-WL	1	piece
2CKA006220A0531	Mov. detector/actuator 1g	MSA-F-1.1.1-82	1	piece
2CKA006200A0084	WL-Mov. detector/act. 1g	MSA-F-1.1.1-82-WL	1	piece
2CKA006220A0137	Rocker with Small Transparent Calotte 1gang anthracite - Platform 63	SR-1-81	1	piece
2CKA006220A0516	Rocker 1gang ivory white - Platform 63	SR-1-82	1	piece
2CKA006220A0152	Rocker with Small Transparent Calotte 2gang anthracite - Platform 63	SR-2-81	1	piece
2CKA006220A0521	Rocker 2gang ivory white - Platform 63	SR-2-82	1	piece
2CKA006220A0143	Rocker with Small Transparent Calotte 1gang anthracite - Platform 63	SRB-1-81	1	piece
2CKA006220A0518	Rocker 1gang ivory white - Platform 63	SRB-1-82	1	piece
2CKA006220A0158	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang anthracite - Platform 63	SRB-2-81	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0523	Rocker Symbol "venetian blind" 2gang ivory white - Platform 63	SRB-2-82	1	piece
2CKA006220A0149	Rocker Symbol "dimming" with Small Transparent Calotte 1gang anthracite - Platform 63	SRD-1-81	1	piece
2CKA006220A0520	Rocker Symbol "dimming" 1gang ivory white - Platform 63	SRD-1-82	1	piece
2CKA006220A0164	Rocker Symbol "dimming" with Small Transparent Calotte 2gang anthracite - Platform 63	SRD-2-L-81	1	piece
2CKA006220A0525	Rocker Symbol "dimming" 2gang ivory white - Platform 63	SRD-2-L-82	1	piece
2CKA006220A0258	Rocker Symbol "dimming" with Small Transparent Calotte 2gang anthracite - Platform 63	SRD-2-R-81	1	piece
2CKA006220A0526	Rocker Symbol "dimming" 2gang ivory white - Platform 63	SRD-2-R-82	1	piece
2CKA006220A0140	Rocker Symbol "light" with Small Transparent Calotte 1gang anthracite - Platform 63	SRL-1-81	1	piece
2CKA006220A0517	Rocker Symbol "light" 1gang ivory white - Platform 63	SRL-1-82	1	piece
2CKA006220A0155	Rocker Symbol "light" with Small Transparent Calotte 2gang anthracite - Platform 63	SRL-2-L-81	1	piece
2CKA006220A0522	Rocker Symbol "light" 2gang ivory white - Platform 63	SRL-2-L-82	1	piece
2CKA006220A0167	Rocker Symbol "light" with Small Transparent Calotte 2gang anthracite - Platform 63	SRL-2-R-81	1	piece
2CKA006220A0527	Rocker Symbol "light" 2gang ivory white - Platform 63	SRL-2-R-82	1	piece
2CKA006220A0146	Rocker Symbol "scene" with Small Transparent Calotte 1gang anthracite - Platform 63	SRS-1-81	1	piece
2CKA006220A0519	Rocker Symbol "scene" 1gang ivory white - Platform 63	SRS-1-82	1	piece
2CKA006220A0161	Rocker Symbol "scene" with Small Transparent Calotte 2gang anthracite - Platform 63	SRS-2-L-81	1	piece
2CKA006220A0524	Rocker Symbol "scene" 2gang ivory white - Platform 63	SRS-2-L-82	1	piece
2CKA006220A0173	Rocker Symbol "scene" with Small Transparent Calotte 2gang anthracite - Platform 63	SRS-2-R-81	1	piece
2CKA006220A0528	Rocker Symbol "scene" 2gang ivory white - Platform 63	SRS-2-R-82	1	piece
2CKA001731A1950	Cover Busch-Infolicht® aluminium silver - Platform 63	1716-83	1	piece
2CKA001731A1978	Cover Busch-Infolicht® studio white matt - Platform 63	1716-884	1	piece
2CKA001731A1980	Cover Busch-Infolicht® black matt - Platform 63	1716-885	1	piece
2CKA001731A1949	Rocker open for red pull button calotte, Pull cord aluminium silver - Platform 63	1720-83	1	piece
2CKA001731A1979	Rocker open for red pull button calotte, Pull cord studio white matt - Platform 63	1720-884	1	piece
2CKA001731A1981	Rocker open for red pull button calotte, Pull cord black matt - Platform 63	1720-885	1	piece
2CKA001710A3811	Cover plate with legend Loudspeaker Turn button aluminium silver - Platform 63	1740 DR/03-83	1	piece
2CKA001710A3870	Cover plate with legend Loudspeaker Turn button studio white matt - Platform 63	1740 DR/03-884	1	piece
2CKA001710A3892	Cover plate with legend Loudspeaker Turn button black matt - Platform 63	1740 DR/03-885	1	piece
2CKA001710A4123	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button aluminium silver - Platform 63	1740 DRL-83-503	1	piece
2CKA001710A3871	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button studio white matt - Platform 63	1740 DRL-884-503	1	piece
2CKA001710A3893	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button black matt - Platform 63	1740 DRL-885-503	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3661	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button aluminium silver - Platform 63	1740-83	1	piece
2CKA001710A3872	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white matt - Platform 63	1740-884	1	piece
2CKA001710A3894	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button black matt - Platform 63	1740-885	1	piece
2CKA001710A3664	Cover plate for Blind cap 1-gang with Mounting plate aluminium silver - Platform 63	1742-83	1	piece
2CKA001710A3873	Cover plate for Blind cap 1-gang with Mounting plate studio white matt - Platform 63	1742-884	1	piece
2CKA001710A3895	Cover plate for Blind cap 1-gang with Mounting plate black matt - Platform 63	1742-885	1	piece
2CKA001724A4367	Cover plate SAT 4 gang aluminium silver - Platform 63	1743/10-04-83	1	piece
2CKA001724A4370	Cover plate SAT 4 gang studio white matt - Platform 63	1743/10-04-884	1	piece
2CKA001724A4371	Cover plate SAT 4 gang black matt - Platform 63	1743/10-04-885	1	piece
2CKA001724A4376	Cover plate SAT 4 gang aluminium silver - Platform 63	1743-04-83	1	piece
2CKA001724A4379	Cover plate SAT 4 gang studio white matt - Platform 63	1743-04-884	1	piece
2CKA001724A4380	Cover plate SAT 4 gang black matt - Platform 63	1743-04-885	1	piece
2CKA001724A4262	Cover plate SAT 3 gang aluminium silver - Platform 63	1743-83	1	piece
2CKA001724A4293	Cover plate SAT 3 gang studio white matt - Platform 63	1743-884	1	piece
2CKA001724A4298	Cover plate SAT 3 gang black matt - Platform 63	1743-885	1	piece
2CKA001710A3675	Cover plate telephone connector boxes (VDo) aluminium silver - Platform 63	1745-83	1	piece
2CKA001710A3874	Cover plate telephone connector boxes (VDo) studio white matt - Platform 63	1745-884	1	piece
2CKA001710A3896	Cover plate telephone connector boxes (VDo) black matt - Platform 63	1745-885	1	piece
2CKA001710A3677	Cover plate 50x50 mm for data connection housing aluminium silver - Platform 63	1746/10-83	1	piece
2CKA001710A3875	Cover plate 50x50 mm for data connection housing studio white matt - Platform 63	1746/10-884	1	piece
2CKA001710A3897	Cover plate 50x50 mm for data connection housing black matt - Platform 63	1746/10-885	1	piece
2CKA001710A3678	Cover plate 50x50 mm with Hinged Lid for data connection housing aluminium silver - Platform 63	1746-83	1	piece
2CKA001710A3876	Cover plate 50x50 mm with Hinged Lid for data connection housing studio white matt - Platform 63	1746-884	1	piece
2CKA001710A3898	Cover plate 50x50 mm with Hinged Lid for data connection housing black matt - Platform 63	1746-885	1	piece
2CKA001710A4095	Intermediate Ring for cover plates Busch-Balance® SI 1-gang aluminium silver - Platform 63	1747 BSI-83	1	piece
2CKA001710A4098	Intermediate Ring for cover plates Busch-Balance® SI 1-gang studio white matt - Platform 63	1747 BSI-884	1	piece
2CKA001710A4099	Intermediate Ring for cover plates Busch-Balance® SI 1-gang black matt - Platform 63	1747 BSI-885	1	piece
2CKA001710A3673	Cover plate Data connection 2 gang aluminium silver - Platform 63	1748-83	1	piece
2CKA001710A3877	Cover plate Data connection 2 gang studio white matt - Platform 63	1748-884	1	piece
2CKA001710A3899	Cover plate Data connection 2 gang black matt - Platform 63	1748-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3665	Cover plate for Cable outlet 1-gang with Mounting plate aluminium silver - Platform 63	1749-83	1	piece
2CKA001710A3878	Cover plate for Cable outlet 1-gang with Mounting plate studio white matt - Platform 63	1749-884	1	piece
2CKA001710A3900	Cover plate for Cable outlet 1-gang with Mounting plate black matt - Platform 63	1749-885	1	piece
2CKA001710A3679	Cover plate BNC/TNC 2 gang aluminium silver - Platform 63	1750-83	1	piece
2CKA001710A3879	Cover plate BNC/TNC 2 gang studio white matt - Platform 63	1750-884	1	piece
2CKA001710A3901	Cover plate BNC/TNC 2 gang black matt - Platform 63	1750-885	1	piece
2CKA001723A0254	Cover plate Loudspeaker 2 gang aluminium silver - Platform 63	1751-83	1	piece
2CKA001723A0260	Cover plate Loudspeaker 2 gang studio white matt - Platform 63	1751-884	1	piece
2CKA001723A0259	Cover plate Loudspeaker 2 gang black matt - Platform 63	1751-885	1	piece
2CKA001710A3662	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key aluminium silver - Platform 63	1755 SL/PZ-83-101	1	piece
2CKA001710A3925	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white matt - Platform 63	1755 SL/PZ-884-101	1	piece
2CKA001710A3902	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key black matt - Platform 63	1755 SL/PZ-885-101	1	piece
2CKA001753A0091	Cover plate Busch-Infolicht® aluminium silver - Platform 63	1756-83	1	piece
2CKA001753A0251	Cover plate Busch-Infolicht® studio white matt - Platform 63	1756-884	1	piece
2CKA001753A0252	Cover plate Busch-Infolicht® black matt - Platform 63	1756-885	1	piece
2CKA001724A4263	Cover plate with labelling field for data connection housing aluminium silver - Platform 63	1758-83	1	piece
2CKA001724A4307	Cover plate with labelling field for data connection housing studio white matt - Platform 63	1758-884	1	piece
2CKA001724A4299	Cover plate with labelling field for data connection housing black matt - Platform 63	1758-885	1	piece
2CKA001710A4105	Data / Telecommunication / Antenna TDO aluminium silver - Platform 63	1762-83-506	1	piece
2CKA001710A4108	Data / Telecommunication / Antenna TDO studio white matt - Platform 63	1762-884-506	1	piece
2CKA001710A4109	Data / Telecommunication / Antenna TDO black matt - Platform 63	1762-885-506	1	piece
2CKA001731A4000	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker aluminium silver - Platform 63	1764 NLI/KI-83	1	piece
2CKA001731A4004	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker studio white matt - Platform 63	1764 NLI/KI-884	1	piece
2CKA001731A4005	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker black matt - Platform 63	1764 NLI/KI-885	1	piece
2CKA001731A1948	Rocker with labelling field for Switch/push button, Single rocker aluminium silver - Platform 63	1764 NLI-83	1	piece
2CKA001731A1985	Rocker with labelling field for Switch/push button, Single rocker studio white matt - Platform 63	1764 NLI-884	1	piece
2CKA001731A1982	Rocker with labelling field for Switch/push button, Single rocker black matt - Platform 63	1764 NLI-885	1	piece
2CKA001710A3659	Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang aluminium silver - Platform 63	1766-83	1	piece
2CKA001710A3926	Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang studio white matt - Platform 63	1766-884	1	piece
2CKA001710A3903	Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang black matt - Platform 63	1766-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001753A0257	Cover plate with legend 0 ... 15 Min for Time switch, Turning handle aluminium silver - Platform 63	1770-83-103	1	piece
2CKA001753A0260	Cover plate with legend 0 ... 15 Min for Time switch, Turning handle studio white matt - Platform 63	1770-884-103	1	piece
2CKA001753A0261	Cover plate with legend 0 ... 15 Min for Time switch, Turning handle black matt - Platform 63	1770-885-103	1	piece
2CKA001753A0267	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle aluminium silver - Platform 63	1771-83-103	1	piece
2CKA001753A0303	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle studio white matt - Platform 63	1771-884-103	1	piece
2CKA001753A0304	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle black matt - Platform 63	1771-885-103	1	piece
2CKA001751A2979	Multimedia Devices aluminium silver	1785 ENO-83	1	piece
2CKA001751A3097	Rocker with legend Symbol "arrows" 4gang for KNX push-button coupling unit Two-part rocker aluminium silver - Platform 63	1785 JA/02-83	1	piece
2CKA001751A3103	Rocker with legend Symbol "arrows" 4gang for KNX push-button coupling unit Two-part rocker studio white matt - Platform 63	1785 JA/02-884	1	piece
2CKA001751A3105	Rocker with legend Symbol "arrows" 4gang for KNX push-button coupling unit Two-part rocker black matt - Platform 63	1785 JA/02-885	1	piece
2CKA001751A2944	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker aluminium silver - Platform 63	1785 JA-83	1	piece
2CKA001751A3022	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - Platform 63	1785 JA-884	1	piece
2CKA001751A3036	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - Platform 63	1785 JA-885	1	piece
2CKA001751A3125	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785 K-83	1	piece
2CKA001751A3126	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785 K-83-500	1	piece
2CKA001751A3134	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker studio white matt - Platform 63	1785 K-884	1	piece
2CKA001751A3135	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker studio white matt - Platform 63	1785 K-884-500	1	piece
2CKA001751A3136	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker black matt - Platform 63	1785 K-885	1	piece
2CKA001751A3137	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker black matt - Platform 63	1785 K-885-500	1	piece
2CKA001751A3210	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker aluminium silver - Platform 63	1785/11 K-83	1	piece
2CKA001751A3211	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker studio white matt - Platform 63	1785/11 K-884	1	piece
2CKA001751A3213	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker black matt - Platform 63	1785/11 K-885	1	piece
2CKA001751A2995	Rocker with legend DND, MUR for Switch/push button, Two-part rocker aluminium silver - Platform 63	1785/11-83	1	piece
2CKA001751A3023	Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white matt - Platform 63	1785/11-884	1	piece
2CKA001751A3037	Rocker with legend DND, MUR for Switch/push button, Two-part rocker black matt - Platform 63	1785/11-885	1	piece
2CKA001751A2967	Multimedia Devices aluminium silver	1786 ENO-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3096	Rocker with legend Symbol "arrows" for KNX push-button coupling unit Single rocker aluminium silver - Platform 63	1786 JA/02-83	1	piece
2CKA001751A3102	Rocker with legend Symbol "arrows" for KNX push-button coupling unit Single rocker studio white matt - Platform 63	1786 JA/02-884	1	piece
2CKA001751A3104	Rocker with legend Symbol "arrows" for KNX push-button coupling unit Single rocker black matt - Platform 63	1786 JA/02-885	1	piece
2CKA001751A3001	Rocker with legend DND for Switch/push button, Single rocker aluminium silver - Platform 63	1786/11-83	1	piece
2CKA001751A3026	Rocker with legend DND for Switch/push button, Single rocker studio white matt - Platform 63	1786/11-884	1	piece
2CKA001751A3040	Rocker with legend DND for Switch/push button, Single rocker black matt - Platform 63	1786/11-885	1	piece
2CKA001751A2954	Rocker with legend Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1788-83	1	piece
2CKA001751A3028	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1788-884	1	piece
2CKA001751A3042	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1788-885	1	piece
2CKA001751A2955	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 H-83	1	piece
2CKA001751A3029	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 H-884	1	piece
2CKA001751A3043	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 H-885	1	piece
2CKA001751A2952	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 KI-83	1	piece
2CKA001751A3030	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 KI-884	1	piece
2CKA001751A3044	Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 KI-885	1	piece
2CKA001751A2951	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 LI-83	1	piece
2CKA001751A3031	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 LI-884	1	piece
2CKA001751A3045	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 LI-885	1	piece
2CKA001751A3149	Rocker with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 N-83	1	piece
2CKA001751A3153	Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 N-884	1	piece
2CKA001751A3154	Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 N-885	1	piece
2CKA001751A3159	Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 ST-83	1	piece
2CKA001751A3163	Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 ST-884	1	piece
2CKA001751A3164	Rocker with legend Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 ST-885	1	piece
2CKA001751A2953	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 TR-83	1	piece
2CKA001751A3032	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 TR-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3046	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 TR-885	1	piece
2CKA001751A2945	Rocker with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789-83	1	piece
2CKA001751A3033	Rocker with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789-884	1	piece
2CKA001751A3047	Rocker with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1789-885	1	piece
2CKA001710A4128	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card aluminium silver - Platform 63	1792 RFID-83	1	piece
2CKA001710A4129	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card studio white matt - Platform 63	1792 RFID-884	1	piece
2CKA001710A4131	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card black matt - Platform 63	1792 RFID-885	1	piece
2CKA001710A3670	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card aluminium silver - Platform 63	1792-83	1	piece
2CKA001710A3928	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card studio white matt - Platform 63	1792-884	1	piece
2CKA001710A3905	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card black matt - Platform 63	1792-885	1	piece
2CKA006430A0419	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate aluminium silver - Platform 63	1794 MDRT-83	1	piece
2CKA006430A0423	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate studio white matt - Platform 63	1794 MDRT-884	1	piece
2CKA006430A0424	Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate black matt - Platform 63	1794 MDRT-885	1	piece
2CKA001710A4200	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1794 R-83	1	piece
2CKA001710A4204	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1794 R-884	1	piece
2CKA001710A4205	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1794 R-885	1	piece
2CKA001710A3697	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1794 TA-83	1	piece
2CKA001710A3883	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1794 TA-884	1	piece
2CKA001710A3906	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1794 TA-885	1	piece
2CKA001710A3668	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1794-83	1	piece
2CKA001710A3884	Cover plate Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1794-884	1	piece
2CKA001710A3907	Cover plate Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1794-885	1	piece
2CKA001710A4016	Cover plate Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1795 HK-83	1	piece
2CKA001710A4019	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1795 HK-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A4020	Cover plate Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1795 HK-885	1	piece
2CKA001710A4048	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1795 HKEA-83	1	piece
2CKA001710A4051	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1795 HKEA-884	1	piece
2CKA001710A4052	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1795 HKEA-885	1	piece
2CKA001710A3724	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1795 TA-83	1	piece
2CKA001710A3885	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1795 TA-884	1	piece
2CKA001710A3908	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1795 TA-885	1	piece
2CKA001710A3669	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - Platform 63	1795-83	1	piece
2CKA001710A3886	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Platform 63	1795-884	1	piece
2CKA001710A3909	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Platform 63	1795-885	1	piece
2CKA001753A0310	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord aluminium silver - Platform 63	1796-83	1	piece
2CKA001753A0313	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord studio white matt - Platform 63	1796-884	1	piece
2CKA001753A0314	Cover plate for Pull-cord switch 2610/6 UC-xx, 2610/6 UJ-xx, Pull cord black matt - Platform 63	1796-885	1	piece
2CKA001710A3676	Cover plate with labelling field Keystone 2 gang aluminium silver - Platform 63	1800-83	1	piece
2CKA001710A3887	Cover plate with labelling field Keystone 2 gang studio white matt - Platform 63	1800-884	1	piece
2CKA001710A3910	Cover plate with labelling field Keystone 2 gang black matt - Platform 63	1800-885	1	piece
2CKA001710A3610	Cover plate with labelling field for data connection housing 2 gang aluminium silver - Platform 63	1803-02-83	1	piece
2CKA001710A3888	Cover plate with labelling field for data connection housing 2 gang studio white matt - Platform 63	1803-02-884	1	piece
2CKA001710A3911	Cover plate with labelling field for data connection housing 2 gang black matt - Platform 63	1803-02-885	1	piece
2CKA001710A3674	Cover plate with labelling field for data connection housing 1 gang aluminium silver - Platform 63	1803-83	1	piece
2CKA001710A3889	Cover plate with labelling field for data connection housing 1 gang studio white matt - Platform 63	1803-884	1	piece
2CKA001710A3912	Cover plate with labelling field for data connection housing 1 gang black matt - Platform 63	1803-885	1	piece
2CKA002013A5406	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	20 EUAB-83	1	piece
2CKA002013A5409	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	20 EUAB-884	1	piece
2CKA002013A5410	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUAB-885	1	piece
2CKA002011A6271	SCHUKO® USB socket insert Safety Shutter with USB A/A aluminium silver - Platform 63	20 EUCB2USB-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002011A6272	Socket insert Safety Shutter with USB A/A aluminium silver - Platform 63	20 EUCB2USB-83-500	1	piece
2CKA002011A6277	SCHUKO® USB socket insert Safety Shutter with USB A/A studio white matt - Platform 63	20 EUCB2USB-884	1	piece
2CKA002011A6278	Socket insert Safety Shutter with USB A/A studio white matt - Platform 63	20 EUCB2USB-884-500	1	piece
2CKA002011A6279	SCHUKO® USB socket insert Safety Shutter with USB A/A black matt - Platform 63	20 EUCB2USB-885	1	piece
2CKA002011A6280	Socket insert Safety Shutter with USB A/A black matt - Platform 63	20 EUCB2USB-885-500	1	piece
2CKA002011A6304	SCHUKO® USB socket insert Safety Shutter with USB A/C aluminium silver - Platform 63	20 EUCB2USBAC-83	1	piece
2CKA002011A6305	Socket insert Safety Shutter with USB A/C aluminium silver - Platform 63	20 EUCB2USBAC-83-500	1	piece
2CKA002011A6310	SCHUKO® USB socket insert Safety Shutter with USB A/C studio white matt - Platform 63	20 EUCB2USBAC-884	1	piece
2CKA002011A6311	Socket insert Safety Shutter with USB A/C studio white matt - Platform 63	20 EUCB2USBAC-884-500	1	piece
2CKA002011A6312	SCHUKO® USB socket insert Safety Shutter with USB A/C black matt - Platform 63	20 EUCB2USBAC-885	1	piece
2CKA002011A6313	Socket insert Safety Shutter with USB A/C black matt - Platform 63	20 EUCB2USBAC-885-500	1	piece
2CKA002013A5417	Busch-Service-Socket SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	20 EUCBDR-83	1	piece
2CKA002013A5420	Busch-Service-Socket SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	20 EUCBDR-884	1	piece
2CKA002013A5421	Busch-Service-Socket SCHUKO® socket insert Safety Shutter black matt - Platform 63	20 EUCBDR-885	1	piece
2CKA002013A5285	SCHUKO® socket insert Safety Shutter with LED Control light /Green aluminium silver - Platform 63	20 EUCBL-83	1	piece
2CKA002013A5336	SCHUKO® socket insert Safety Shutter with LED Control light /Green studio white matt - Platform 63	20 EUCBL-884	1	piece
2CKA002013A5330	SCHUKO® socket insert Safety Shutter with LED Control light /Green black matt - Platform 63	20 EUCBL-885	1	piece
2CKA002013A5293	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White aluminium silver - Platform 63	20 EUCBLI-83	1	piece
2CKA002013A5326	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White studio white matt - Platform 63	20 EUCBLI-884	1	piece
2CKA002013A5331	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White black matt - Platform 63	20 EUCBLI-885	1	piece
2CKA002011A6160	Socket insert Safety Shutter with USB A aluminium silver - Platform 63	20 EUCBUSB-83	1	piece
2CKA002011A6178	Socket Outlets Safety Shutter with USB A aluminium silver - Platform 63	20 EUCBUSB-83-500	1	piece
2CKA002011A6164	Socket insert Safety Shutter with USB A studio white matt - Platform 63	20 EUCBUSB-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002011A6182	Socket Outlets Safety Shutter with USB A studio white matt - Platform 63	20 EUCBUSB-884-500	1	piece
2CKA002011A6165	Socket insert Safety Shutter with USB A black matt - Platform 63	20 EUCBUSB-885	1	piece
2CKA002011A6183	Socket Outlets Safety Shutter with USB A black matt - Platform 63	20 EUCBUSB-885-500	1	piece
2CKA002013A5273	SCHUKO® Socket insert with legend EDV Safety Shutter aluminium silver - Platform 63	20 EUCKS/DV-83	1	piece
2CKA002013A5327	SCHUKO® Socket insert with legend EDV Safety Shutter studio white matt - Platform 63	20 EUCKS/DV-884	1	piece
2CKA002013A5332	SCHUKO® Socket insert with legend EDV Safety Shutter black matt - Platform 63	20 EUCKS/DV-885	1	piece
2CKA002013A5429	SCHUKO® Socket insert with labelling field Safety Shutter with label space aluminium silver - Platform 63	20 EUCNB-83	1	piece
2CKA002013A5433	SCHUKO® Socket insert with labelling field Safety Shutter with label space studio white matt - Platform 63	20 EUCNB-884	1	piece
2CKA002013A5434	SCHUKO® Socket insert with labelling field Safety Shutter with label space black matt - Platform 63	20 EUCNB-885	1	piece
2CKA002011A3895	Socket Outlets without claw studio white matt - Platform 63	20 EUCR-884-503	1	piece
2CKA002013A5439	SCHUKO® socket insert Safety Shutter without claw aluminium silver - Platform 63	20 EUCRB-83	1	piece
2CKA002013A5443	SCHUKO® socket insert Safety Shutter without claw studio white matt - Platform 63	20 EUCRB-884	1	piece
2CKA002013A5444	SCHUKO® socket insert Safety Shutter without claw black matt - Platform 63	20 EUCRB-885	1	piece
2CKA002018A1487	SCHUKO® socket insert with Hinged Lid aluminium silver - Platform 63	20 EUK-83	1	piece
2CKA002018A1494	SCHUKO® socket insert with Hinged Lid studio white matt - Platform 63	20 EUK-884	1	piece
2CKA002018A1495	SCHUKO® socket insert with Hinged Lid black matt - Platform 63	20 EUK-885	1	piece
2CKA002018A1519	SCHUKO® socket insert Safety Shutter with Hinged Lid aluminium silver - Platform 63	20 EUKB-83	1	piece
2CKA002018A1522	SCHUKO® socket insert Safety Shutter with Hinged Lid studio white matt - Platform 63	20 EUKB-884	1	piece
2CKA002018A1523	SCHUKO® socket insert Safety Shutter with Hinged Lid black matt - Platform 63	20 EUKB-885	1	piece
2CKA002018A1528	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw aluminium silver - Platform 63	20 EUKBR-83	1	piece
2CKA002018A1530	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw studio white matt - Platform 63	20 EUKBR-884	1	piece
2CKA002018A1531	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw black matt - Platform 63	20 EUKBR-885	1	piece
2CKA002018A1539	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space aluminium silver - Platform 63	20 EUKNB-83	1	piece
2CKA002018A1541	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space studio white matt - Platform 63	20 EUKNB-884	1	piece
2CKA002018A1542	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid with label space black matt - Platform 63	20 EUKNB-885	1	piece
2CKA002018A1550	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space aluminium silver - Platform 63	20 EUKNBL-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002018A1552	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space studio white matt - Platform 63	20 EUKNBL-884	1	piece
2CKA002018A1553	SCHUKO® Socket insert with labelling field Safety Shutter with LED Control light /Green with Hinged Lid with label space black matt - Platform 63	20 EUKNBL-885	1	piece
2CKA002018A1561	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Different Locking with label space aluminium silver - Platform 63	20 EUKNBSL-83	1	piece
2CKA002018A1562	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space aluminium silver - Platform 63	20 EUKNBSL-83-101	1	piece
2CKA002018A1565	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Different Locking with label space studio white matt - Platform 63	20 EUKNBSL-884	1	piece
2CKA002018A1566	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space studio white matt - Platform 63	20 EUKNBSL-884-101	1	piece
2CKA002018A1567	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Different Locking with label space black matt - Platform 63	20 EUKNBSL-885	1	piece
2CKA002018A1568	SCHUKO® Socket insert with labelling field Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space black matt - Platform 63	20 EUKNBSL-885-101	1	piece
2CKA002011A3810	SCHUKO® Socket insert with labelling field with label space aluminium silver - Platform 63	20 EUN-83	1	piece
2CKA002011A3881	SCHUKO® Socket insert with labelling field with label space studio white matt - Platform 63	20 EUN-884	1	piece
2CKA002011A3884	SCHUKO® Socket insert with labelling field with label space black matt - Platform 63	20 EUN-885	1	piece
2CKA002017A1890	Socket Safety Shutter with USB A/A aluminium silver - Platform 63	20 MUCB2USB-83-500	1	piece
2CKA002017A1893	Socket Safety Shutter with USB A/A studio white matt - Platform 63	20 MUCB2USB-884-500	1	piece
2CKA002017A1894	Socket Safety Shutter with USB A/A black matt - Platform 63	20 MUCB2USB-885-500	1	piece
2CKA002017A1915	Socket Safety Shutter with USB A/C aluminium silver - Platform 63	20 MUCB2USBAC-83-500	1	piece
2CKA002017A1918	Socket Safety Shutter with USB A/C studio white matt - Platform 63	20 MUCB2USBAC-884-500	1	piece
2CKA002017A1919	Socket Safety Shutter with USB A/C black matt - Platform 63	20 MUCB2USBAC-885-500	1	piece
2CKA002017A0894	Socket Outlets Safety Shutter with USB A aluminium silver - Platform 63	20 MUCBUSB-83-500	1	piece
2CKA002017A0896	Socket Outlets Safety Shutter with USB A studio white matt - Platform 63	20 MUCBUSB-884-500	1	piece
2CKA002017A0897	Socket Outlets Safety Shutter with USB A black matt - Platform 63	20 MUCBUSB-885-500	1	piece
2CKA001012A2159	Fan switch Off-and-alternating switch - Busch-axcent	2000/6 UJ/01	1	piece
2CKA001012A2200	Fan switch Off-and-alternating switch - Busch-axcent	2000/6 UJ/02	1	piece
2CKA001012A2201	Fan switch Off-and-alternating switch - Busch-axcent	2000/6 UJ/03	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001012A2203	Fan switch Off-and-alternating switch - Busch-axcent	2000/6 UJ/04	1	piece
2CKA001012A2205	Fan switch Off-and-alternating switch - Busch-axcent	2000/6 UJ/05	1	piece
2CKA001012A2208	Fan switch Off-and-alternating switch - Busch-axcent	2000/6 UJ/09	1	piece
2CKA001751A3169	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P 1NO aluminium silver - Platform 63	2029 UC-83	1	piece
2CKA001751A3172	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P 1NO studio white matt - Platform 63	2029 UC-884	1	piece
2CKA001751A3173	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P 1NO black matt - Platform 63	2029 UC-885	1	piece
2CKA001751A3232	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P aluminium silver - Platform 63	2029/12 UC-83	1	piece
2CKA001751A3233	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P studio white matt - Platform 63	2029/12 UC-884	1	piece
2CKA001751A3235	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P black matt - Platform 63	2029/12 UC-885	1	piece
2CKA001751A3221	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker aluminium silver - Platform 63	2058-24-83	1	piece
2CKA001751A3222	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker studio white matt - Platform 63	2058-24-884	1	piece
2CKA001751A3224	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker black matt - Platform 63	2058-24-885	1	piece
2CKA001751A3241	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker aluminium silver - Platform 63	2059 UC-83	1	piece
2CKA001751A3242	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker studio white matt - Platform 63	2059 UC-884	1	piece
2CKA001751A3244	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker black matt - Platform 63	2059 UC-885	1	piece
2CKA002495A0089	Equipotential socket insert aluminium silver - Platform 63	2095 UC-83	1	piece
2CKA002495A0091	Equipotential socket insert studio white matt - Platform 63	2095 UC-884	1	piece
2CKA002495A0092	Equipotential socket insert black matt - Platform 63	2095 UC-885	1	piece
2CKA002190A0214	Socket Outlets without claw aluminium silver - Platform 63	2190 EUC-83	1	piece
2CKA002190A0218	Socket Outlets without claw studio white matt - Platform 63	2190 EUC-884	1	piece
2CKA002190A0219	Socket Outlets without claw black matt - Platform 63	2190 EUC-885	1	piece
2CKA002013A5476	SCHUKO® socket insert Safety Shutter with screw terminals aluminium silver - Platform 63	23 EUCB-83	1	piece
2CKA002013A5479	SCHUKO® socket insert Safety Shutter with screw terminals studio white matt - Platform 63	23 EUCB-884	1	piece
2CKA002013A5480	SCHUKO® socket insert Safety Shutter with screw terminals black matt - Platform 63	23 EUCB-885	1	piece
2CKA002013A5450	SCHUKO® socket insert Safety Shutter with screw terminals aluminium silver - Platform 63	2300 EUCB-83	1	piece
2CKA002013A5453	SCHUKO® socket insert Safety Shutter with screw terminals studio white matt - Platform 63	2300 EUCB-884	1	piece
2CKA002013A5454	SCHUKO® socket insert Safety Shutter with screw terminals black matt - Platform 63	2300 EUCB-885	1	piece
2CKA002113A5337	Socket Outlets Safety Shutter without claw studio white matt - Platform 63	2300 UCRKS-884-503	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002113A5340	Socket Outlets Safety Shutter without claw black matt - Platform 63	2300 UCRKS-885-503	1	piece
2CKA002011A3832	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals aluminium silver - Platform 63	2310 EUGL/VA-83-11	1	piece
2CKA002011A3882	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals studio white matt - Platform 63	2310EUGL/VA-884-11	1	piece
2CKA002011A3885	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals black matt - Platform 63	2310EUGL/VA-885-11	1	piece
2CKA002013A5360	Flush Mounted Inserts Safety Shutter with screw terminals aluminium silver	2398 CKS-83	1	piece
2CKA002013A5363	Flush Mounted Inserts Safety Shutter with screw terminals studio white matt	2398 CKS-884	1	piece
2CKA002013A5364	Flush Mounted Inserts Safety Shutter with screw terminals black matt	2398 CKS-885	1	piece
2CKA002099A0241	Socket Outlets Safety Shutter aluminium silver - Platform 63	2399 UCKS-83	1	piece
2CKA002099A0255	Socket Outlets Safety Shutter studio white matt - Platform 63	2399 UCKS-884	1	piece
2CKA002099A0256	Socket Outlets Safety Shutter black matt - Platform 63	2399 UCKS-885	1	piece
2CKA001719A0219	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring aluminium silver - Platform 63	2518-WD-83	1	piece
2CKA001719A0222	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring studio white matt - Platform 63	2518-WD-884	1	piece
2CKA001719A0223	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring black matt - Platform 63	2518-WD-885	1	piece
2CKA001751A3178	Rocker with legend Symbol "bell" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 KI-83	1	piece
2CKA001751A3182	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - Platform 63	2520 KI-884	1	piece
2CKA001751A3183	Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - Platform 63	2520 KI-885	1	piece
2CKA001751A3188	Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 LI-83	1	piece
2CKA001751A3192	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - Platform 63	2520 LI-884	1	piece
2CKA001751A3193	Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - Platform 63	2520 LI-885	1	piece
2CKA001751A3198	Rocker with legend Symbol "key" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 TR-83	1	piece
2CKA001751A3201	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - Platform 63	2520 TR-884	1	piece
2CKA001751A3202	Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - Platform 63	2520 TR-885	1	piece
2CKA001724A4261	Cover plate Pilot devices 1 gang aluminium silver - Platform 63	2533-83	1	piece
2CKA001724A4296	Cover plate Pilot devices 1 gang studio white matt - Platform 63	2533-884	1	piece
2CKA001724A4301	Cover plate Pilot devices 1 gang black matt - Platform 63	2533-885	1	piece
2CKA001710A3671	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button aluminium silver - Platform 63	2542 DR/01-83	1	piece
2CKA001710A3890	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white matt - Platform 63	2542 DR/01-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3913	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button black matt - Platform 63	2542 DR/01-885	1	piece
2CKA001710A3672	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button aluminium silver - Platform 63	2542 DR/02-83	1	piece
2CKA001710A3891	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white matt - Platform 63	2542 DR/02-884	1	piece
2CKA001710A3914	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button black matt - Platform 63	2542 DR/02-885	1	piece
2CKA001724A4401	Cover plate XLR 1 gang aluminium silver - Platform 63	2553-83	1	piece
2CKA001724A4404	Cover plate XLR 1 gang studio white matt - Platform 63	2553-884	1	piece
2CKA001724A4405	Cover plate XLR 1 gang black matt - Platform 63	2553-885	1	piece
2CKA001753A0393	Cover plate Keystone 2 gang aluminium silver - Platform 63	2561-02-83	1	piece
2CKA001753A0396	Cover plate Keystone 2 gang studio white matt - Platform 63	2561-02-884	1	piece
2CKA001753A0397	Cover plate Keystone 2 gang black matt - Platform 63	2561-02-885	1	piece
2CKA001753A0402	Cover plate Keystone 1 gang aluminium silver - Platform 63	2561-83	1	piece
2CKA001753A0405	Cover plate Keystone 1 gang studio white matt - Platform 63	2561-884	1	piece
2CKA001753A0406	Cover plate Keystone 1 gang black matt - Platform 63	2561-885	1	piece
2CKA001751A3259	Rocker with Small Transparent Calotte for Electronic push button insert Single rocker aluminium silver - Platform 63	2570-10-83	1	piece
2CKA001751A3260	Rocker with Small Transparent Calotte for Electronic push button insert Single rocker studio white matt - Platform 63	2570-10-884	1	piece
2CKA001751A3262	Rocker with Small Transparent Calotte for Electronic push button insert Single rocker black matt - Platform 63	2570-10-885	1	piece
2CKA001751A3270	Rocker with Small Transparent Calotte for Electronic push button insert Two-part rocker aluminium silver - Platform 63	2570-20-83	1	piece
2CKA001751A3271	Rocker with Small Transparent Calotte for Electronic push button insert Two-part rocker studio white matt - Platform 63	2570-20-884	1	piece
2CKA001751A3273	Rocker with Small Transparent Calotte for Electronic push button insert Two-part rocker black matt - Platform 63	2570-20-885	1	piece
2CKA001751A3281	Rocker with Small Transparent Calotte for Electronic push button insert Three-part rocker aluminium silver - Platform 63	2570-30-83	1	piece
2CKA001751A3282	Rocker with Small Transparent Calotte for Electronic push button insert Three-part rocker studio white matt - Platform 63	2570-30-884	1	piece
2CKA001751A3284	Rocker with Small Transparent Calotte for Electronic push button insert Three-part rocker black matt - Platform 63	2570-30-885	1	piece
2CKA001724A4297	Data / Telecommunication / Antenna RJ11 1 gang studio white matt - Platform 63	2767-884-503	1	piece
2CKA001724A4302	Data / Telecommunication / Antenna RJ11 1 gang black matt - Platform 63	2767-885-503	1	piece
2CKA003116A0668	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter aluminium silver - Platform 63	3120 EUCB-83	1	piece
2CKA003116A0670	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter studio white matt - Platform 63	3120 EUCB-884	1	piece
2CKA003116A0671	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter black matt - Platform 63	3120 EUCB-885	1	piece
2CKA003117A0010	Buschmat RCD - Insert RCD 16 A 30 mA aluminium silver - Platform 63	3151 UC-83	1	piece
2CKA003117A0012	Buschmat RCD - Insert RCD 16 A 30 mA studio white matt - Platform 63	3151 UC-884	1	piece
2CKA003117A0013	Buschmat RCD - Insert RCD 16 A 30 mA black matt - Platform 63	3151 UC-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006115A0466	Cover plate Symbols "up, down, menu left, menu right, " 1-gang for Control element 6gang aluminium silver - Platform 63	6108/61-83	1	piece
2CKA006115A0485	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang aluminium silver - Platform 63	6108/61-83-500	1	piece
2CKA006115A0468	Cover plate Symbols "up, down, menu left, menu right, " 1-gang for Control element 6gang studio white matt - Platform 63	6108/61-884	1	piece
2CKA006115A0487	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang studio white matt - Platform 63	6108/61-884-500	1	piece
2CKA006115A0469	Cover plate Symbols "up, down, menu left, menu right, " 1-gang for Control element 6gang black matt - Platform 63	6108/61-885	1	piece
2CKA006115A0488	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang black matt - Platform 63	6108/61-885-500	1	piece
2CKA006155A0043	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller aluminium silver - Platform 63	6109/03-83	1	piece
2CKA006155A0062	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller aluminium silver - Platform 63	6109/03-83-500	1	piece
2CKA006155A0045	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller studio white matt - Platform 63	6109/03-884	1	piece
2CKA006155A0064	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller studio white matt - Platform 63	6109/03-884-500	1	piece
2CKA006155A0046	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller black matt - Platform 63	6109/03-885	1	piece
2CKA006155A0065	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller black matt - Platform 63	6109/03-885-500	1	piece
2CKA006132A0248	Watchdog 180 Standard FM	6122/01-83	1	piece
2CKA006132A0274	Watchdog 180 Standard FM	6122/01-83-500	1	piece
2CKA006132A0257	Watchdog 180 Standard FM	6122/01-884	1	piece
2CKA006132A0281	Watchdog 180 Standard FM	6122/01-884-500	1	piece
2CKA006132A0258	Watchdog 180 Standard FM	6122/01-885	1	piece
2CKA006132A0282	6122/01-885-500 Watchdog 180 Standard FM	6122/01-885-500	1	piece
2CKA006132A0261	Busch-Watchdog 180 ° Motion detector Twisted Pair Wiring aluminium silver	6122/02-83	1	piece
2CKA006132A0285	Presence Detection Twisted Pair Wiring aluminium silver	6122/02-83-500	1	piece
2CKA006132A0270	Busch-Watchdog 180 ° Motion detector Twisted Pair Wiring studio white matt	6122/02-884	1	piece
2CKA006132A0292	Presence Detection Twisted Pair Wiring studio white matt	6122/02-884-500	1	piece
2CKA006132A0271	Busch-Watchdog 180 ° Motion detector Twisted Pair Wiring black matt	6122/02-885	1	piece
2CKA006132A0293	Presence Detection Twisted Pair Wiring black matt	6122/02-885-500	1	piece
2CKA006132A0365	Busch-Watchdog Motion detector Twisted Pair Wiring aluminium silver	6122/10-83	1	piece
2CKA006132A0378	Busch-Watchdog Motion detector Twisted Pair Wiring aluminium silver	6122/10-83-500	1	piece
2CKA006132A0367	Busch-Watchdog Motion detector Twisted Pair Wiring studio white matt	6122/10-884	1	piece
2CKA006132A0380	Busch-Watchdog Motion detector Twisted Pair Wiring studio white matt	6122/10-884-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006132A0368	Busch-Watchdog Motion detector Twisted Pair Wiring black matt	6122/10-885	1	piece
2CKA006132A0381	Busch-Watchdog Motion detector Twisted Pair Wiring black matt	6122/10-885-500	1	piece
2CKA006134A0246	Room Thermostat	6124/01-83	1	piece
2CKA006134A0275	Room Thermostat	6124/01-83-500	1	piece
2CKA006134A0255	Room Thermostat	6124/01-884	1	piece
2CKA006134A0282	Room Thermostat	6124/01-884-500	1	piece
2CKA006134A0256	Room Thermostat	6124/01-885	1	piece
2CKA006134A0283	Room Thermostat	6124/01-885-500	1	piece
2CKA006134A0221	6124-83-101 Room Thermostat with Display	6124-83-101	1	piece
2CKA006115A0181	Control Element with Bus Coupler 2gang Twisted Pair Wiring aluminium silver - Platform 63	6125/01-83	1	piece
2CKA006115A0207	Solo 2gang Twisted Pair Wiring aluminium silver - Platform 63	6125/01-83-500	1	piece
2CKA006115A0190	Control Element with Bus Coupler 2gang Twisted Pair Wiring studio white matt - Platform 63	6125/01-884	1	piece
2CKA006115A0214	Solo 2gang Twisted Pair Wiring studio white matt - Platform 63	6125/01-884-500	1	piece
2CKA006115A0191	Control Element with Bus Coupler 2gang Twisted Pair Wiring black matt - Platform 63	6125/01-885	1	piece
2CKA006115A0215	Solo 2gang Twisted Pair Wiring black matt - Platform 63	6125/01-885-500	1	piece
2CKA006115A0195	Control Element 2gang aluminium silver - Platform 63	6125/02-83	1	piece
2CKA006115A0218	Labeling Cover 2gang aluminium silver - Platform 63	6125/02-83-500	1	piece
2CKA006115A0203	Control Element 2gang studio white matt - Platform 63	6125/02-884	1	piece
2CKA006115A0226	Solo 2gang studio white matt - Platform 63	6125/02-884-500	1	piece
2CKA006115A0204	Control Element 2gang black matt - Platform 63	6125/02-885	1	piece
2CKA006115A0227	HVAC/CO2-device 2gang black matt - Platform 63	6125/02-885-500	1	piece
2CKA006115A0166	Switch Sensor 1-fold, FM	6125-83-101	1	piece
2CKA006115A0178	Switch Sensor 1-fold, FM	6125-884-101	1	piece
2CKA006116A0172	Control Element with Bus Coupler 4gang Twisted Pair Wiring aluminium silver - Platform 63	6126/01-83	1	piece
2CKA006116A0197	Solo 4gang Twisted Pair Wiring aluminium silver - Platform 63	6126/01-83-500	1	piece
2CKA006116A0181	Control Element with Bus Coupler 4gang Twisted Pair Wiring studio white matt - Platform 63	6126/01-884	1	piece
2CKA006116A0204	Solo 4gang Twisted Pair Wiring studio white matt - Platform 63	6126/01-884-500	1	piece
2CKA006116A0182	Control Element with Bus Coupler 4gang Twisted Pair Wiring black matt - Platform 63	6126/01-885	1	piece
2CKA006116A0205	Solo 4gang Twisted Pair Wiring black matt - Platform 63	6126/01-885-500	1	piece
2CKA006116A0185	Control Element 4gang aluminium silver - Platform 63	6126/02-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006116A0208	HVAC-device 4gang aluminium silver - Platform 63	6126/02-83-500	1	piece
2CKA006116A0193	Control Element 4gang studio white matt - Platform 63	6126/02-884	1	piece
2CKA006116A0216	Solo 4gang studio white matt - Platform 63	6126/02-884-500	1	piece
2CKA006116A0194	Control Element 4gang black matt - Platform 63	6126/02-885	1	piece
2CKA006116A0217	HVAC/CO2-device 4gang black matt - Platform 63	6126/02-885-500	1	piece
2CKA006116A0168	Switch Sensor 2-fold, FM	6126-885-101	1	piece
2CKA006117A0178	MF-Switch Sensor 4fold, FM	6127 MF-83-101	1	piece
2CKA006117A0192	MF-Switch Sensor 4fold, FM	6127 MF-885-101	1	piece
2CKA006117A0198	Control Element with Bus Coupler 8gang Twisted Pair Wiring aluminium silver - Platform 63	6127/01-83	1	piece
2CKA006117A0223	Solo 8gang Twisted Pair Wiring aluminium silver - Platform 63	6127/01-83-500	1	piece
2CKA006117A0207	Control Element with Bus Coupler 8gang Twisted Pair Wiring studio white matt - Platform 63	6127/01-884	1	piece
2CKA006117A0230	Solo 8gang Twisted Pair Wiring studio white matt - Platform 63	6127/01-884-500	1	piece
2CKA006117A0208	Control Element with Bus Coupler 8gang Twisted Pair Wiring black matt - Platform 63	6127/01-885	1	piece
2CKA006117A0231	Solo 8gang Twisted Pair Wiring black matt - Platform 63	6127/01-885-500	1	piece
2CKA006117A0211	Control Element 8gang aluminium silver - Platform 63	6127/02-83	1	piece
2CKA006117A0234	HVAC-device 8gang aluminium silver - Platform 63	6127/02-83-500	1	piece
2CKA006117A0219	Control Element 8gang studio white matt - Platform 63	6127/02-884	1	piece
2CKA006117A0242	Solo 8gang studio white matt - Platform 63	6127/02-884-500	1	piece
2CKA006117A0220	Control Element 8gang black matt - Platform 63	6127/02-885	1	piece
2CKA006117A0243	HVAC/CO2-device 8gang black matt - Platform 63	6127/02-885-500	1	piece
2CKA006117A0167	Switch Sensor 4-fold, FM	6127-83-101	1	piece
2CKA006134A0259	RTC Control element 2/4g	6128/01-83	1	piece
2CKA006134A0286	RTC Control element 2/4g	6128/01-83-500	1	piece
2CKA006134A0268	RTC Control element 2/4g	6128/01-884	1	piece
2CKA006134A0293	RTC Control element 2/4g	6128/01-884-500	1	piece
2CKA006134A0269	RTC Control element 2/4g	6128/01-885	1	piece
2CKA006134A0294	RTC Control element 2/4g	6128/01-885-500	1	piece
2CKA006134A0323	Control Element aluminium - Platform 63	6128/28-83	1	piece
2CKA006134A0333	HVAC-device 4gang aluminium - Platform 63	6128/28-83-500	1	piece
2CKA006134A0328	Control Element 4gang studio white matt - Platform 63	6128/28-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006134A0338	Solo studio white matt - Platform 63	6128/28-884-500	1	piece
2CKA006134A0329	Control Element black matt - Platform 63	6128/28-885	1	piece
2CKA006134A0339	Labeling Cover 4gang black matt - Platform 63	6128/28-885-500	1	piece
2CKA006134A0210	RoomThermostat/Switch Sensor	6128-83-101	1	piece
2CKA006135A0144	Control Element 3gang aluminium silver - Platform 63	6129/01-83	1	piece
2CKA006135A0158	Solo 3gang aluminium silver - Platform 63	6129/01-83-500	1	piece
2CKA006135A0153	Control Element 3gang studio white matt - Platform 63	6129/01-884	1	piece
2CKA006135A0165	Solo 3gang studio white matt - Platform 63	6129/01-884-500	1	piece
2CKA006135A0154	Control Element 3gang black matt - Platform 63	6129/01-885	1	piece
2CKA006135A0166	Solo 3gang black matt - Platform 63	6129/01-885-500	1	piece
2CKA006135A0130	IR-Switch Sensor 3fold, FM	6129-83-101	1	piece
2CKA006135A0141	6129-884-101 IR-Switch Sensor 3fold, FM	6129-884-101	1	piece
2CKA006138A0004	RTR Fan Coil with Display, SM	6138/11-83	1	piece
2CKA006138A0005	RTR Fan Coil with Display, SM	6138/11-83-500	1	piece
2CKA006220A0111	Motion detector 1gang Movement sensor 1 channel Twisted Pair Wiring aluminium silver - Platform 63	6215/1.1-83	1	piece
2CKA006200A0055	WL-Mov. detector/act. 1g	6215/1.1-83-WL	1	piece
2CKA006220A0496	Motion detector 1gang Movement sensor 1 channel Twisted Pair Wiring studio white matt - Platform 63	6215/1.1-884	1	piece
2CKA006200A0062	WL-Mov. detector/act. 1g	6215/1.1-884-WL	1	piece
2CKA006220A0513	Motion detector 1gang Movement sensor 1 channel Twisted Pair Wiring black matt - Platform 63	6215/1.1-885	1	piece
2CKA006200A0063	WL-Mov. detector/act. 1g	6215/1.1-885-WL	1	piece
2CKA006220A0108	Motion detector Movement sensor 1 channel Twisted Pair Wiring aluminium silver - Platform 63	6225/1.0-83	1	piece
2CKA006220A0495	Motion detector Movement sensor 1 channel Twisted Pair Wiring studio white matt - Platform 63	6225/1.0-884	1	piece
2CKA006220A0512	Motion detector Movement sensor 1 channel Twisted Pair Wiring black matt - Platform 63	6225/1.0-885	1	piece
2CKA006220A0033	Rocker with Small Transparent Calotte 1gang aluminium silver - Platform 63	6230-10-83	1	piece
2CKA006220A0481	Rocker with Small Transparent Calotte 1gang studio white matt - Platform 63	6230-10-884	1	piece
2CKA006220A0498	Rocker with Small Transparent Calotte 1gang black matt - Platform 63	6230-10-885	1	piece
2CKA006220A0048	Rocker with Small Transparent Calotte 2gang aluminium silver - Platform 63	6230-20-83	1	piece
2CKA006220A0486	Rocker with Small Transparent Calotte 2gang studio white matt - Platform 63	6230-20-884	1	piece
2CKA006220A0503	Rocker with Small Transparent Calotte 2gang black matt - Platform 63	6230-20-885	1	piece
2CKA006220A0036	Rocker Symbol "light" with Small Transparent Calotte 1gang aluminium silver - Platform 63	6231-10-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0482	Rocker Symbol "light" with Small Transparent Calotte 1gang studio white matt - Platform 63	6231-10-884	1	piece
2CKA006220A0499	Rocker Symbol "light" with Small Transparent Calotte 1gang black matt - Platform 63	6231-10-885	1	piece
2CKA006220A0051	Rocker Symbol "light" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6231-21-83	1	piece
2CKA006220A0487	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white matt - Platform 63	6231-21-884	1	piece
2CKA006220A0504	Rocker Symbol "light" with Small Transparent Calotte 2gang black matt - Platform 63	6231-21-885	1	piece
2CKA006220A0063	Rocker Symbol "light" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6231-22-83	1	piece
2CKA006220A0492	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white matt - Platform 63	6231-22-884	1	piece
2CKA006220A0509	Rocker Symbol "light" with Small Transparent Calotte 2gang black matt - Platform 63	6231-22-885	1	piece
2CKA006220A0039	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang aluminium silver - Platform 63	6232-10-83	1	piece
2CKA006220A0483	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang studio white matt - Platform 63	6232-10-884	1	piece
2CKA006220A0500	Rocker Symbol "venetian blind" with Small Transparent Calotte 1gang black matt - Platform 63	6232-10-885	1	piece
2CKA006220A0054	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6232-20-83	1	piece
2CKA006220A0488	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang studio white matt - Platform 63	6232-20-884	1	piece
2CKA006220A0505	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang black matt - Platform 63	6232-20-885	1	piece
2CKA006220A0042	Rocker Symbol "scene" with Small Transparent Calotte 1gang aluminium silver - Platform 63	6233-10-83	1	piece
2CKA006220A0484	Rocker Symbol "scene" with Small Transparent Calotte 1gang studio white matt - Platform 63	6233-10-884	1	piece
2CKA006220A0501	Rocker Symbol "scene" with Small Transparent Calotte 1gang black matt - Platform 63	6233-10-885	1	piece
2CKA006220A0057	Rocker Symbol "scene" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6233-21-83	1	piece
2CKA006220A0489	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white matt - Platform 63	6233-21-884	1	piece
2CKA006220A0506	Rocker Symbol "scene" with Small Transparent Calotte 2gang black matt - Platform 63	6233-21-885	1	piece
2CKA006220A0069	Rocker Symbol "scene" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6233-22-83	1	piece
2CKA006220A0493	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white matt - Platform 63	6233-22-884	1	piece
2CKA006220A0510	Rocker Symbol "scene" with Small Transparent Calotte 2gang black matt - Platform 63	6233-22-885	1	piece
2CKA006220A0045	Rocker Symbol "dimming" with Small Transparent Calotte 1gang aluminium silver - Platform 63	6234-10-83	1	piece
2CKA006220A0485	Rocker Symbol "dimming" with Small Transparent Calotte 1gang studio white matt - Platform 63	6234-10-884	1	piece
2CKA006220A0502	Rocker Symbol "dimming" with Small Transparent Calotte 1gang black matt - Platform 63	6234-10-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0060	Rocker Symbol "dimming" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6234-21-83	1	piece
2CKA006220A0490	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white matt - Platform 63	6234-21-884	1	piece
2CKA006220A0507	Rocker Symbol "dimming" with Small Transparent Calotte 2gang black matt - Platform 63	6234-21-885	1	piece
2CKA006220A0254	Rocker Symbol "dimming" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6234-22-83	1	piece
2CKA006220A0491	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white matt - Platform 63	6234-22-884	1	piece
2CKA006220A0508	Rocker Symbol "dimming" with Small Transparent Calotte 2gang black matt - Platform 63	6234-22-885	1	piece
2CKA006220A0075	Cover plate Symbols "up, down, ECO, Power" 2gang aluminium silver - Platform 63	6235-83	1	piece
2CKA006220A0494	Cover plate Symbols "up, down, ECO, Power" 2gang studio white matt - Platform 63	6235-884	1	piece
2CKA006220A0511	Cover plate Symbols "up, down, ECO, Power" 2gang black matt - Platform 63	6235-885	1	piece
2CKA006220A0249	Cover plate Symbols "up, down, ECO, menu" 2gang aluminium silver - Platform 63	6236-83	1	piece
2CKA006220A0497	Cover plate Symbols "up, down, ECO, menu" 2gang studio white matt - Platform 63	6236-884	1	piece
2CKA006220A0514	Cover plate Symbols "up, down, ECO, menu" 2gang black matt - Platform 63	6236-885	1	piece
2CKA006220A0737	Rocker Symbols "music control" with Small Transparent Calotte 2gang aluminium silver - Platform 63	6237-21-83	1	piece
2CKA006220A0749	Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white matt - Platform 63	6237-21-884	1	piece
2CKA006220A0751	Rocker Symbols "music control" with Small Transparent Calotte 2gang black matt - Platform 63	6237-21-885	1	piece
2CKA006220A0738	Rocker Symbols "music control" aluminium silver - Platform 63	6237-22-83	1	piece
2CKA006220A0750	Rocker Symbols "music control" with Small Transparent Calotte 2gang studio white matt - Platform 63	6237-22-884	1	piece
2CKA006220A0752	Rocker Symbols "music control" with Small Transparent Calotte 2gang black matt - Platform 63	6237-22-885	1	piece
2CKA006200A0169	Motion detector Movement sensor Wireless aluminium silver - Platform 63	62762-83-WL	1	piece
2CKA006200A0170	Motion Detectors Movement sensor Wireless aluminium silver - Platform 63	62762-83-WL-500	1	piece
2CKA006200A0175	Motion detector Movement sensor Wireless studio white matt - Platform 63	62762-884-WL	1	piece
2CKA006200A0176	Motion Detectors Movement sensor Wireless studio white matt - Platform 63	62762-884-WL-500	1	piece
2CKA006200A0177	Motion detector Movement sensor Wireless black matt - Platform 63	62762-885-WL	1	piece
2CKA006200A0178	Motion Detectors Movement sensor Wireless black matt - Platform 63	62762-885-WL-500	1	piece
2CKA006200A0237	Motion detector Enrolment device Wireless aluminium silver - Platform 63	62764-83-WL	1	piece
2CKA006200A0238	Motion Detectors Enrolment device Wireless aluminium silver - Platform 63	62764-83-WL-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006200A0243	Motion detector Enrolment device Wireless studio white matt - Platform 63	62764-884-WL	1	piece
2CKA006200A0244	Motion Detectors Enrolment device Wireless studio white matt - Platform 63	62764-884-WL-500	1	piece
2CKA006200A0245	Motion detector Enrolment device Wireless black matt - Platform 63	62764-885-WL	1	piece
2CKA006200A0246	Motion Detectors Enrolment device Wireless black matt - Platform 63	62764-885-WL-500	1	piece
2CKA006320A0017	triton 3/6gang MF/IR	6320/30-83	1	piece
2CKA006320A0037	triton 5/10gang MF/IR	6320/50-83	1	piece
2CKA006430A0328	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker aluminium silver - Platform 63	6430-83-102	1	piece
2CKA006430A0385	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker studio white matt - Platform 63	6430-884-102	1	piece
2CKA006430A0386	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind Single rocker black matt - Platform 63	6430-885-102	1	piece
2CKA006430A0305	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate aluminium silver - Platform 63	6435-83	1	piece
2CKA006430A0388	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate studio white matt - Platform 63	6435-884	1	piece
2CKA006430A0389	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate black matt - Platform 63	6435-885	1	piece
2CKA006800A2924	Busch-Watchdog 180 flex Basic sensor with select lens Movement sensor aluminium silver - Platform 63	64761-83	1	piece
2CKA006800A2925	Busch-Watchdog Electronic Controls Movement sensor aluminium silver - Platform 63	64761-83-500	1	piece
2CKA006800A2930	Busch-Watchdog 180 flex Basic sensor with select lens Movement sensor studio white matt - Platform 63	64761-884	1	piece
2CKA006800A2931	Busch-Watchdog Electronic Controls Movement sensor studio white matt - Platform 63	64761-884-500	1	piece
2CKA006800A2932	Busch-Watchdog 180 flex Basic sensor with select lens Movement sensor black matt - Platform 63	64761-885	1	piece
2CKA006800A2933	Electronic Controls Movement sensor black matt - Platform 63	64761-885-500	1	piece
2CKA006800A2961	Busch-Watchdog 180 flex Comfort sensor with select lens Movement sensor aluminium silver - Platform 63	64762-83	1	piece
2CKA006800A2962	Busch-Watchdog Cover plate Movement sensor aluminium silver - Platform 63	64762-83-500	1	piece
2CKA006800A2967	Busch-Watchdog 180 flex Comfort sensor with select lens Movement sensor studio white matt - Platform 63	64762-884	1	piece
2CKA006800A2968	Busch-Watchdog Cover plate Movement sensor studio white matt - Platform 63	64762-884-500	1	piece
2CKA006800A2969	Busch-Watchdog 180 flex Comfort sensor with select lens Movement sensor black matt - Platform 63	64762-885	1	piece
2CKA006800A2970	Busch-Watchdog Cover plate Movement sensor black matt - Platform 63	64762-885-500	1	piece
2CKA006800A2998	Busch-Watchdog 180 flex Multi sensor with select lens Movement sensor aluminium silver - Platform 63	64764-83	1	piece
2CKA006800A2999	Electronic Controls Movement sensor aluminium silver - Platform 63	64764-83-500	1	piece
2CKA006800A3004	Busch-Watchdog 180 flex Multi sensor with select lens Movement sensor studio white matt - Platform 63	64764-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006800A3005	Electronic Controls Movement sensor studio white matt - Platform 63	64764-884-500	1	piece
2CKA006800A3006	Busch-Watchdog 180 flex Multi sensor with select lens Movement sensor black matt - Platform 63	64764-885	1	piece
2CKA006800A3007	Electronic Controls Movement sensor black matt - Platform 63	64764-885-500	1	piece
2CKA006800A2886	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light aluminium silver - Platform 63	64765-83	1	piece
2CKA006800A2887	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light aluminium silver - Platform 63	64765-83-500	1	piece
2CKA006800A2892	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light studio white matt - Platform 63	64765-884	1	piece
2CKA006800A2893	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light studio white matt - Platform 63	64765-884-500	1	piece
2CKA006800A2894	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light black matt - Platform 63	64765-885	1	piece
2CKA006800A2895	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light black matt - Platform 63	64765-885-500	1	piece
2CKA006470A0008	Cover plate for Proximity switch aluminium silver - Platform 63	6476-83	1	piece
2CKA006470A0010	Cover plate for Proximity switch studio white matt - Platform 63	6476-884	1	piece
2CKA006470A0011	Cover plate for Proximity switch black matt - Platform 63	6476-885	1	piece
2CKA006400A0058	Cover plate PowerDock 1 gang aluminium silver - Platform 63	6477-83	1	piece
2CKA006400A0062	Cover plate PowerDock 1 gang studio white matt - Platform 63	6477-884	1	piece
2CKA006400A0063	Cover plate PowerDock 1 gang black matt - Platform 63	6477-885	1	piece
2CKA006400A0447	Cover plate USB power supply insert 1 gang with USB C aluminium silver - Platform 63	6479-83	1	piece
2CKA006400A0451	Cover plate USB power supply insert 1 gang with USB C studio white matt - Platform 63	6479-884	1	piece
2CKA006400A0453	Cover plate USB power supply insert 1 gang with USB C black matt - Platform 63	6479-885	1	piece
2CKA006599A2952	Cover plate for Dimmer Turn button with Neon lamp aluminium silver - Platform 63	6540-83-102	1	piece
2CKA006599A2961	Cover plate for Dimmer Turn button with Neon lamp studio white matt - Platform 63	6540-884-102	1	piece
2CKA006599A2966	Cover plate for Dimmer Turn button with Neon lamp black matt - Platform 63	6540-885-102	1	piece
2CKA006599A2885	Cover plate for Cooling Central cover plate aluminium silver - Platform 63	6541-83	1	piece
2CKA006599A2962	Cover plate for Cooling Central cover plate studio white matt - Platform 63	6541-884	1	piece
2CKA006599A2967	Cover plate for Cooling Central cover plate black matt - Platform 63	6541-885	1	piece
2CKA006599A2887	Control Element for Switch/dimmer Single push button with Neon lamp aluminium silver - Platform 63	6543-83-101	1	piece
2CKA006599A2963	Control Element for Switch/dimmer Single push button with Neon lamp studio white matt - Platform 63	6543-884-101	1	piece
2CKA006599A2968	Control Element for Switch/dimmer Single push button with Neon lamp black matt - Platform 63	6543-885-101	1	piece
2CKA006599A2914	Control Element for Dimmer Two-part button with Neon lamp aluminium silver - Platform 63	6545-83	1	piece
2CKA006599A2964	Control Element for Dimmer Two-part button with Neon lamp studio white matt - Platform 63	6545-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006599A2969	Control Element for Dimmer Two-part button with Neon lamp black matt 6545-885 - Platform 63	6545-885	1	piece
2CKA006710A0017	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless aluminium silver - future linear	6716 UJ-83	1	piece
2CKA006710A0016	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless black matt - future linear	6716 UJ-885	1	piece
2CKA006710A0018	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless black matt - future linear	6716 UJ-885-500	1	piece
2CKA006730A0155	Bluetooth Low Energie (BLE/Casambi) Smart Switch set for Bluetooth Low Energy (BLE) 4 channel Wireless black matt - future linear	6716/01 UJ-885	1	piece
2CKA006730A0157	Bluetooth Low Energie (BLE/Casambi) Smart Switch set for Bluetooth Low Energy (BLE) 4 channel Wireless black matt - future linear	6716/01 UJ-885-500	1	piece
2CKA006730A0159	Bluetooth Low Energie (BLE/Casambi) Smart Switch set for Bluetooth Low Energy (BLE) 4 channel Wireless black matt - future linear	6716/01 UJ-885-510	1	piece
2CKA006710A0021	Friends of Hue Friends of Hue Smart Switch set 4 channel Wireless black matt - future linear	6716/03 UJ-885	1	piece
2CKA006730A0051	WaveLine Wall sensor 1-gang 1 channel Wireless aluminium silver - Platform 63	6731-83	1	piece
2CKA006730A0035	WaveLine Wall sensor 1 channel Wireless aluminium silver - Platform 63	6731-83-500	1	piece
2CKA006730A0052	WaveLine Wall sensor 2-gang Wireless aluminium silver - Platform 63	6732-83	1	piece
2CKA006730A0036	WaveLine Wall sensor 2 channel Wireless aluminium silver - Platform 63	6732-83-500	1	piece
2CKA006730A0053	WaveLine Wall sensor 4-gang Wireless aluminium silver - Platform 63	6733-83	1	piece
2CKA006730A0037	WaveLine Wall sensor 4 channel Wireless aluminium silver - Platform 63	6733-83-500	1	piece
2CKA006730A0144	Rocker for Smart switch Single rocker aluminium silver - Platform 63	6735 BT-83	1	piece
2CKA006730A0149	Rocker for Smart switch Single rocker studio white matt - Platform 63	6735 BT-884	1	piece
2CKA006730A0150	Rocker for Smart switch Single rocker black matt - Platform 63	6735 BT-885	1	piece
2CKA006730A0081	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless aluminium silver - Platform 63	6735/01-83	1	piece
2CKA006730A0118	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless studio white matt - Platform 63	6735/01-884	1	piece
2CKA006730A0119	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless black matt - Platform 63	6735/01-885	1	piece
2CKA006220A0987	Rocker 1g blinds Symbol "venetian blind" for Smart switch Single rocker aluminium silver - Platform 63	6735-11-83	1	piece
2CKA006220A0991	Rocker 1g blinds Symbol "venetian blind" for Smart switch Single rocker studio white matt - Platform 63	6735-11-884	1	piece
2CKA006220A0992	Rocker 1g blinds Symbol "venetian blind" for Smart switch Single rocker black matt - Platform 63	6735-11-885	1	piece
2CKA006730A0069	Control Element 1-gang for Switch/dimmer Wireless aluminium silver - Platform 63	6735-83	1	piece
2CKA006730A0100	Control Element 1-gang for Switch/dimmer Wireless studio white matt - Platform 63	6735-884	1	piece
2CKA006730A0101	Control Element 1-gang for Switch/dimmer Wireless black matt - Platform 63	6735-885	1	piece
2CKA006730A0135	Rocker for Smart switch Two-part rocker aluminium silver - Platform 63	6736 FoH-83	1	piece
2CKA006730A0140	Rocker for Smart switch Two-part rocker studio white matt - Platform 63	6736 FoH-884	1	piece
2CKA006730A0141	Rocker for Smart switch Two-part rocker black matt - Platform 63	6736 FoH-885	1	piece
2CKA006730A0085	Wall sensor 2-gang 2 channel Wireless aluminium silver - Platform 63	6736/01-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006730A0124	Wall sensor 2-gang 2 channel Wireless studio white matt - Platform 63	6736/01-884	1	piece
2CKA006730A0125	Wall sensor 2-gang 2 channel Wireless black matt - Platform 63	6736/01-885	1	piece
2CKA006730A0073	Control Element 2-gang for Switch/dimmer Wireless aluminium silver - Platform 63	6736-83	1	piece
2CKA006730A0106	Control Element 2-gang for Switch/dimmer Wireless studio white matt - Platform 63	6736-884	1	piece
2CKA006730A0107	Control Element 2-gang for Switch/dimmer Wireless black matt - Platform 63	6736-885	1	piece
2CKA006730A0089	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless aluminium silver - Platform 63	6737/01-83	1	piece
2CKA006730A0130	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless studio white matt - Platform 63	6737/01-884	1	piece
2CKA006730A0131	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless black matt - Platform 63	6737/01-885	1	piece
2CKA006730A0077	Control Element 4-gang for Switch/dimmer Wireless aluminium silver - Platform 63	6737-83	1	piece
2CKA006730A0112	Control Element 4-gang for Switch/dimmer Wireless studio white matt - Platform 63	6737-884	1	piece
2CKA006730A0113	Control Element 4-gang for Switch/dimmer Wireless black matt - Platform 63	6737-885	1	piece
2CKA006800A2325	Electronic Controls - Platform 63	6800-83-104	1	piece
2CKA006800A2327	Electronic Controls - Platform 63	6800-83-104M	1	piece
2CKA006800A2506	Electronic Controls black matt - Platform 63	6800-885-104	1	piece
2CKA006800A2831	Electronic Controls aluminium silver - Platform 63	6815-83-101	1	piece
2CKA006800A2832	Electronic Controls aluminium silver - Platform 63	6815-83-101-500	1	piece
2CKA006800A2837	Electronic Controls studio white matt - Platform 63	6815-884-101	1	piece
2CKA008200A0252	Cover plate with legend Busch-Radio Radio aluminium silver - Platform 63	8252-83-101	1	piece
2CKA008200A0253	Cover plate with legend Radio 0 gang aluminium silver - Platform 63	8252-83-101-500	1	piece
2CKA008200A0258	Cover plate with legend Busch-Radio Radio studio white matt - Platform 63	8252-884-101	1	piece
2CKA008200A0259	Cover plate with legend Radio 0 gang studio white matt - Platform 63	8252-884-101-500	1	piece
2CKA008200A0260	Cover plate with legend Busch-Radio Radio black matt - Platform 63	8252-885-101	1	piece
2CKA008200A0261	Cover plate with legend Radio 0 gang black matt - Platform 63	8252-885-101-500	1	piece
2CKA008200A0080	Cover plate Loudspeaker aluminium silver - Platform 63	8253-83	1	piece
2CKA008200A0123	Cover plate Loudspeaker studio white matt - Platform 63	8253-884	1	piece
2CKA008200A0126	Cover plate Loudspeaker black matt - Platform 63	8253-885	1	piece
2CKA008200A0225	Cover plate Multimedia 3 gang aluminium silver - Platform 63	8256-83	1	piece
2CKA008200A0226	Cover plate Multimedia 3 gang studio white matt - Platform 63	8256-884	1	piece
2CKA008200A0228	Cover plate Multimedia 3 gang black matt - Platform 63	8256-885	1	piece
2CKA008300A0215	Cover plate, aluminium silver	83260-83	1	piece
2CKA008300A0221	Welcome, aluminium silver	83260-83-500	1	piece
2CKA006220A0243	User Operation Symbols "up, down, ECO, menu" 1gang aluminium silver - Platform 63	CP-FCC-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0617	User Operation Symbols "up, down, ECO, menu" 1gang studio white matt CP-FCC-884 - Platform 63	CP-FCC-884	1	piece
2CKA006220A0634	User Operation Symbols "up, down, ECO, menu" 1gang black matt - Platform 63	CP-FCC-885	1	piece
2CKA006220A0180	User Operation Symbols "up, down, ECO, Power" 1gang aluminium silver - Platform 63	CP-RTC-83	1	piece
2CKA006220A0614	User Operation Symbols "up, down, ECO, Power" 1gang studio white matt - Platform 63	CP-RTC-884	1	piece
2CKA006220A0631	User Operation Symbols "up, down, ECO, Power" 1gang black matt - Platform 63	CP-RTC-885	1	piece
2CKA006199A0209	Cover plate Symbol "arrows" aluminium silver - Platform 63	LFAW/A.1.63.11-83	1	piece
2CKA006199A0211	Cover plate Symbol "arrows" studio white matt - Platform 63	LFAW/A.1.63.11-884	1	piece
2CKA006199A0212	Cover plate Symbol "arrows" black matt - Platform 63	LFAW/A.1.63.11-885	1	piece
2CKA006199A0281	Cover plate Symbol "arrows" aluminium silver - Platform 63	LFAW/A.1.63.1-83	1	piece
2CKA006199A0283	Cover plate Symbol "arrows" studio white matt - Platform 63	LFAW/A.1.63.1-884	1	piece
2CKA006199A0284	Cover plate Symbol "arrows" black matt - Platform 63	LFAW/A.1.63.1-885	1	piece
2CKA006199A0249	Cover plate Symbol "arrows" aluminium silver - Platform 63	LFAW/A.2.63.11-83	1	piece
2CKA006199A0251	Cover plate Symbol "arrows" studio white matt - Platform 63	LFAW/A.2.63.11-884	1	piece
2CKA006199A0252	Cover plate Symbol "arrows" black matt - Platform 63	LFAW/A.2.63.11-885	1	piece
2CKA006199A0321	Cover plate Symbol "arrows" aluminium silver - Platform 63	LFAW/A.2.63.1-83	1	piece
2CKA006199A0323	Cover plate Symbol "arrows" studio white matt - Platform 63	LFAW/A.2.63.1-884	1	piece
2CKA006199A0324	Cover plate Symbol "arrows" black matt - Platform 63	LFAW/A.2.63.1-885	1	piece
2CKA006199A0076	Cover plate Symbol "light" aluminium silver - Platform 63	LFBT/A.1.63.11-83	1	piece
2CKA006199A0078	Cover plate Symbol "light" studio white matt - Platform 63	LFBT/A.1.63.11-884	1	piece
2CKA006199A0079	Cover plate Symbol "light" black matt - Platform 63	LFBT/A.1.63.11-885	1	piece
2CKA006199A0136	Cover plate Symbol "light" aluminium silver - Platform 63	LFBT/A.1.63.1-83	1	piece
2CKA006199A0138	Cover plate Symbol "light" studio white matt - Platform 63	LFBT/A.1.63.1-884	1	piece
2CKA006199A0139	Cover plate Symbol "light" black matt - Platform 63	LFBT/A.1.63.1-885	1	piece
2CKA006199A0217	Cover plate Symbol "light" aluminium silver - Platform 63	LFBT/A.2.63.11-83	1	piece
2CKA006199A0219	Cover plate Symbol "light" studio white matt - Platform 63	LFBT/A.2.63.11-884	1	piece
2CKA006199A0220	Cover plate Symbol "light" black matt - Platform 63	LFBT/A.2.63.11-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0289	Cover plate Symbol "light" aluminium silver - Platform 63	LFBT/A.2.63.1-83	1	piece
2CKA006199A0291	Cover plate Symbol "light" studio white matt - Platform 63	LFBT/A.2.63.1-884	1	piece
2CKA006199A0292	Cover plate Symbol "light" black matt - Platform 63	LFBT/A.2.63.1-885	1	piece
2CKA006199A0193	Cover plate Symbol "dimming" aluminium silver - Platform 63	LFDW/A.1.63.11-83	1	piece
2CKA006199A0195	Cover plate Symbol "dimming" studio white matt - Platform 63	LFDW/A.1.63.11-884	1	piece
2CKA006199A0196	Cover plate Symbol "dimming" black matt - Platform 63	LFDW/A.1.63.11-885	1	piece
2CKA006199A0265	Cover plate Symbol "dimming" aluminium silver - Platform 63	LFDW/A.1.63.1-83	1	piece
2CKA006199A0267	Cover plate Symbol "dimming" studio white matt - Platform 63	LFDW/A.1.63.1-884	1	piece
2CKA006199A0268	Cover plate Symbol "dimming" black matt - Platform 63	LFDW/A.1.63.1-885	1	piece
2CKA006199A0241	Cover plate Symbol "arrows/venetian blind" and "dimmer" aluminium silver - Platform 63	LFDW/A.2.63.1-1-83	1	piece
2CKA006199A0243	Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white matt - Platform 63	LFDW/A.2.63.1-1-884	1	piece
2CKA006199A0244	Cover plate Symbol "arrows/venetian blind" and "dimmer" black matt - Platform 63	LFDW/A.2.63.1-1-885	1	piece
2CKA006199A0313	Cover plate Symbol "arrows/venetian blind" and "dimmer" aluminium silver - Platform 63	LFDW/A.2.63.1-83	1	piece
2CKA006199A0315	Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white matt - Platform 63	LFDW/A.2.63.1-884	1	piece
2CKA006199A0316	Cover plate Symbol "arrows/venetian blind" and "dimmer" black matt - Platform 63	LFDW/A.2.63.1-885	1	piece
2CKA006199A0084	Cover plate Symbol "venetian blind" aluminium silver - Platform 63	LFJT/A.1.63.11-83	1	piece
2CKA006199A0086	Cover plate Symbol "venetian blind" studio white matt - Platform 63	LFJT/A.1.63.11-884	1	piece
2CKA006199A0087	Cover plate Symbol "venetian blind" black matt - Platform 63	LFJT/A.1.63.11-885	1	piece
2CKA006199A0145	Cover plate Symbol "venetian blind" aluminium silver - Platform 63	LFJT/A.1.63.1-83	1	piece
2CKA006199A0147	Cover plate Symbol "venetian blind" studio white matt - Platform 63	LFJT/A.1.63.1-884	1	piece
2CKA006199A0148	Cover plate Symbol "venetian blind" black matt - Platform 63	LFJT/A.1.63.1-885	1	piece
2CKA006199A0225	Cover plate Symbol "venetian blind" aluminium silver - Platform 63	LFJT/A.2.63.11-83	1	piece
2CKA006199A0227	Cover plate Symbol "venetian blind" studio white matt - Platform 63	LFJT/A.2.63.11-884	1	piece
2CKA006199A0228	Cover plate Symbol "venetian blind" black matt - Platform 63	LFJT/A.2.63.11-885	1	piece
2CKA006199A0297	Cover plate Symbol "venetian blind" aluminium silver - Platform 63	LFJT/A.2.63.1-83	1	piece
2CKA006199A0299	Cover plate Symbol "venetian blind" studio white matt - Platform 63	LFJT/A.2.63.1-884	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0300	Cover plate Symbol "venetian blind" black matt - Platform 63	LFJT/A.2.63.1-885	1	piece
2CKA006199A0201	Cover plate Symbol "venetian blind" aluminium silver - Platform 63	LFJW/A.1.63.11-83	1	piece
2CKA006199A0203	Cover plate Symbol "venetian blind" studio white matt - Platform 63	LFJW/A.1.63.11-884	1	piece
2CKA006199A0204	Cover plate Symbol "venetian blind" black matt - Platform 63	LFJW/A.1.63.11-885	1	piece
2CKA006199A0273	Cover plate Symbol "venetian blind" aluminium silver - Platform 63	LFJW/A.1.63.1-83	1	piece
2CKA006199A0275	Cover plate Symbol "venetian blind" studio white matt - Platform 63	LFJW/A.1.63.1-884	1	piece
2CKA006199A0276	Cover plate Symbol "venetian blind" black matt - Platform 63	LFJW/A.1.63.1-885	1	piece
2CKA006199A0257	Cover plate Symbols "music control" aluminium silver - Platform 63	LFMW/A.4.63.11-83	1	piece
2CKA006199A0259	Cover plate Symbols "music control" studio white matt - Platform 63	LFMW/A.4.63.11-884	1	piece
2CKA006199A0260	Cover plate Symbols "music control" black matt - Platform 63	LFMW/A.4.63.11-885	1	piece
2CKA006199A0329	Cover plate Symbols "music control" aluminium silver - Platform 63	LFMW/A.4.63.11-83	1	piece
2CKA006199A0331	Cover plate Symbols "music control" studio white matt - Platform 63	LFMW/A.4.63.11-884	1	piece
2CKA006199A0332	Cover plate Symbols "music control" black matt - Platform 63	LFMW/A.4.63.11-885	1	piece
2CKA006199A0092	Cover plate Symbol "scene" aluminium silver - Platform 63	LFST/A.1.63.11-83	1	piece
2CKA006199A0094	Cover plate Symbol "scene" studio white matt - Platform 63	LFST/A.1.63.11-884	1	piece
2CKA006199A0095	Cover plate Symbol "scene" black matt - Platform 63	LFST/A.1.63.11-885	1	piece
2CKA006199A0154	Cover plate Symbol "scene" aluminium silver - Platform 63	LFST/A.1.63.1-83	1	piece
2CKA006199A0156	Cover plate Symbol "scene" studio white matt - Platform 63	LFST/A.1.63.1-884	1	piece
2CKA006199A0157	Cover plate Symbol "scene" black matt - Platform 63	LFST/A.1.63.1-885	1	piece
2CKA006199A0233	Cover plate Symbol "scene" aluminium silver - Platform 63	LFST/A.2.63.11-83	1	piece
2CKA006199A0235	Cover plate Symbol "scene" studio white matt - Platform 63	LFST/A.2.63.11-884	1	piece
2CKA006199A0236	Cover plate Symbol "scene" black matt - Platform 63	LFST/A.2.63.11-885	1	piece
2CKA006199A0305	Cover plate Symbol "scene" aluminium silver - Platform 63	LFST/A.2.63.1-83	1	piece
2CKA006199A0307	Cover plate Symbol "scene" studio white matt - Platform 63	LFST/A.2.63.1-884	1	piece
2CKA006199A0308	Cover plate Symbol "scene" black matt - Platform 63	LFST/A.2.63.1-885	1	piece
2CKA006199A0044	Cover plate aluminium silver - Platform 63	LFW/A.1.63.11-83	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006199A0046	Cover plate studio white matt - Platform 63	LFW/A.1.63.11-884	1	piece
2CKA006199A0047	Cover plate black matt - Platform 63	LFW/A.1.63.11-885	1	piece
2CKA006199A0100	Cover plate aluminium silver - Platform 63	LFW/A.1.63.1-83	1	piece
2CKA006199A0102	Cover plate studio white matt - Platform 63	LFW/A.1.63.1-884	1	piece
2CKA006199A0103	Cover plate black matt - Platform 63	LFW/A.1.63.1-885	1	piece
2CKA006199A0052	Cover plate aluminium silver - Platform 63	LFW/A.2.63.11-83	1	piece
2CKA006199A0054	Cover plate studio white matt - Platform 63	LFW/A.2.63.11-884	1	piece
2CKA006199A0055	Cover plate black matt - Platform 63	LFW/A.2.63.11-885	1	piece
2CKA006199A0109	Cover plate aluminium silver - Platform 63	LFW/A.2.63.1-83	1	piece
2CKA006199A0111	Cover plate studio white matt - Platform 63	LFW/A.2.63.1-884	1	piece
2CKA006199A0112	Cover plate black matt - Platform 63	LFW/A.2.63.1-885	1	piece
2CKA006199A0060	Cover plate aluminium silver - Platform 63	LFW/A.3.63.11-83	1	piece
2CKA006199A0062	Cover plate studio white matt - Platform 63	LFW/A.3.63.11-884	1	piece
2CKA006199A0063	Cover plate black matt - Platform 63	LFW/A.3.63.11-885	1	piece
2CKA006199A0118	Cover plate aluminium silver - Platform 63	LFW/A.3.63.1-83	1	piece
2CKA006199A0120	Cover plate studio white matt - Platform 63	LFW/A.3.63.1-884	1	piece
2CKA006199A0121	Cover plate black matt - Platform 63	LFW/A.3.63.1-885	1	piece
2CKA006199A0068	Cover plate aluminium silver - Platform 63	LFW/A.4.63.11-83	1	piece
2CKA006199A0070	Cover plate studio white matt - Platform 63	LFW/A.4.63.11-884	1	piece
2CKA006199A0071	Cover plate black matt - Platform 63	LFW/A.4.63.11-885	1	piece
2CKA006199A0127	Cover plate aluminium silver - Platform 63	LFW/A.4.63.1-83	1	piece
2CKA006199A0129	Cover plate studio white matt - Platform 63	LFW/A.4.63.1-884	1	piece
2CKA006199A0130	Cover plate black matt - Platform 63	LFW/A.4.63.1-885	1	piece
2CKA006220A0213	Motion Detectors Movement sensor Twisted Pair Wiring aluminium silver MD-F-1.0.1-83 - Platform 63		1	piece
2CKA006220A0615	Motion Detectors Movement sensor Twisted Pair Wiring studio white matt - Platform 63	MD-F-1.0.1-884	1	piece
2CKA006220A0632	Motion Detectors Movement sensor Twisted Pair Wiring black matt - Platform 63	MD-F-1.0.1-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0216	Motion Detectors 1gang Movement sensor 1 channel Twisted Pair Wiring aluminium silver - Platform 63	MSA-F-1.1.1-83	1	piece
2CKA006200A0085	WL-Mov. detector/act. 1g	MSA-F-1.1.1-83-WL	1	piece
2CKA006220A0616	Motion Detectors 1gang Movement sensor 1 channel Twisted Pair Wiring studio white matt - Platform 63	MSA-F-1.1.1-884	1	piece
2CKA006200A0097	WL-Mov. detector/act. 1g	MSA-F-1.1.1-884-WL	1	piece
2CKA006220A0633	Motion Detectors 1gang Movement sensor 1 channel Twisted Pair Wiring black matt - Platform 63	MSA-F-1.1.1-885	1	piece
2CKA006200A0098	WL-Mov. detector/act. 1g	MSA-F-1.1.1-885-WL	1	piece
2CKA006220A0138	Rocker with Small Transparent Calotte 1gang aluminium silver - Platform 63	SR-1-83	1	piece
2CKA006220A0601	Rocker with Small Transparent Calotte 1gang studio white matt - Platform 63	SR-1-884	1	piece
2CKA006220A0618	Rocker with Small Transparent Calotte 1gang black matt - Platform 63	SR-1-885	1	piece
2CKA006220A0153	Rocker with Small Transparent Calotte 2gang aluminium silver - Platform 63	SR-2-83	1	piece
2CKA006220A0606	Rocker with Small Transparent Calotte 2gang studio white matt - Platform 63	SR-2-884	1	piece
2CKA006220A0623	Rocker with Small Transparent Calotte 2gang black matt - Platform 63	SR-2-885	1	piece
2CKA006220A0144	Rocker with Small Transparent Calotte 1gang aluminium silver - Platform 63	SRB-1-83	1	piece
2CKA006220A0603	Rocker with Small Transparent Calotte 1gang studio white matt - Platform 63	SRB-1-884	1	piece
2CKA006220A0620	Rocker with Small Transparent Calotte 1gang black matt - Platform 63	SRB-1-885	1	piece
2CKA006220A0159	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRB-2-83	1	piece
2CKA006220A0608	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRB-2-884	1	piece
2CKA006220A0625	Rocker Symbol "venetian blind" with Small Transparent Calotte 2gang black matt - Platform 63	SRB-2-885	1	piece
2CKA006220A0150	Rocker Symbol "dimming" with Small Transparent Calotte 1gang aluminium silver - Platform 63	SRD-1-83	1	piece
2CKA006220A0605	Rocker Symbol "dimming" with Small Transparent Calotte 1gang studio white matt - Platform 63	SRD-1-884	1	piece
2CKA006220A0622	Rocker Symbol "dimming" with Small Transparent Calotte 1gang black matt - Platform 63	SRD-1-885	1	piece
2CKA006220A0165	Rocker Symbol "dimming" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRD-2-L-83	1	piece
2CKA006220A0610	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRD-2-L-884	1	piece
2CKA006220A0627	Rocker Symbol "dimming" with Small Transparent Calotte 2gang black matt - Platform 63	SRD-2-L-885	1	piece
2CKA006220A0259	Rocker Symbol "dimming" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRD-2-R-83	1	piece
2CKA006220A0611	Rocker Symbol "dimming" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRD-2-R-884	1	piece
2CKA006220A0628	Rocker Symbol "dimming" with Small Transparent Calotte 2gang black matt - Platform 63	SRD-2-R-885	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0141	Rocker Symbol "light" with Small Transparent Calotte 1gang aluminium silver - Platform 63	SRL-1-83	1	piece
2CKA006220A0602	Rocker Symbol "light" with Small Transparent Calotte 1gang studio white matt - Platform 63	SRL-1-884	1	piece
2CKA006220A0619	Rocker Symbol "light" with Small Transparent Calotte 1gang black matt - Platform 63	SRL-1-885	1	piece
2CKA006220A0156	Rocker Symbol "light" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRL-2-L-83	1	piece
2CKA006220A0607	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRL-2-L-884	1	piece
2CKA006220A0624	Rocker Symbol "light" with Small Transparent Calotte 2gang black matt - Platform 63	SRL-2-L-885	1	piece
2CKA006220A0168	Rocker Symbol "light" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRL-2-R-83	1	piece
2CKA006220A0612	Rocker Symbol "light" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRL-2-R-884	1	piece
2CKA006220A0629	Rocker Symbol "light" with Small Transparent Calotte 2gang black matt - Platform 63	SRL-2-R-885	1	piece
2CKA006220A0147	Rocker Symbol "scene" with Small Transparent Calotte 1gang aluminium silver - Platform 63	SRS-1-83	1	piece
2CKA006220A0604	Rocker Symbol "scene" with Small Transparent Calotte 1gang studio white matt - Platform 63	SRS-1-884	1	piece
2CKA006220A0621	Rocker Symbol "scene" with Small Transparent Calotte 1gang black matt - Platform 63	SRS-1-885	1	piece
2CKA006220A0162	Rocker Symbol "scene" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRS-2-L-83	1	piece
2CKA006220A0609	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRS-2-L-884	1	piece
2CKA006220A0626	Rocker Symbol "scene" with Small Transparent Calotte 2gang black matt - Platform 63	SRS-2-L-885	1	piece
2CKA006220A0174	Rocker Symbol "scene" with Small Transparent Calotte 2gang aluminium silver - Platform 63	SRS-2-R-83	1	piece
2CKA006220A0613	Rocker Symbol "scene" with Small Transparent Calotte 2gang studio white matt - Platform 63	SRS-2-R-884	1	piece
2CKA006220A0630	Rocker Symbol "scene" with Small Transparent Calotte 2gang black matt - Platform 63	SRS-2-R-885	1	piece
2CKA001731A1976	Cover Busch-Infolicht® grey metallic - Platform 63	1716-803	1	piece
2CKA001710A4119	Cover plate with legend Loudspeaker Turn button grey metallic - Platform 63	1740 DR/03-803	1	piece
2CKA001710A4121	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button grey metallic - Platform 63	1740 DRL-803-503	1	piece
2CKA001710A3840	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button grey metallic - Platform 63	1740-803	1	piece
2CKA001710A3843	Cover plate for Blind cap 1-gang with Mounting plate grey metallic - Platform 63	1742-803	1	piece
2CKA001724A4364	Cover plate SAT 4 gang grey metallic - Platform 63	1743/10-04-803	1	piece
2CKA001724A4373	Cover plate TV / Radio / 2x SAT 4 gang grey metallic - Platform 63	1743-04-803	1	piece
2CKA001724A4291	Cover plate SAT 3 gang grey metallic - Platform 63	1743-803	1	piece
2CKA001710A3855	Cover plate telephone connector boxes (VDo) grey metallic - Platform 63	1745-803	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001710A3857	Cover plate 50x50 mm Telecommunication inserts grey metallic - Platform 63	1746/10-803	1	piece
2CKA001710A3858	Cover plate 50x50 mm with Hinged Lid Telecommunication inserts grey metallic - Platform 63	1746-803	1	piece
2CKA001710A4092	Intermediate Ring for cover plates Busch-Balance® SI 1-gang grey metallic - Platform 63	1747 BSI-803	1	piece
2CKA001710A3851	Cover plate Data connection 2 gang grey metallic - Platform 63	1748-803	1	piece
2CKA001710A3844	Cover plate for Cable outlet 1-gang with Mounting plate grey metallic - Platform 63	1749-803	1	piece
2CKA001710A3859	Cover plate BNC/TNC 2 gang grey metallic - Platform 63	1750-803	1	piece
2CKA001723A0257	Cover plate Loudspeaker 2 gang grey metallic - Platform 63	1751-803	1	piece
2CKA001710A3841	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key grey metallic - Platform 63	1755 SL/PZ-803-101	1	piece
2CKA001753A0088	Cover plate Busch-Infolicht® grey metallic - Platform 63	1756-803	1	piece
2CKA001724A4292	Cover plate with labelling field for data connection housing grey metallic - Platform 63	1758-803	1	piece
2CKA001710A4102	Data / Telecommunication / Antenna TDO grey metallic - Platform 63	1762-803-506	1	piece
2CKA001731A3997	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single rocker grey metallic - Platform 63	1764 NLI/KI-803	1	piece
2CKA001731A1975	Rocker with labelling field for Switch/push button, Single rocker grey metallic - Platform 63	1764 NLI-803	1	piece
2CKA001710A3854	Cover plate TAE, UAE/TAE, USB/VGA/HDMI/loudspeaker/charging 1 gang grey metallic - Platform 63	1766-803	1	piece
2CKA001753A0254	Cover plate 0 ... 15 Min for Time switch, Turn button grey metallic - Platform 63	1770-803-103	1	piece
2CKA001753A0264	Cover plate with legend 0 ... 120 Min for Time switch, Turning handle grey metallic - Platform 63	1771-803-103	1	piece
2CKA001751A3020	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker grey metallic - Platform 63	1785 JA-803	1	piece
2CKA001751A3129	Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker grey metallic - Platform 63	1785 K-803	1	piece
2CKA001751A3130	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker grey metallic - Platform 63	1785 K-803-500	1	piece
2CKA001751A3215	Rocker with legend DND, MUR with Small Transparent Calotte 1gang for Switch/push button Two-part rocker grey metallic - Platform 63	1785/11 K-803	1	piece
2CKA001751A3204	Rocker with legend DND, MUR for Switch/push button, Two-part rocker grey metallic - Platform 63	1785/11-803	1	piece
2CKA001751A3018	Rocker for Switch/push button, Two-part rocker grey metallic - Platform 63	1785-803	1	piece
2CKA001751A3206	Rocker DND for Switch/push button, Single rocker grey metallic - Platform 63	1786/11-803	1	piece
2CKA001751A3012	Rocker for Switch/push button, Single rocker grey metallic - Platform 63	1786-803	1	piece
2CKA001751A3093	Mechanical Controls for Switch/push button, Single rocker grey metallic - Platform 63	1786-803-500	1	piece
2CKA001751A3017	Rocker Characters 0 and 1 with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1788-803	1	piece
2CKA001751A3019	Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 H-803	1	piece
2CKA001751A3015	Rocker with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 KI-803	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001751A3014	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 LI-803	1	piece
2CKA001751A3146	Rocker with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 N-803	1	piece
2CKA001751A3156	Rocker Symbol "Socket" with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 ST-803	1	piece
2CKA001751A3016	Rocker with legend Symbol "key" with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 TR-803	1	piece
2CKA001751A3013	Rocker with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789-803	1	piece
2CKA001710A4133	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Card switch RFID Hotel card grey metallic - Platform 63	1792 RFID-803	1	piece
2CKA001710A4124	Cover plate with legend Card, Symbol "arrows" with Transparent Calotte for Switch/push button, Hotel card grey metallic - Platform 63	1792-803	1	piece
2CKA001710A3849	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1794 TA-803	1	piece
2CKA001710A3847	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1794-803	1	piece
2CKA001710A4012	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1795 HK-803	1	piece
2CKA001710A4044	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1795 HKEA-803	1	piece
2CKA001710A3850	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1795 TA-803	1	piece
2CKA001710A3848	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - Platform 63	1795-803	1	piece
2CKA001753A0307	Cover plate Pull cord grey metallic - Platform 63	1796-803	1	piece
2CKA001710A3856	Cover plate with labelling field Modular Jack 2 gang grey metallic - Platform 63	1800-803	1	piece
2CKA001710A3853	Cover plate with labelling field UAE/IAE (ISDN) 2 gang grey metallic - Platform 63	1803-02-803	1	piece
2CKA001710A3852	Cover plate with labelling field UAE/IAE (ISDN) 1 gang grey metallic - Platform 63	1803-803	1	piece
2CKA002013A5403	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	20 EUAB-803	1	piece
2CKA002011A6275	SCHUKO® USB socket insert Safety Shutter with USB A/A grey metallic - Platform 63	20 EUCB2USB-803	1	piece
2CKA002011A6276	Socket insert Safety Shutter with USB A/A grey metallic - Platform 63	20 EUCB2USB-803-500	1	piece
2CKA002011A6308	SCHUKO® USB socket insert Safety Shutter with USB A/C grey metallic - Platform 63	20 EUCB2USBAC-803	1	piece
2CKA002011A6309	Socket insert Safety Shutter with USB A/C grey metallic - solo	20 EUCB2USBAC-803-500	1	piece
2CKA002013A5414	Busch-Service-Socket SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	20 EUCBDR-803	1	piece
2CKA002013A5456	SCHUKO® socket insert Safety Shutter with LED Control light /Green grey metallic - Platform 63	20 EUCBL-803	1	piece
2CKA002013A5458	Busch-steplight® SCHUKO® socket insert Safety Shutter with LED Night light /White grey metallic - Platform 63	20 EUCBLI-803	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002011A6162	Socket insert Safety Shutter with USB A grey metallic - Platform 63	20 EUCBUSB-803	1	piece
2CKA002011A6180	Socket Outlets Safety Shutter with USB A grey metallic - Platform 63	20 EUCBUSB-803-500	1	piece
2CKA002013A5462	SCHUKO® Socket insert with legend EDV Safety Shutter grey metallic - Platform 63	20 EUCKS/DV-803	1	piece
2CKA002013A5426	SCHUKO® Socket insert with labelling field Safety Shutter with label space grey metallic - Platform 63	20 EUCNB-803	1	piece
2CKA002013A5436	SCHUKO® socket insert Safety Shutter without claw grey metallic - Platform 63	20 EUCRB-803	1	piece
2CKA002018A1493	SCHUKO® socket insert with Hinged Lid grey metallic - Platform 63	20 EUK-803	1	piece
2CKA002018A1516	SCHUKO® socket insert Safety Shutter with Hinged Lid grey metallic - Platform 63	20 EUKB-803	1	piece
2CKA002018A1525	SCHUKO® socket insert Safety Shutter with Hinged Lid without claw grey metallic - Platform 63	20 EUKBR-803	1	piece
2CKA002018A1536	SCHUKO® socket insert Safety Shutter with Hinged Lid with label space grey metallic - Platform 63	20 EUKNB-803	1	piece
2CKA002018A1547	SCHUKO® socket insert Safety Shutter with LED Control light /Green with Hinged Lid with label space grey metallic - Platform 63	20 EUKNBL-803	1	piece
2CKA002018A1555	SCHUKO® socket insert Safety Shutter with Hinged Lid Cylinder with Different Locking with label space grey metallic - Platform 63	20 EUKNBSL-803	1	piece
2CKA002018A1556	SCHUKO® socket insert Safety Shutter with Hinged Lid Cylinder with Simultaneous Locking with label space grey metallic - Platform 63	20 EUKNBSL-803-101	1	piece
2CKA002011A3876	SCHUKO® Socket insert with labelling field with label space grey metallic - Platform 63	20 EUN-803	1	piece
2CKA002017A1892	Socket Safety Shutter with USB A/A grey metallic - Platform 63	20 MUCB2USB-803-500	1	piece
2CKA002017A1917	Socket Safety Shutter with USB A/C grey metallic - solo	20 MUCB2USBAC-803-500	1	piece
2CKA002017A0892	Socket Outlets Safety Shutter with USB A grey metallic - Busch-axcent	20 MUCBUSB-803-500	1	piece
2CKA001751A3166	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P 1NO grey metallic - Platform 63	2029 UC-803	1	piece
2CKA001751A3237	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P grey metallic - Platform 63	2029/12 UC-803	1	piece
2CKA001751A3226	Rocker with legend DND, MUR with Small Transparent Calotte for Electronic push button insert Two-part rocker grey metallic - Platform 63	2058-24-803	1	piece
2CKA001751A3246	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" 1gang Single push button with LED 1 rocker grey metallic - Platform 63	2059 UC-803	1	piece
2CKA002495A0097	Socket insert grey metallic - Platform 63	2095 UC-803	1	piece
2CKA002190A0224	Socket Outlets with screw terminals grey metallic - Platform 63	2190 EUC-803	1	piece
2CKA002013A5473	SCHUKO® socket insert Safety Shutter with screw terminals grey metallic - Platform 63	23 EUCB-803	1	piece
2CKA002013A5447	SCHUKO® socket insert Safety Shutter with screw terminals grey metallic - Platform 63	2300 EUCB-803	1	piece
2CKA002113A5341	Socket Outlets Safety Shutter without claw grey metallic - Platform 63	2300 UCRKS-803-503	1	piece
2CKA002011A3877	Busch-Protector® SCHUKO® socket insert with Neon lamp /Red with screw terminals grey metallic - Platform 63	2310EUGL/VA-803-11	1	piece
2CKA002013A5356	2398 CKS-803 Cover plate shuttered	2398 CKS-803	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002099A0253	Socket Outlets Safety Shutter grey metallic - Platform 63	2399 UCKS-803	1	piece
2CKA002099A0193	Socket Outlets Safety Shutter manhattan / graphite - Busch-axcent	2399 UCKS-85-505	1	piece
2CKA001719A0216	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring grey metallic - Platform 63	2518-WD-803	1	piece
2CKA001751A3175	Rocker with legend Symbol "bell" for Switch/push button, Single rocker grey metallic - Platform 63	2520 KI-803	1	piece
2CKA001751A3185	Rocker for Switch/push button, Single rocker grey metallic - Platform 63	2520 LI-803	1	piece
2CKA001751A3195	Rocker Symbol "key" for Switch/push button, Single rocker grey metallic - Platform 63	2520 TR-803	1	piece
2CKA001724A4407	Cover plate Pilot devices grey metallic - Platform 63	2533-803	1	piece
2CKA001710A4125	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button grey metallic - Platform 63	2542 DR/01-803	1	piece
2CKA001710A4126	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button grey metallic - Platform 63	2542 DR/02-803	1	piece
2CKA001724A4398	Cover plate XLR grey metallic - Platform 63	2553-803	1	piece
2CKA001753A0316	Cover plate Modular Jack 2 gang grey metallic - Platform 63	2561-02-803	1	piece
2CKA001753A0399	Cover plate Modular Jack 1 gang grey metallic - Platform 63	2561-803	1	piece
2CKA001751A3264	Rocker with Small Transparent Calotte for Switch/push button Single rocker grey metallic - Platform 63	2570-10-803	1	piece
2CKA001751A3275	Rocker with Small Transparent Calotte for Switch/push button Two-part rocker grey metallic	2570-20-803	1	piece
2CKA001751A3286	Rocker with Small Transparent Calotte for Switch/push button Three-part rocker grey metallic - Platform 63	2570-30-803	1	piece
2CKA003116A0666	FI-SCHUKOMAT SCHUKO® socket insert Safety Shutter grey metallic - Platform 63	3120 EUCB-803	1	piece
2CKA003117A0008	Buschmat RCD - Insert RCD 16 A 30 mA grey metallic - Platform 63	3151 UC-803	1	piece
2CKA006115A0470	Coverplate f. CE	6108/61-803	1	piece
2CKA006115A0489	Coverplate f. CE	6108/61-803-500	1	piece
2CKA006155A0047	Coverplate f. RTC	6109/03-803	1	piece
2CKA006155A0066	Coverplate f. RTC	6109/03-803-500	1	piece
2CKA006132A0255	6122/01-803 Watchdog 180 Standard FM	6122/01-803	1	piece
2CKA006132A0279	6122/01-803-500 Watchdog 180 Standard FM	6122/01-803-500	1	piece
2CKA006132A0256	6122/01-815 Watchdog 180 Standard FM	6122/01-815	1	piece
2CKA006132A0280	6122/01-815-500 Watchdog 180 Standard FM	6122/01-815-500	1	piece
2CKA006132A0321	6122/01-896 Watchdog 180 Standard FM	6122/01-896	1	piece
2CKA006132A0268	Motion detector Twisted Pair Wiring grey	6122/02-803	1	piece
2CKA006132A0290	Presence Detection Twisted Pair Wiring grey	6122/02-803-500	1	piece
2CKA006132A0269	6122/02-815 Watchdog 180 comfort FM	6122/02-815	1	piece
2CKA006132A0291	6122/02-815-500 Watchdog 180 comfort FM	6122/02-815-500	1	piece
2CKA006132A0323	6122/02-896 Watchdog 180 comfort FM	6122/02-896	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006132A0369	Busch-Watchdog Motion detector Twisted Pair Wiring grey metallic	6122/10-803	1	piece
2CKA006132A0382	Busch-Watchdog Motion detector Twisted Pair Wiring grey metallic	6122/10-803-500	1	piece
2CKA006132A0371	BW standard	6122/10-896	1	piece
2CKA006134A0253	Room Thermostat	6124/01-803	1	piece
2CKA006134A0280	Room Thermostat	6124/01-803-500	1	piece
2CKA006134A0254	Room Thermostat	6124/01-815	1	piece
2CKA006134A0281	Room Thermostat	6124/01-815-500	1	piece
2CKA006134A0303	Room Thermostat	6124/01-896	1	piece
2CKA006134A0304	6124/01-896-500 Room Thermostat	6124/01-896-500	1	piece
2CKA006134A0226	Room Thermostat with Display	6124-87-101	1	piece
2CKA006115A0188	Control element 1g w. BAU	6125/01-803	1	piece
2CKA006115A0212	Control element 1g w. BAU	6125/01-803-500	1	piece
2CKA006115A0448	Control element 1g w. BAU	6125/01-896	1	piece
2CKA006115A0201	Control element 1/2gang	6125/02-803	1	piece
2CKA006115A0224	Control element 1/2gang	6125/02-803-500	1	piece
2CKA006115A0450	Control element 1/2gang	6125/02-896	1	piece
2CKA006115A0176	Switch Sensor 1-fold, FM	6125-803-101	1	piece
2CKA006115A0168	Switch Sensor 1-fold, FM	6125-85-101	1	piece
2CKA006115A0170	6125-87-101 Switch Sensor 1-fold, FM	6125-87-101	1	piece
2CKA006115A0172	Switch Sensor 1-fold, FM	6125-89-101	1	piece
2CKA006116A0179	Control element 2g w. BAU	6126/01-803	1	piece
2CKA006116A0202	Control element 2g w. BAU	6126/01-803-500	1	piece
2CKA006116A0223	6126/01-896 Control element 2g w. BAU	6126/01-896	1	piece
2CKA006116A0191	Control element 2/4gang	6126/02-803	1	piece
2CKA006116A0214	Control element 2/4gang	6126/02-803-500	1	piece
2CKA006116A0225	6126/02-896 Control element 2/4gang	6126/02-896	1	piece
2CKA006116A0158	6126-85-101 Switch Sensor 2-fold, FM	6126-85-101	1	piece
2CKA006116A0162	Switch Sensor 2-fold, FM	6126-89-101	1	piece
2CKA006117A0190	6127 MF-803-101 MF-Switch Sensor 4fold, FM	6127 MF-803-101	1	piece
2CKA006117A0180	MF-Switch Sensor 4fold, FM	6127 MF-85-101	1	piece
2CKA006117A0182	6127 MF-87-101 MF-Switch Sensor 4fold, FM	6127 MF-87-101	1	piece
2CKA006117A0184	MF-Switch Sensor 4fold, FM	6127 MF-89-101	1	piece
2CKA006117A0205	Control element 4g w. BAU	6127/01-803	1	piece
2CKA006117A0228	Control element 4g w. BAU	6127/01-803-500	1	piece
2CKA006117A0248	Control element 4g w. BAU	6127/01-896	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006117A0217	Control element 4/8gang	6127/02-803	1	piece
2CKA006117A0240	Control element 4/8gang	6127/02-803-500	1	piece
2CKA006117A0250	Control element 4/8gang	6127/02-896	1	piece
2CKA006117A0188	Switch Sensor 4-fold, FM	6127-803-101	1	piece
2CKA006117A0169	6127-85-101 Switch Sensor 4-fold, FM	6127-85-101	1	piece
2CKA006117A0173	Switch Sensor 4-fold, FM	6127-89-101	1	piece
2CKA006134A0291	RTC Control element 2/4g	6128/01-803-500	1	piece
2CKA006134A0267	RTC Control element 2/4g	6128/01-815	1	piece
2CKA006134A0292	RTC Control element 2/4g	6128/01-815-500	1	piece
2CKA006134A0305	RTC Control element 2/4g	6128/01-896	1	piece
2CKA006134A0306	RTC Control element 2/4g	6128/01-896-500	1	piece
2CKA006136A0173	6128/10-85-101 Timer w. Display/Switch Sensor	6128/10-85-101	1	piece
2CKA006136A0177	6128/10-89-101 Timer w. Display/Switch Sensor	6128/10-89-101	1	piece
2CKA006134A0326	RTC Control element 2/4g	6128/28-803	1	piece
2CKA006134A0336	RTC Control element 2/4g	6128/28-803-500	1	piece
2CKA006134A0330	6128/28-896 RTC Control element 2/4g	6128/28-896	1	piece
2CKA006135A0151	Control element 3/6g w. IR	6129/01-803	1	piece
2CKA006135A0163	Control element 3/6g w. IR	6129/01-803-500	1	piece
2CKA006135A0152	6129/01-815 Control element 3/6g w. IR	6129/01-815	1	piece
2CKA006135A0164	6129/01-815-500 Control element 3/6g w. IR	6129/01-815-500	1	piece
2CKA006135A0169	6129/01-896 Control element 3/6g w. IR	6129/01-896	1	piece
2CKA006135A0132	6129-85-101 IR-Switch Sensor 3fold, FM	6129-85-101	1	piece
2CKA006220A0445	Mov. detector/actuator 1g	6215/1.1-803	1	piece
2CKA006200A0059	WL-Mov. detector/act. 1g	6215/1.1-803-WL	1	piece
2CKA006220A0479	6215/1.1-896 Mov. detector/actuator 1g	6215/1.1-896	1	piece
2CKA006220A0444	Movement detector	6225/1.0-803	1	piece
2CKA006220A0478	6225/1.0-896 Movement detector	6225/1.0-896	1	piece
2CKA006220A0430	Rocker 1gang grey metallic - Platform 63	6230-10-803	1	piece
2CKA006220A0464	rocker 1gang	6230-10-896	1	piece
2CKA006220A0435	Rocker 2gang grey metallic - Platform 63	6230-20-803	1	piece
2CKA006220A0452	6230-20-815 rocker 2gang	6230-20-815	1	piece
2CKA006220A0469	rocker 2gang	6230-20-896	1	piece
2CKA006220A0431	Rocker Symbol "light" 1gang grey metallic - Platform 63	6231-10-803	1	piece
2CKA006220A0465	6231-10-896 rocker 1gang, lighting	6231-10-896	1	piece
2CKA006220A0436	Rocker Symbol "light" 2gang grey metallic - Platform 63	6231-21-803	1	piece
2CKA006220A0470	6231-21-896 rocker 2g, left, lighting	6231-21-896	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0441	Rocker Symbol "light" 2gang grey metallic - Platform 63	6231-22-803	1	piece
2CKA006220A0475	6231-22-896 rocker 2g, right, lighting	6231-22-896	1	piece
2CKA006220A0432	Rocker Symbol "venetian blind" 1gang grey metallic - Platform 63	6232-10-803	1	piece
2CKA006220A0449	rocker 1gang, blinds	6232-10-815	1	piece
2CKA006220A0466	6232-10-896 rocker 1gang, blinds	6232-10-896	1	piece
2CKA006220A0437	Rocker Symbol "venetian blind" 2gang grey metallic - Platform 63	6232-20-803	1	piece
2CKA006220A0454	6232-20-815 rocker 2g, blinds	6232-20-815	1	piece
2CKA006220A0471	6232-20-896 rocker 2g, blinds	6232-20-896	1	piece
2CKA006220A0433	Rocker Symbol "scene" 1gang grey metallic - Platform 63	6233-10-803	1	piece
2CKA006220A0467	rocker 1gang, scene	6233-10-896	1	piece
2CKA006220A0438	Rocker Symbol "scene" 2gang grey metallic - Platform 63	6233-21-803	1	piece
2CKA006220A0472	rocker 2gang, left, scene	6233-21-896	1	piece
2CKA006220A0442	Rocker Symbol "scene" 2gang grey metallic - Platform 63	6233-22-803	1	piece
2CKA006220A0476	rocker 2g, right, scene	6233-22-896	1	piece
2CKA006220A0434	Rocker Symbol "dimming" 1gang grey metallic - Platform 63	6234-10-803	1	piece
2CKA006220A0468	rocker 1gang, dimming	6234-10-896	1	piece
2CKA006220A0439	Rocker Symbol "dimming" 2gang grey metallic - Platform 63	6234-21-803	1	piece
2CKA006220A0473	rocker 2g, left, dimming	6234-21-896	1	piece
2CKA006220A0440	Rocker Symbol "dimming" 2gang grey metallic - Platform 63	6234-22-803	1	piece
2CKA006220A0474	rocker 2g, right, dimming	6234-22-896	1	piece
2CKA006220A0443	C-plate RT sensor unit	6235-803	1	piece
2CKA006220A0477	C-plate RT sensor unit	6235-896	1	piece
2CKA006220A0446	C-plate Fan Coil	6236-803	1	piece
2CKA006220A0480	6236-896 C-plate Fan Coil	6236-896	1	piece
2CKA006220A0745	rocker 2g, left, Play/Paus	6237-21-803	1	piece
2CKA006220A0746	rocker 2g, right, Volume	6237-22-803	1	piece
2CKA006200A0173	Motion detector Movement sensor Wireless grey metallic - Platform 63	62762-803-WL	1	piece
2CKA006200A0174	Motion Detectors Movement sensor Wireless grey metallic - Platform 63	62762-803-WL-500	1	piece
2CKA006200A0241	Motion detector Enrolment device Wireless grey metallic - Platform 63	62764-803-WL	1	piece
2CKA006200A0242	Motion Detectors Enrolment device Wireless grey metallic - Platform 63	62764-803-WL-500	1	piece
2CKA006430A0350	Control Element Symbol "arrows" for Venetian blind grey metallic - Platform 63	6430-803-102	1	piece
2CKA006430A0351	Cover plate with legend Symbols "play, up, down, ok" for Time switch, Room temperature controller, CO2-sensor Central cover plate grey metallic - Platform 63	6435-803	1	piece
2CKA006800A2928	Busch-Watchdog Cover plate Movement sensor grey metallic - Platform 63	64761-803	1	piece
2CKA006800A2929	Busch-Watchdog Electronic Controls Movement sensor grey metallic - Platform 63	64761-803-500	1	piece
2CKA006800A2965	Busch-Watchdog Cover plate Movement sensor grey metallic - Platform 63	64762-803	1	piece
2CKA006800A2966	Busch-Watchdog Cover plate Movement sensor grey metallic - Platform 63	64762-803-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006800A3002	Busch-Watchdog Cover plate Movement sensor grey metallic - Platform 63	64764-803	1	piece
2CKA006800A3003	Electronic Controls Movement sensor grey metallic - Platform 63	64764-803-500	1	piece
2CKA006800A2890	Busch-Comfort switch® flex Control Element Movement sensor with LED Orientation light grey metallic - Platform 63	64765-803	1	piece
2CKA006800A2891	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light grey metallic - Platform 63	64765-803-500	1	piece
2CKA006470A0006	Cover plate for Proximity switch grey metallic - Platform 63	6476-803	1	piece
2CKA006400A0060	Cover plate PowerDock 1 gang grey metallic - Platform 63	6477-803	1	piece
2CKA006599A2980	Cover plate for Dimmer Turn button with Neon lamp grey metallic - Platform 63	6540-803-102	1	piece
2CKA006599A2940	Cover plate for Cooling Central cover plate grey metallic - Platform 63	6541-803	1	piece
2CKA006599A2942	Control Element for Switch/dimmer Single push button with Neon lamp grey metallic - Platform 63	6543-803-101	1	piece
2CKA006599A2943	Control Element for Dimmer Two-part button with Neon lamp grey metallic - Platform 63	6545-803	1	piece
2CKA006730A0146	Rocker for Smart switch Single rocker grey metallic - Platform 63	6735 BT-803	1	piece
2CKA006730A0117	Wall sensor 1-gang for ZigBee Light Link applications 1 channel Wireless grey metallic - Platform 63	6735/01-803	1	piece
2CKA006730A0099	Control Element 1-gang for Switch/dimmer Wireless grey metallic - Platform 63	6735-803	1	piece
2CKA006730A0137	Rocker for Smart switch Two-part rocker grey metallic - Platform 63	6736 FoH-803	1	piece
2CKA006730A0121	Wall sensor 2-gang 2 channel Wireless grey metallic - Platform 63	6736/01-803	1	piece
2CKA006730A0105	Control Element 2-gang for Switch/dimmer Wireless grey metallic - Platform 63	6736-803	1	piece
2CKA006730A0127	Wall sensor 4-gang for ZigBee Light Link applications 4 channel Wireless grey metallic - Platform 63	6737/01-803	1	piece
2CKA006730A0111	Control Element 4-gang for Switch/dimmer Wireless grey metallic - Platform 63	6737-803	1	piece
2CKA006800A2835	Electronic Controls grey metallic - Platform 63	6815-803-101	1	piece
2CKA006800A2836	Electronic Controls grey metallic - Platform 63	6815-803-101-500	1	piece
2CKA008200A0256	Cover plate with legend Radio grey metallic - Platform 63	8252-803-101	1	piece
2CKA008200A0257	Cover plate with legend Radio 0 gang grey metallic - Platform 63	8252-803-101-500	1	piece
2CKA008200A0115	Cover plate Loudspeaker grey metallic - Platform 63	8253-803	1	piece
2CKA008200A0230	Cover plate Multimedia 3 gang grey metallic - Platform 63	8256-803	1	piece
2CKA006220A0566	C-plate Fan Coil	CP-FCC-803	1	piece
2CKA006220A0600	CP-FCC-896 C-plate Fan Coil	CP-FCC-896	1	piece
2CKA006220A0563	C-plate RT sensor unit	CP-RTC-803	1	piece
2CKA006220A0597	CP-RTC-896 C-plate RT sensor unit	CP-RTC-896	1	piece
2CKA006220A0564	Movement detector	MD-F-1.0.1-803	1	piece
2CKA006220A0598	MD-F-1.0.1-896 Movement detector	MD-F-1.0.1-896	1	piece
2CKA006220A0565	Mov. detector/actuator 1g	MSA-F-1.1.1-803	1	piece
2CKA006200A0094	WL-Mov. detector/act. 1g	MSA-F-1.1.1-803-WL	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006220A0599	MSA-F-1.1.1-896 Mov. detector/actuator 1g	MSA-F-1.1.1-896	1	piece
2CKA006220A0550	Electronic Controls 1gang grey metallic - Platform 63	SR-1-803	1	piece
2CKA006220A0584	SR-1-896 rocker 1gang	SR-1-896	1	piece
2CKA006220A0555	Electronic Controls 2gang grey metallic - Platform 63	SR-2-803	1	piece
2CKA006220A0589	SR-2-896 rocker 2gang	SR-2-896	1	piece
2CKA006220A0552	Electronic Controls 1gang grey metallic - Platform 63	SRB-1-803	1	piece
2CKA006220A0586	SRB-1-896 rocker 1gang, blinds	SRB-1-896	1	piece
2CKA006220A0557	Electronic Controls 2gang grey metallic - Platform 63	SRB-2-803	1	piece
2CKA006220A0591	SRB-2-896 rocker 2g, blinds	SRB-2-896	1	piece
2CKA006220A0554	Electronic Controls 1gang grey metallic - Platform 63	SRD-1-803	1	piece
2CKA006220A0588	SRD-1-896 rocker 1gang, dimming	SRD-1-896	1	piece
2CKA006220A0559	Electronic Controls 2gang grey metallic - Platform 63	SRD-2-L-803	1	piece
2CKA006220A0593	SRD-2-L-896 rocker 2g, left, dimming	SRD-2-L-896	1	piece
2CKA006220A0560	Electronic Controls 2gang grey metallic - Platform 63	SRD-2-R-803	1	piece
2CKA006220A0594	SRD-2-R-896 rocker 2g, right, dimming	SRD-2-R-896	1	piece
2CKA006220A0551	Electronic Controls 1gang grey metallic - Platform 63	SRL-1-803	1	piece
2CKA006220A0585	SRL-1-896 rocker 1gang, lighting	SRL-1-896	1	piece
2CKA006220A0556	Electronic Controls 2gang grey metallic - Platform 63	SRL-2-L-803	1	piece
2CKA006220A0590	SRL-2-L-896 rocker 2g, left, lighting	SRL-2-L-896	1	piece
2CKA006220A0561	Electronic Controls 2gang grey metallic - Platform 63	SRL-2-R-803	1	piece
2CKA006220A0595	SRL-2-R-896 rocker 2g, right, lighting	SRL-2-R-896	1	piece
2CKA006220A0553	Electronic Controls 1gang grey metallic - Platform 63	SRS-1-803	1	piece
2CKA006220A0587	SRS-1-896 rocker 1gang, scene	SRS-1-896	1	piece
2CKA006220A0558	Electronic Controls 2gang grey metallic - Platform 63	SRS-2-L-803	1	piece
2CKA006220A0575	SRS-2-L-815 rocker 2gang, left, scene	SRS-2-L-815	1	piece
2CKA006220A0592	SRS-2-L-896 rocker 2gang, left, scene	SRS-2-L-896	1	piece
2CKA006220A0562	Electronic Controls 2gang grey metallic - Platform 63	SRS-2-R-803	1	piece
2CKA006220A0596	SRS-2-R-896 rocker 2g, right, scene	SRS-2-R-896	1	piece
2CKA001731A2025	Light & Signalization LED antique brass - Platform 63	1716-840-500	1	piece
2CKA001710A4089	Mechanical Controls Symbol "arrows" for Venetian blind, Turn button antique brass - Platform 63	1740-840-500	1	piece
2CKA001710A4086	Cover plate 50x50 mm 0 gang antique brass - Platform 63	1746-840-500	1	piece
2CKA001710A4079	Cable Outlet / Blank Plate / Adapter Ring antique brass - Platform 63	1747 SI-840-500	1	piece
2CKA001751A3131	Mechanical Controls with Small Transparent Calotte for Switch/push button, Two-part rocker antique brass - Platform 63	1785 K-840-500	1	piece
2CKA001751A3217	Rocker with legend DND, MUR 1gang for Switch/push button Two-part rocker antique brass - Platform 63	1785/11 K-840-500	1	piece
2CKA001751A3119	Mechanical Controls for Switch/push button, Two-part rocker antique brass - Platform 63	1785/11-840-500	1	piece
2CKA002011A6281	Socket insert Safety Shutter with USB A/A antique brass anthracite - Platform 63	20 EUCB2USB-845-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA002011A6282	Socket insert Safety Shutter with USB A/A antique brass ivory white - Platform 63	20 EUCB2USB-848-500	1	piece
2CKA002013A5399	Busch-steplight® Socket Outlets Safety Shutter with LED Night light /White antique brass - Platform 63	20 EUCBLI-840-500	1	piece
2CKA002011A6246	Socket Outlets Safety Shutter with USB A antique brass - Platform 63	20 EUCBUSB-840-500	1	piece
2CKA002013A5401	Socket Outlets Safety Shutter antique brass anthracite - Platform 63	20 EUCKS-845-500	1	piece
2CKA002013A5398	Socket Outlets Safety Shutter antique brass ivory white - Platform 63	20 EUCKS-848-500	1	piece
2CKA002018A1515	Socket Outlets with Hinged Lid antique brass - Platform 63	20 EUK-840-500	1	piece
2CKA002017A1895	Socket Safety Shutter with USB A/A antique brass anthracite - Platform 63	20 MUCB2USB-845-500	1	piece
2CKA002017A1896	Socket Safety Shutter with USB A/A antique brass ivory white - Platform 63	20 MUCB2USB-848-500	1	piece
2CKA001751A3230	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO antique brass - Platform 63	2029 UC-840-500	1	piece
2CKA001751A3239	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED antique brass - Platform 63	2029/12 UC-840-500	1	piece
2CKA002190A0222	Socket Outlets with screw terminals antique brass - Platform 63	2190 EUC-840-500	1	piece
2CKA002011A6247	Socket Outlets Safety Shutter with screw terminals antique brass anthracite - Platform 63	23 EUCKS-845-507	1	piece
2CKA002011A6245	Socket Outlets Safety Shutter with screw terminals antique brass ivory white - Platform 63	23 EUCKS-848-507	1	piece
2CKA002017A0891	Socket Outlets Safety Shutter with screw terminals antique brass anthracite - Platform 63	23 MUCKS-845-500	1	piece
2CKA002017A0889	Socket Outlets Safety Shutter with screw terminals antique brass ivory white - Platform 63	23 MUCKS-848-500	1	piece
2CKA006155A0121	Cover plate Symbols "up, down, menu left, menu right, " for Control element 6gang antique brass - Platform 63	6108/61-840-500	1	piece
2CKA006155A0114	Cover plate Symbols "up, down, ECO, menu" for Room temperature controller antique brass - Platform 63	6109/03-840-500	1	piece
2CKA006132A0407	Motion detector Movement sensor Twisted Pair Wiring antique brass - Platform 63	6122/10-840-500	1	piece
2CKA006115A0452	Solo antique brass - Platform 63	6125/02-840-500	1	piece
2CKA006116A0227	cont.-element KNX 2g	6126/02-840-500	1	piece
2CKA006117A0252	cont.-element KNX 4g	6127/02-840-500	1	piece
2CKA006134A0341	Solo 4gang brass - Platform 63	6128/28-840	1	piece
2CKA006134A0342	Solo antique brass - Platform 63	6128/28-840-500	1	piece
2CKA006136A0207	Adapter frame -811	6136/27-811	1	piece
2CKA006136A0209	Adapter frame -811	6136/27-811-500	1	piece
2CKA006136A0208	Adapter frame -825	6136/27-825	1	piece
2CKA006136A0210	Adapter frame -825	6136/27-825-500	1	piece

Identifier	Description	Type	Qty	Unit Of Measure
2CKA006200A0179	Motion Detectors Movement sensor Wireless brass - Platform 63	62762-840-WL- 500	1	piece
2CKA006200A0247	Motion Detectors Enrolment device Wireless brass - Platform 63	62764-840-WL- 500	1	piece
2CKA006800A2934	Busch-Watchdog Cover plate Movement sensor antique brass - Platform 63	64761-840-500	1	piece
2CKA006800A2971	Busch-Watchdog Cover plate Movement sensor antique brass - Platform 63	64762-840-500	1	piece
2CKA006800A3008	Busch-Watchdog Cover plate Movement sensor antique brass - Platform 63	64764-840-500	1	piece
2CKA006800A2896	Busch-Comfort switch® flex Electronic Controls Movement sensor with LED Orientation light antique brass - Platform 63	64765-840-500	1	piece
2CKA006599A3024	Electronic Controls for Dimmer Two-part button antique brass - Platform 63	6545-840-500	1	piece
2CKA006710A0015	Bluetooth Low Energie (BLE/Casambi) Smart Switch insert Casambi	6716 UBT	1	piece
2CKA006710A0024	Bluetooth Low Energie (BLE/Casambi) Smart Switch insert Casambi	6716/10 UBT	1	piece
2CKA006730A0094	cont.-element WaveL 1g	6731-840-500	1	piece
2CKA006730A0095	cont.-element WaveL 2g	6732-840-500	1	piece
2CKA006800A2841	Electronic Controls antique brass - Platform 63	6815-840-101-500	1	piece
2CKA008200A0262	Cover plate with legend Radio 0 gang antique brass - Platform 63	8252-840-101-500	1	piece
2CKA008200A0191	Multimedia Devices Loudspeaker antique brass - Platform 63	8253-840-500	1	piece
2CKA006220A0384	c-plate temp.	CP-RTC-840	1	piece
2CKA006220A0385	WD 180 sens	MD-F-1.0.1-840	1	piece
2CKA006220A0386	WD 180 sens actuator	MSA-F-1.1.1-840	1	piece
2CKA006220A0371	Rocker 1gang antique brass - Platform 63	SR-1-840	1	piece
2CKA006220A0376	Rocker 2gang antique brass - Platform 63	SR-2-840	1	piece
2CKA006220A0373	Rocker 1gang antique brass - Platform 63	SRB-1-840	1	piece
2CKA006220A0378	Rocker Symbol "venetian blind" 2gang antique brass - Platform 63	SRB-2-840	1	piece
2CKA006220A0375	Rocker Symbol "dimming" 1gang antique brass - Platform 63	SRD-1-840	1	piece
2CKA006220A0380	Rocker Symbol "dimming" 2gang antique brass - Platform 63	SRD-2-L-840	1	piece
2CKA006220A0383	Rocker Symbol "dimming" 2gang antique brass - Platform 63	SRD-2-R-840	1	piece
2CKA006220A0372	Rocker Symbol "light" 1gang antique brass - Platform 63	SRL-1-840	1	piece
2CKA006220A0377	Rocker Symbol "light" 2gang antique brass - Platform 63	SRL-2-L-840	1	piece
2CKA006220A0381	Rocker Symbol "light" 2gang antique brass - Platform 63	SRL-2-R-840	1	piece
2CKA006220A0374	Rocker Symbol "scene" 1gang antique brass - Platform 63	SRS-1-840	1	piece
2CKA006220A0379	Rocker Symbol "scene" 2gang antique brass - Platform 63	SRS-2-L-840	1	piece
2CKA006220A0382	Rocker Symbol "scene" 2gang antique brass - Platform 63	SRS-2-R-840	1	piece

Categories

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > free@home > User Operation > Frames

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > KNX > User Operation > Frames

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Frames

